







# INSTALLATION OPERATION AND SERVICE MANUAL

  	<p><b>GAS FIRED WALL HUNG &amp; FLOOR MOUNT RESIDENTIAL COMMERCIAL STAINLESS STEEL BOILERS</b> <i>DynaMax SERIES</i></p> <p><b>HYDRONIC HEATING</b> <i>Models; DMH081, 101, 151, 201, 251, 211, 261, 291, 391, 501, 601, 701, 801</i></p> <p><b>HOT WATER SUPPLY</b> <i>Models; DMW082, 102, 152, 202, 252, 212, 262, 292, 392, 502, 602, 702, 802</i></p> <p><b>COMBINATION HEATING/HOT WATER SUPPLY</b> <i>Models; DMC083, 103, 153, 203, 253, 213, 263, 293, 393, 503, 603, 703, 803</i></p>	  
---	---	---

## **WARNING:**

If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death

Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance.

### **WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance,
- Do not touch any electrical switch; do not use any phone in your building,
- Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions,
- If you cannot reach your gas supplier, call the fire department.

**Qualified installer, service agency or the gas supplier must perform installation and service.**

**To the Installer:** After installation, these instructions must be given to the end user or left on or near the appliance.

**To the End User:** This booklet contains important information about this appliance. Retain for future reference.



**CAMUS HYDRONICS LTD.**

6226 Netherhart Road, Mississauga, Ontario, L5T 1B7

99-0056  
Rev.03



## Contents

PART 1	GENERAL INFORMATION .....	1
1.1	INTRODUCTION.....	1
1.2	SPECIAL INSTRUCTIONS TO OWNER .....	1
1.3	CHECKING EQUIPMENT .....	1
1.4	DISPLAY UNIT .....	1
1.5	SEQUENCE OF OPERATION .....	1
1.5.1	Heat Transfer Process .....	1
1.5.2	End of Sequence.....	2
1.6	INSTALLATION CODES.....	2
1.7	WARRANTY .....	2
1.8	REMOVAL OF EXISTING APPLIANCE .....	2
1.9	BOILER/FURNACE ROOM OPERATING CONDITION .....	3
1.10	LOCATION OF UNIT .....	3
1.11	CLEARANCE FROM COMBUSTIBLE MATERIAL .....	4
PART 2	AIR INLET AND VENTING .....	8
2.1	GENERAL VENTING GUIDE .....	8
2.2	CATEGORY IV VENTING .....	8
2.2.1	Approved Venting Materials Category IV.....	8
2.3	CATEGORY II VENTING .....	9
2.3.1	Approved Venting Materials Category II.....	9
2.4	COMBINED COMBUSTION AIR INLET.....	9
2.5	VENT TERMINATION AND AIR INLET CLEARANCES.....	10
2.5.1	Sidewall Venting.....	10
2.5.2	Sidewall Air Inlet .....	10
2.5.3	Sidewall Concentric Vent/Air .....	11
2.6	Vertical Direct Venting.....	11
PART 3	GAS CONNECTION .....	13
3.1	GAS CONNECTION.....	13
3.2	GAS PIPING .....	13
3.3	INSTALL PIPING .....	13
3.4	CHECKING GAS SUPPLY PRESSURE .....	13
3.5	HIGH and LOW GAS PRESSURE SWITCHES (Optional) .....	14
3.6	AIR/GAS RATIO VALVE .....	14
3.7	BURNER.....	14
PART 4	WATER CONNECTION.....	15
4.1	FREEZE PROTECTION OUTDOOR INSTALLATION .....	15
4.2	WARNING REGARDING CHILLED WATER SYSTEMS .....	15
4.3	INLET AND OUTLET CONNECTIONS .....	15
4.4	MINIMUM PIPE SIZE REQUIREMENTS .....	15
4.5	HEAT EXCHANGER .....	16
4.6	LOW WATER TEMPERATURE SYSTEMS.....	16
4.7	PIPING ARRANGEMENTS .....	16
4.7.1	Field Supplied Components .....	16
4.8	FLOW PROVING DEVICE (wall mount models and combination models only).....	17
4.9	WATER FLOW SWITCH (Floor mount hydronic and DHW models only).....	18
4.10	LOW WATER CUTOFF (If Equipped) .....	18
4.11	RELIEF VALVE .....	18
4.12	DHW TUNING VALVE (combination models only) .....	18
PART 5	ELECTRICAL & CONTROLS.....	19
5.1	ELECTRICAL CONECTIONS .....	19
5.2	HIGH LIMIT .....	19
5.3	DYNAMAX CONTROLLER.....	19
5.3.1	SERVICE PARTS .....	19
5.3.2	IGNITION MODULE LOCKOUT FUNCTIONS .....	19
5.4	ERROR TABLE .....	20

5.4.1	Manual Reset Codes.....	20
5.4.2	Automatic Reset Codes .....	20
PART 6	CONTROL PANEL .....	21
6.1	DYNAMAX CONTROLLER.....	21
6.2	SETTING THE DYNAMAX CONTROLLER .....	21
6.3	CENTRAL HEATING MODES.....	21
6.4	DOMESTIC HOT WATER MODES .....	22
PART 7	COMPONENTS.....	23
7.1	DIRECT SPARK IGNITER .....	23
7.2	FLAME SENSOR .....	23
7.3	COMBUSTION AIR FAN .....	23
7.4	GAS VALVE .....	23
7.5	OUTER JACKET .....	23
PART 8	LABVISION SOFTWARE .....	24
8.1	INSTALLING LABVISION DRIVER ON WINDOWS XP .....	24
8.2	INSTALLING LABVISION DRIVER ON WINDOWS 7 .....	24
8.3	STARTING UP LAB VISION .....	24
8.4	ADJUSTING FAN SPEEDS .....	25
8.5	LABVISION CENTRAL HEATING .....	26
8.5.1	Central Heating Mode, Installer Level.....	26
8.5.2	Central Heating Mode = 1, 2, 3 Installer Level .....	27
8.6	LABVISION DOMESTIC HOT WATER .....	27
8.6.1	DHW Mode = 0, Installer Level.....	27
8.6.2	DHW Mode 1, 2 Installer Level.....	27
8.6.3	DHW Mode 4, Installer Level .....	28
8.7	LABVISION CASCADE.....	29
8.8	DATA LOGGING.....	30
8.8.1	Procedure for Viewing Log Files in Microsoft® Excel .....	31
8.8.2	Analysis of Microsoft® Excel Log File.....	31
8.9	Error History .....	32
PART 9	DYNAMAX CONTROL PANEL .....	33
9.1	INTRODUCTION TO THE DYNAMAX CONTROL PANEL .....	34
9.2	MENU SCREEN .....	35
9.3	SYSTEM MONITOR DISPLAY .....	36
9.4	DISPLAY OPTIONS DISPLAY .....	37
9.5	CENTRAL HEATING DISPLAY.....	38
9.6	DOMESTIC HOT WATER DISPLAY .....	39
9.7	CASCADE CONTROL .....	39
9.8	BOILER CONTROL.....	40
9.9	ERROR SCREEN.....	40
PART 10	TROUBLESHOOTING.....	41
10.1	SETTING THE CORRECT COMBUSTION.....	45
10.2	GAS VALVE ADJUSTMENT PROCEDURE .....	45
PART 11	MAINTENANCE .....	47
11.1	EXAMINE THE VENTING SYSTEM .....	47
11.2	VISUALLY CHECK MAIN BURNER FLAMES.....	47
11.3	CLEANING BOILER HEAT EXCHANGER .....	47
11.4	CONDENSATE TREATMENT.....	48
11.5	IGNITER AND FLAME SENSOR ELECTRODES .....	48
11.6	CHECK IGNITER GROUND WIRING .....	48
11.7	BURNER MAINTENANCE .....	48
11.7.1	Burner Removal and Cleaning.....	48
11.8	COMBUSTION AND VENTILATION AIR .....	49
11.9	GAS VALVE VOLTAGE .....	49
11.10	COMBUSTIBLE MATERIALS .....	49
11.11	FREEZE PROTECTION FOR INDOOR & OUTDOOR INSTALLATIONS .....	49

11.12	FREEZE PROTECTION FOR A HEATING BOILER SYSTEM (Optional) .....	49
PART 12	INSTALLATIONS .....	50
12.1	CHECKING THE INSTALLATION .....	50
12.2	CHECKING THE CONSTRUCTION .....	50
12.3	HEATING BOILER INSTALLATIONS .....	50
12.4	INSPECT & RECHARGE CONDENSATE COLLECTION/NEUTRALIZING RESERVOIR .....	50
12.5	WATER CONNECTIONS .....	50
12.6	PIPING LENGTHS .....	50
12.7	SUMMARY .....	50
12.8	DOMESTIC HOT WATER WITH STORAGE TANK .....	51
12.9	DOMESTIC HOT WATER WITH PLATE HEAT EXCHANGER .....	51
12.10	TEMPERATURE RISE AT FULL FIRING RATE .....	52
12.11	SETTING THE CORRECT COMBUSTION .....	53
12.12	CASCADE SETUP .....	53
12.13	INTERFACE MODULE (if equipped) .....	54
12.14	Write Functionality .....	57
12.14.1	Write CH Setpoint .....	57
12.14.2	Write DHW Setpoint .....	58
12.15	Alarm Output (if equipped) .....	58
12.16	External Reset (if equipped) .....	58
12.17	0-10Vdc External Input (if equipped) .....	58
12.18	APPLIANCE .....	59
12.19	IGNITION CYCLE .....	60
PART 13	PIPING DIAGRAMS .....	61
PART 14	EXPLODED VIEW & PARTS LIST .....	66
	DYNAMAX WALL HUNG .....	66
	DYNAMAX FLOOR MOUNT .....	67
PART 15	ELECTRICAL DIAGRAMS .....	74
15.1	DM 80- 250 INTERNAL WIRING DIAGRAM (WALL HUNG MODELS) .....	74
15.2	DM 210-299 INTERNAL WIRING DIAGRAM (FLOOR MOUNT MODELS) .....	75
15.3	848IF Interface Module Wiring Schematic .....	76
15.4	FIELD WIRING .....	77
15.4.1	System Sensor .....	77
15.4.2	Cascade Setup .....	77
15.5	DETAILED CONNECTOR DESCRIPTION .....	78



## PART 1 GENERAL INFORMATION

### 1.1 INTRODUCTION

The **DynaMax** boiler is a fan assisted boiler based on a push through design which offers several venting options. Heat output is controlled by a one to one air/gas ratio control gas valve which provides seamless modulation. The boiler provides central heating, domestic hot water or combination heating with DHW priority at working pressure up to 160 PSI. It is designed for use with a fully pumped and pressurized water system. The boiler/water heater will automatically modulate to provide heat outputs from 100% down to approximately 20% of rated input.

The DynaMax utilizes a negative pressure gas valve. The operation of the fan will generate a negative pressure in the venturi, which draws in a matching amount of gas through the valve.

During operation the DynaMax maintains steady state efficiency across the entire range of modulation. Air and gas are metered in precise proportion (1:1 Ratio) allowing combustion characteristics which determine efficiency to remain the same over the entire operating range.

The DynaMax is designed so that all of the sensible heating value and most of the latent heat is being transferred to the water.

### 1.2 SPECIAL INSTRUCTIONS TO OWNER

This manual supplies information for the installation, operation and servicing of the appliance. It is strongly recommended that this manual be reviewed completely before proceeding with an installation

#### CAUTION

It is important that all gas appliances are installed by a qualified installer/technician. It is in your own interest and that of safety to ensure that all local codes, and all the following "NOTES" and "WARNINGS" are complied with. Installing, servicing or adjusting this appliance should be performed only by a qualified installer/technician that is trained by Camus Hydronics. The serviceman must utilize a combustion analyzer with CO<sub>2</sub>, CO, and draft gauge, to set the appliance according to Camus Hydronics' recommendations, prior to commissioning.

#### NOTE

RETAIN THIS MANUAL FOR FUTURE REFERENCE

### 1.3 CHECKING EQUIPMENT

Check for signs of shipping damage upon receiving equipment. Pay particular attention to parts accompanying the boiler, which may show signs of being hit or otherwise being mishandled. Verify total number of pieces shown on packing slip with those actually received. In case there is damage or a shortage, immediately notify carrier.

### 1.4 DISPLAY UNIT

The display unit will indicate status and will display selected temperature. Refer to Part 9 DynaMax Control Panel, which provides details to modes and error codes displayed on the appliance.

### 1.5 SEQUENCE OF OPERATION

- 1) Power switch is placed in the "ON" position.
- 2) Minimum 120 VAC 60Hz single phase (15A circuit) is supplied to the DynaMax field connection board.
- 3) 120 VAC power is supplied to the DynaMax Controller which provides all setup and ignition control functions.
- 4) Access to settings is through the use of a USB A-to-B cable using a laptop computer through the USB port on the DynaMax Control Panel.
- 5) After the appliance water pump starts, flow is proven by the flow proving device or flow switch. The normally open dry contacts in the low water cutoff (LWCO), if supplied, is to be wired in series with the normally open contacts of the flow proving device.
- 6) Locate the probe type LWCO in the piping at least 3 feet above the boiler/ inlet connection. In all cases check with local codes.
- 7) Depending on the selected mode, the appliance operates as a master or slave configuration.
- 8) The DynaMax Controller initiates a startup sequence once it receives a heat demand.
- 9) The DynaMax Controller energizes the on-board pump and starts to ramp up the voltage to the electrically commutated DC motor of the combustion fan.
- 10) The fan will run at pre-purge speed until the pre-purge timer is satisfied. Once this is complete the DynaMax controller provides a signal to modulate down to ignition fan speed.
- 11) The DynaMax controller goes through internal safety checks and if this is satisfied the ignition sequence begins.
- 12) The DynaMax Controller supplies voltage to the air/gas ratio control valve. The air/gas ratio control valve senses the pressure across the venturi and supplies gas to pre-mix with air.
- 13) The igniter will continue to spark for 6 seconds, with the gas valve opened, and the fan running at ignition speed.
- 14) Spark Igniter lights the air/gas mixture. The DynaMax Controller looks for a minimum flame rectification signal of 1.25  $\mu$ A DC from the flame sensor. If the signal is present the DynaMax Controller will allow the gas valve to remain open. The burner is now firing at starting input rate.
- 15) Boiler will modulate to the correct fan speed to meet heat demand. The modulation rate is controlled via Pulse Width Modulation (PWM) signal.
- 16) Fan speed will slowly decrease as heat request nears the heat demand. If heat demand is sustained for a long duration of time the boiler will get to a point of steady-state and the fan will rotate at constant speed.
- 17) When the heat demand is satisfied or is removed the burner will shut off and the fan speed will ramp up to the preset post-purge speed until the post-purge timer is satisfied.
- 18) The boiler will then go into standby as it waits for the next heat demand.

#### 1.5.1 Heat Transfer Process

- 1) Burner input continues to increase until outlet water temperature reaches the setpoint temperature.
- 2) Burner input may stabilize at a fixed rate where demand equals input.
- 3) Burner input will decrease rate when outlet water temperature approaches temperature Set Point.

### 1.5.2 End of Sequence

- 1) Setpoint temperature is satisfied.
- 2) Power to the gas valve is turned off.
- 3) Combustion Air Fan ramps to a stop over the factory preprogrammed time period.
- 4) Thermostat is now in standby mode waiting for the next "Call for Heat".

<b>WARNING</b>
To minimize the possibility of serious personal injury, fire or damage to your appliance, never violate the following safety rules.

<b>DO NOT</b>
Do not use this appliance if any part of it has been <b>under water</b> . The possible damage to a flooded appliance can be extensive and present numerous safety hazards. Any appliance that has been <b>under water</b> must be replaced

<b>WHAT TO DO IF YOU SMELL GAS</b>
Do not try to light any appliance. • Do not touch any electric switch: do not use any phone in your building. • Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. • If you cannot reach your gas supplier, call the fire department.

<b>IMPORTANT</b>
Consult and follow local Building and Fire Regulations and other Safety Codes that apply to this installation. Contact the local gas utility company to inspect and authorize all gas and flue connections.
<b>Installation and service must be performed by a qualified technician/installer, and trained by Camus Hydronics.</b>

<b>WARNING</b>
Should overheating occur or the gas supply fails to shut off, <b>DO NOT</b> turn off or disconnect the electrical supply to the pump. Shut off the gas supply at a location external to the appliance.

- Boilers and water heaters are heat producing appliances. To avoid damage or injury, do not store materials against the appliance or the vent-air inlet system. Use proper care to avoid unnecessary contact (especially children) with the appliance and vent-air inlet components.
- Never cover appliance, lean anything against it, store trash or debris near it, stand on it or in any way block the flow of fresh air to appliance.
- **UNDER NO CIRCUMSTANCES** may flammable materials such as gasoline or paint thinner be used or stored in the vicinity of this appliance, vent-air inlet system or any location from which fumes could reach the appliance or vent-air inlet system.
- A gas appliance that draws combustion air from the equipment room where it is installed must have a supply of fresh air circulating around it during burner operation for proper gas combustion and proper venting.

### 1.6 INSTALLATION CODES

The equipment shall be installed in accordance with those installation regulations enforced in the local area where the installation is to be made. These shall be

carefully followed in all cases. Authorities having jurisdiction shall be consulted before installations are made. In the absence of such requirements, the installation shall conform to the latest edition or current as amended of the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA-B149 Installation Code. All electrical wiring must be done in accordance with the requirements of the authority having jurisdiction or, in the absence of such requirements, with national electrical code, ANSI/NFPA70 and/or the Canadian electrical code part 1 CSA C22.1. Where required by the authority having jurisdiction, the installation must conform to American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers, ASME CSD-1. All boilers must conform to the latest edition of the ASME Boiler and Pressure Vessel Code, Section II. Where required by the authority having jurisdiction, the installation must comply with the CSA International, CAN/CGA-B149 and/or local codes. This appliance meets the safe lighting performance criteria with the gas manifold and control assembly provided, as specified in the ANSI standards for gas-fired units, ANSI Z21.13.

### 1.7 WARRANTY

- Factory warranty (shipped with unit) does not apply to units improperly installed or improperly operated.
- Factory warranty shall apply only when the appliance is installed in accordance with local plumbing and building codes, ordinances and regulations, the printed instructions provided with it and good industry practices.
- Excessive **water hardness** causing a lime build-up in the stainless steel coils or tubes is not a fault of the appliance and is not covered by warranty. Consult the factory for recommendations for use in hard water areas. (See Water Treatment and Water Chemistry)
- Using or storing **corrosive chemicals** in the vicinity of this appliance can rapidly attack the stainless steel venting and heat exchanger coils and voids warranty.
- Damage caused by **freezing or dry firing** voids warranty.
- This appliance is not to be used for **temporary heating** of buildings under construction.
- The manufacturer shall **NOT** be held liable for any personal injury or property damage due to ice formation or the dislodging of ice from the vent system or the vent termination

### 1.8 REMOVAL OF EXISTING APPLIANCE

When an existing appliance is removed from a common venting system, the common venting system is likely to be too large for proper venting of the appliances remaining connected to it. At the time of removal of an existing appliance, the following steps must be followed with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation.

- Seal any unused openings in the common venting system.
- Visually inspect the venting system for proper size and horizontal pitch and determine that there is no blockage, restriction, leakage, corrosion or other





- deficiency, which could cause an unsafe condition. Insofar as is practical, close all building doors and windows and all doors between the spaces in which the appliances remaining connected to the common venting system are located and other spaces of the building. If applicable turn on the clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
- Place in operation the appliance being inspected. Follow the lighting instructions. Adjust thermostat so that appliance operates continuously.
- Test for spillage at the draft control device relief opening after 5 minutes of main burner operation. Use a cold mirror, the flame of a match, or a candle or smoke from a cigarette.
- After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous condition of use.
- Any improper operation of the common venting system should be corrected so that the installation conforms to the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA B149, Installation Codes. When resizing any portion of the common venting system, the common venting system should be resized to approach the minimum size as determined using the appropriate tables in Part 11 of the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA B149, Installation Codes.

Heat exchanger surfaces and vent piping should be checked every six months for deterioration and carbon deposits. Remove all soot or other obstructions from the chimney and flue, which might impede draft action. Replace any damaged or deteriorated parts of the venting system.

A qualified service technician should follow this procedure when inspecting and cleaning the heat exchanger and vent pipe.

- 1) Turn off electrical power and main manual gas shut-off and allow appliance to cool down.
- 2) Remove the vent pipe at connection to heat exchanger and check heat exchanger and vent for obstruction and clean as necessary.
- 3) Remove burner from appliance and carefully clean as required. Never brush or wipe the knitted metal fiber surface. Use a garden hose or gently wash under the tap. Vacuum out any deposits found in the heat exchanger.

#### CAUTION

Never use a pressure washer or compressed air to clean the burner.

- 4) Reinstall parts removed in steps 2 and 3. Be sure that vent pipe has proper pitch and is properly sealed. Replace any damaged gasket or refractory. Tighten fan flange mounting nuts to 3 ft-lb.
- 5) Restore electrical power and gas supply to appliance.
- 6) Place appliance in operation using lighting instructions provided.

- 7) Confirm proper operation of all safety devices
- 8) Check for gas leaks and proper vent operation.

#### NOTE

Experience has shown that improper installation or system design, rather than faulty equipment, is the cause of most operating problems

### 1.9 BOILER/FURNACE ROOM OPERATING CONDITION

- Due to low jacket losses from the appliance, temperatures in the vicinity of the boiler room may drop significantly; supplemental heat is required to maintain ambient temperature at acceptable levels.

### 1.10 LOCATION OF UNIT

Install this appliance in a clean, dry location with adequate service clearance.

- Do not locate this appliance in an area where it will be subject to freezing unless precautions are taken. Radiant losses from the DynaMax are minimal and should not be relied on to keep the appliance room warm.
- The appliance should be located close to a floor drain in an area where leakage from the appliance or connections will not result in damage to the adjacent area or to lower floors in the structure, it is recommended that a suitable drain pan, adequately drained, be installed under the unit. Under no circumstances is the manufacturer to be held responsible for water damage in connection with this unit, or any of its components.
- If the appliance is installed above the level of the building's radiation system, a low water cut-off device must be installed in the appliance outlet at a minimum of 3 ft (1M) above the heat exchanger inlet/outlet connections. Some local codes require the installation of a low water cut-off on all systems
- When placing the appliance be aware that a minimum clearance of 24" must be provided at the front to allow easy access to the heat exchanger. DynaMax wall mount units do not require access through the sides and can be placed adjacent to each other with zero clearance. Floor mount units require access on the left side.
- The appliance must be installed so that the ignition system components are protected from water (dripping, spraying, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)
- Appliances located in a residential garage and in adjacent spaces that open to the garage and are not part of the living space of a dwelling unit must be installed so that all burners and burner ignition devices have a minimum clearance of not less than 18" (46cm) above the floor. The appliance must be located or protected so that it is not subject to physical damage by a moving vehicle.
- **DO NOT** install this appliance in any location where gasoline or flammable vapors are likely to be present.
- Appliance must be installed on a level floor. Maintain required clearances from combustible surfaces.



- The appliance designed for indoor installation (Indoor Models) must be installed indoors where it is protected from exposure to wind, rain and weather.
- The appliance designed for outdoor installation (Outdoor Models) must be installed outdoors. Always consider the use of a shelter such as a garden shed in lieu of direct exposure of the appliance to the elements. The additional protection afforded by the shelter will help to minimize nuisance problems with electrical connections and will allow easier servicing of the appliance under severe weather conditions.


### 1.11 CLEARANCE FROM COMBUSTIBLE MATERIAL

This appliance is suitable for alcove (a closet without a door) installation with minimum clearances to combustibles as follows:


**Table 1: Clearance from Combustibles**

Clearances from Combustibles		
	Wall Hung Model	Floor Mount Model
TOP:	0"	0"
SIDES:	0"	0"
REAR:	0"	12"
VENT (Vent Adapter):	1"	1"
VENT (PVC/CPVC):	0"	0"
FRONT:	3"	6"

**Figure 1: Wall Hung Clearance from Combustibles**



**Figure 2: Floor Mount Clearance from Combustibles**




#### NOTE

Clearances from combustible construction are noted on the appliance rating plate

**Table 2: DynaMax Wall Hung Service Clearances**

Model	Service Clearance, Inches (cm)				
	Front	Top	Right Side	Left Side	Rear
80	24" (61cm)	3" (8 cm)	4" (10 cm)	4" (10 cm)	0" (0 cm)
100	24" (61cm)	3" (8 cm)	4" (10 cm)	4" (10 cm)	0" (0 cm)
150	24" (61cm)	3" (8 cm)	4" (10 cm)	4" (10 cm)	0" (0 cm)
200	24" (61cm)	3" (8 cm)	4" (10 cm)	4" (10 cm)	0" (0 cm)
250	24" (61cm)	3" (8 cm)	4" (10 cm)	4" (10 cm)	0" (0 cm)

**Figure 3: DynaMax Wall Hung Model Dimensions**



**Table 3: Appliance Dimensions and Specifications**


Model	Depth Dim. "A" [in.]	Dim. "B" [in.]	Equivalent Length of Vent & Air Intake Pipes at Recommended Diameter, [in.]			Water Connection at Boiler [in.] NPT	Gas Connection at Boiler [in.] NPT
			Over 25' and up to 100'	Over 15' and up to 25'	Up to 15'		
80	16 1/2	12	3	3	2	1	1/2
100	16 1/2	12	3	3	2	1	1/2
150	16 1/2	12	3	3	2	1	1/2
200	23 1/2	19	3	3	2	1	1/2
250	23 1/2	19	3	3	2	1 1/4	1/2

Maintain minimum specified clearances for adequate operation. All installations must allow sufficient space for servicing the vent connections, water pipe connections, circulating pump, bypass piping and other auxiliary equipment, as well as the appliance

**Table 4: DynaMax Floor Mount Service Clearances**

Model	Service Clearance, Inches (cm)				
	Front	Top	Right Side	Left Side	Rear
210	12" (31cm)	24" (61cm)	0" (0cm)	12" (31cm)	14" (36 cm)
260	12" (31cm)	24" (61cm)	0" (0cm)	12" (31cm)	14" (36 cm)
299	12" (31cm)	24" (61cm)	0" (0cm)	12" (31 cm)	14" (36cm)
399	12" (31cm)	24" (61cm)	0" (0cm)	12" (31 cm)	14" (36 cm)
500	12" (31cm)	24" (61cm)	0" (0cm)	12" (31 cm)	14" (36 cm)
600	12" (31cm)	24" (61cm)	0" (0cm)	12" (31 cm)	14" (36cm)
700	12" (31cm)	24" (61cm)	0" (0cm)	12" (31 cm)	14" (36 cm)
800	12" (31cm)	24" (61cm)	0" (0cm)	12" (31 cm)	14" (36 cm)

**Figure 4: DynaMax Floor Mount Model Dimensions**




**Table 5: Appliance Dimensions and Specifications**


Model	Height Dim. "A" [in.]	Dim. "B" [in.]	Dim. "J" [in.]	Equivalent Length of Vent & Air Intake Pipes at Recommended Diameter, [in.]				Water Connection at Heater [in.] NPT	Gas Connection at Boiler [in.] NPT
				Category IV			CAT.II Comb. Vents		
				Over 25' and up to 100'	Over 15' and up to 25'	Up to 15'			
210	36	22 3/4	32	3	3	2	4	1	1/2
260	36	22 3/4	32	3	3	2	4	1 1/4	1/2
299	47 1/8	34 7/8	32	4	3	3	5	1 1/4	3/4
399	47 1/8	34 7/8	32	4	3	3	5	1 1/2	1
500	47 1/8	34 7/8	32	4	3	3	6	1 1/2	1
600	47 1/8	36 1/4	40 1/2	4	3	3	6	2	1
700	47 1/8	36 1/4	40 1/2	4 (Air), 5 (Vent)	4	4	7	2	1
800	47 1/8	36 1/4	40 1/2	5 (Air), 6 (Vent)	5	5	7	2	1

Maintain minimum specified clearances for adequate operation. All installations must allow sufficient space for servicing the vent connections, water pipe connections, circulating pump, bypass piping and other auxiliary equipment, as well as the appliance

**Figure 5: DynaMax Wall Hung Service Clearances**



**Figure 6: DynaMax Floor Mount Service Clearances**





## PART 2 AIR INLET AND VENTING

### **⚠ DANGER**

**It is extremely important to follow these venting instructions carefully. Failure to do so can cause severe personal injury, death or substantial property damage.**

### 2.1 GENERAL VENTING GUIDE

The DynaMax Wall Hung is a category IV condensing appliance, 97% efficient unit. The DynaMax Floor Mount is a category II condensing appliance, 97% efficient.

- The DynaMax may be vented with: manufactured prefabricated UL/ ULC listed vents of AL29-4C or 316L stainless steel or with plastic vent certified to UL/ ULC S636, such as, IPEX System 636 CPVC or IPEX System 636 PVC or as permitted by local jurisdictions.
- The DynaMax boiler must be vented and supplied with combustion and ventilation air as described in this section. Ensure that the venting and combustion air supply complies with these instructions.
- Installations must be in accordance with Part 7, "Venting of Equipment", of the latest edition of the National Fuel Gas Code, ANSI Z223.1 for US installations or the latest edition of CAN/CGA Standard B149 Installation Code for Gas Burning Appliances and Equipment in Canada.
- The distance of the vent terminal from adjacent buildings, windows that open and building openings MUST comply with the latest edition of the National Fuel Gas Code, ANSI Z223.1 for U.S. installations or CAN/CGA Standard B149 Installation Code for Canadian Installations.
- Vent connection is made directly to the flue outlet opening on top of the unit for the wall mount unit and at the back of the unit for floor mount. The connection from the appliance vent to the stack must be made as direct as possible. The first 3 feet of vent from the appliance flue outlet must be readily accessible for visual inspection.
- Vent connectors serving appliances vented by natural draft shall not be connected into any portion of a mechanical draft system operating under positive pressure.
- A UL listed concentric vent/air intake kit may be used with the DynaMax.
- Horizontal runs of vent pipe shall be securely supported (approximately every 4 feet) to prevent sagging and maintain a minimum upward slope of 1/4" per foot from the appliance to the vent terminal.
- The weight of the venting system must not rest on the unit. Adequate support of the venting system must be provided in compliance with local codes and other applicable codes.
- All connections should be secured and sealed per the vent manufacturer's specifications. When a positive vent system is disconnected for any reason, the flue must be reassembled and resealed according to the vent manufacturer's instructions.
- Do not use an existing chimney as a raceway if another appliance or fireplace is vented through the chimney.
- Inspect completed vent and air supply piping thoroughly to ensure all connections are sealed and

are in compliance with the instructions provided and satisfy requirements of all applicable codes.

### NOTE

All vent pipes must be properly assembled and supported, and the exhaust must be pitched a minimum of 1/4 inch per foot back to the boiler. All components used to fabricate and assemble the vent system are to originate from the same supplier.

When determining equivalent inlet air and vent lengths of 3" diameter add 3 to 5 feet for each 90° elbow and 2 to 3 feet for each 45° elbow, depending on centerline radius of the elbow.

Example: 30 feet of CPVC pipe + (3 x 5 feet) 90° elbows + (1 x 3 feet) 45° elbow = 48 equivalent feet of piping for centerline radius of 1.5D, where D is the pipe diameter.

### 2.2 CATEGORY IV VENTING

A category IV appliance is individually vented through a dedicated vent.

The DynaMax Wall Hung boilers/ water heaters shall only be vented as a Category IV appliance.

Both Wall Hung and Floor Mount appliances shall be vented using sealed positive vent suitable for a condensing appliance with the following venting options:

- 1) Sidewall or rooftop termination where both the vent and combustion air inlet air are in the same zone. The inlet and vent terminals are to be installed with a minimum 12" separation distance between centerline of inlet and centerline of exhaust. Refer to Fig. 8, 9, and 10 for sidewall termination and Fig. 11 for rooftop termination.
- 2) Sidewall termination with vent and combustion air inlet from separate zones.
- 3) Single Pipe thru wall or rooftop venting with combustion air inlet from the boiler room.

### NOTE

Vent Option 3 not recommended for R-2000 homes or equivalent air tight construction.

#### 2.2.1 Approved Venting Materials Category IV

- 1) PVC and CPVC (Chlorinated Polyvinyl Chloride) Schedule 40 or 80 approved to ULC S636.
- 2) Manufactured prefabricated UL/ULC listed vent of AL29-4C or 316L stainless steel. Use of 316L is limited to use in applications where there is no possibility of contaminants in the air such as refrigerants, chlorine etc.
- 3) PVC-DWV approved to comply with ANSI/ASTM D2665 (US Jurisdictions ONLY when permitted)
- 4) PVC Schedule 40 approved to comply with ANSI/ASTM D1785. (US Jurisdictions ONLY when permitted)
- 5) CPVC Schedule 40 approved to comply with ANSI/ASTM F441. (US Jurisdictions ONLY when permitted)
- 6) Polypropylene approved to comply with ULC S636

**Table 6: Maximum Flue Temperature for Various Vent Materials**

Vent Material	Maximum Flue Temperature [°F]
PVC	149
CPVC	194
PPE	230
AL29-4C	300+, limited only by rating of seals
316L Stainless Steel	300+, limited only by rating of seals

Stack temperature is 10-15°F below outlet temperature when operating at steady-state

**Air Inlet (Supply Air or Fresh Air) Piping**

- PVC
- CPVC (Chlorinated Polyvinyl Chloride)
- PPE (Polypropylene)
- ABS (Acrylonitrile-Butadiene-Styrene)
- Single wall, Galvanized
- Single wall, Stainless steel
- Single wall, Aluminium

Single wall air inlet pipes are to be insulated 5 feet from the wall toward the interior of the building to minimize external sweating.

The following air intake options shall be utilized:

- Outside air sealed direct (vertical or horizontal)
- Outside air ducted to jacket flange
- Indoor Air

NOTE
For wall hung units that are installed outdoors the bottom of the unit must be at least 36" above ground or 12" above normal snow levels.
NOTE
Sealed combustion is required when DynaMax is placed in a space with other fan-assisted appliances.

**Table 7: Required Vent and Air Inlet Diameters**

Model	Equivalent Length of Vent & Air Intake Pipes at Recommended Diameter*			
	Category IV			Category II
	Over 25' and up to 100'	Over 15' and up to 25'	Up to 15'	
80	3"	3"	2"	-
100	3"	3"	2"	-
150	3"	3"	2"	-
200	3"	3"	2"	-
210	3"	3"	2"	4"
250	3"	3"	2"	-
260	3"	3"	2"	4"
299	4"	3"	3"	5"
399	4"	3"	3"	5"
500	4"	3"	3"	6"
600	4"	3"	3"	6"
700	4" (Air), 5" (Vent)	4"	4"	7"
800	5" (Air), 6" (Vent)	5"	5"	7"

\* Consult factory for recommendations applicable to venting combinations not shown above.

**2.3 CATEGORY II VENTING**

A category II appliance may be combined into a common negative pressure venting system designed to ASHRAE requirements using a proven vent sizing program. Vent designs are to be certified by a qualified professional designer acceptable to the authority having jurisdiction.

The DynaMax Floor Mount boiler may be vented as a Category II appliance using sealed vent suitable for a condensing appliance.

**2.3.1 Approved Venting Materials Category II**

- 1) PVC and CPVC Schedule 40 or 80 approved to ULC S636.
- 2) Manufactured prefabricated UL/ULC listed vent of AL29-4C or 316L stainless steel. Use of 316L is limited to use in where there is no possibility of contaminants in the air such as refrigerants, chlorine etc.
- 3) PVC-DWV approved to comply with ANSI/ASTM D2665 (US Jurisdictions ONLY when permitted).
- 4) PVC Schedule 40 approved to comply with ANSI/ASTM D1785. (US Jurisdictions ONLY when permitted)
- 5) CPVC Schedule 40 approved to comply with ANSI/ASTM F441. (US Jurisdictions ONLY when permitted).
- 6) Polypropylene approved to comply with ULC S636

**Air Inlet (Supply Air or Fresh Air) Piping**

- PVC
- CPVC (Chlorinated Polyvinyl Chloride)
- ABS (Acrylonitrile-Butadiene-Styrene)
- PPE (Polypropylene)
- Single wall, Galvanized
- Single wall, Stainless steel
- Single wall, Aluminium

Single wall air inlet pipes are to be insulated 5 feet from the wall toward the interior of the building to minimize external sweating.

The following air intake options shall be utilized:

- Outside air sealed direct (vertical or horizontal)
- Outside air ducted to jacket flange
- Indoor Air

NOTE
Sealed combustion is required when DynaMax is placed in a space with other fan-assisted appliances.

**2.4 COMBINED COMBUSTION AIR INLET**

To avoid the possibility of nuisance lockouts in cold climates install DynaMax appliances with a combined combustion air inlet.

The combined combustion air inlet pipe sizing can be calculated using the method shown below:

Equivalent pipe diameter = Sq Root  $[(d_1)^2 + (d_2)^2 + (d_3)^2 + \dots + (d_n)^2]$ , where  $d_n$  = individual pipe diameter

- Example: Find the equivalent pipe diameter of three air inlet pipes, 3" (7.6cm), 3" (7.6cm) and 4" (10.2cm)

Equivalent pipe diameter = Sq Root $[(3)^2 + (3)^2 + (4)^2]$  = Sq Root(34) = 5.8", select 6" (15.3cm) equivalent diameter pipe.




Air inlet point for multiple boiler air inlets must be provided with an exterior opening which has a free area equal to or greater than the total area of all air inlet pipes connected to the common air inlet. This exterior opening for combustion air must connect directly to the outdoors. The total length of the combined air inlet pipe must not exceed a maximum of 100 equivalent feet (30.5m). Deduct the restriction in an area provided by any screens, grills or louvers installed in the common air inlet point. Screens, grills or louvers installed in the common air inlet can reduce the free area of the opening from 25 to 75% based on the materials used. Calculate and compensate accordingly.

## 2.5 VENT TERMINATION AND AIR INLET CLEARANCES

### 2.5.1 Sidewall Venting


- The first 3 feet (1m) of vent from the appliance flue outlet must be readily accessible for inspection.

Figure 7: Vertical Configuration



- \* Always check local codes for minimum distance above ground or snow levels

Figure 8: Horizontal Configuration



- \* Always check local codes for minimum distance above ground or snow levels


### Location of Vent Termination

- Total length of vent piping must not exceed limits stated in Table 7.
- Bottom of vent terminal shall be located at least 12" (30cm) above grade or above normal snow levels. In all cases the appliance shall be installed in accordance with local codes
- DynaMax can vent up to 100 equivalent feet. Elbows can range from 3 to 5 feet in equivalent length depending on the centerline radius.
- Vent outlet shall terminate at least 12" (0.30m) away from any forced air inlet. Vent must be at least 7 feet (2.15m) above grade when located adjacent to public walkways due to normal formation of water vapour in the combustion process.

- Vent outlet **MUST NOT** terminate below a forced air inlet at any distance.
- Vent cannot terminate below grade. Position vent termination where vapours will not damage walls or plants or may be otherwise objectionable.
- Vent terminal shall not be installed closer than 3 feet (1m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.
- DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- Position terminations so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- Vent piping must terminate in an elbow pointed outward or away from air inlet.
- Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Keep the vent cap/terminal clear of snow, ice, leaves, debris etc. Some discolouration to exterior building surfaces is to be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.
- Perform regularly scheduled inspections to ensure vent terminal is unobstructed.

### 2.5.2 Sidewall Air Inlet

Figure 9: Sidewall Vent and Air Inlet Configuration



- \* Always check local codes for minimum distance above ground or snow levels



### Location of a Sidewall Air Inlet Cap

- 1) Total length of piping for air inlet must not exceed the limits stated in Table 7.
- 2) Point of termination for the sidewall air inlet cap must be located a minimum of 12 inches (0.30m) away from the flue gas termination, but never above.
- 3) Air piping must terminate in a down-turned elbow to avoid recirculation of flue products into the inlet air stream.
- 4) **DO NOT** terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 5) **DO NOT** terminate the air inlet in a window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect performance or cause recirculation.
- 6) Air inlet cannot terminate below grade.
- 7) Locate terminations so they are not likely to be damaged by foreign objects, or exposed to build-up of debris.
- 8) Perform regularly scheduled inspections to ensure that the air inlet terminal is unobstructed.

### 2.5.3 Sidewall Concentric Vent/Air

A concentric vent kit can be used with the DynaMax appliance. Both combustion air and vent pipes must terminate outside the structure.

- 1) Total length for venting or air must not exceed the limits stated in Table 7.
- 2) Bottom of the termination shall be located at least 1 foot (30cm) above grade or above normal snow levels. In all cases the appliance shall be installed in accordance with local codes
- 3) Termination **MUST NOT** terminate below a forced air inlet at any distance
- 4) Termination cannot terminate below grade. Position the termination where vapours will not damage walls or plants or may be otherwise objectionable.
- 5) The termination shall not be installed closer than 3 feet (1m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.
- 6) **DO NOT** terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 7) Position termination so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- 8) Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Keep the vent cap/terminal clear of snow, ice, leaves, debris etc. Some discolouration to exterior building surfaces is to be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.
- 9) Perform regularly scheduled inspections to ensure that the termination is unobstructed.
- 10) Operate the appliance for one heat cycle to ensure combustion air and vent pipes are properly connected to the concentric vent termination connections.

### CAUTION

Do not operate appliance with the rain cap removed as this may result in the recirculation of flue products. Water may also flow into the combustion air pipe and into the burner enclosure.

Figure 10: Concentric Sidewall Termination





Figure 11: Concentric Vent Sidewall



### Termination and Fittings

The air inlet opening must be at least 12 inches (0.30m) away from (never above) the vent termination and at least 3 feet (1m) above grade or above normal maximum snow levels.

## 2.6 Vertical Direct Venting


### Location of Vent Termination

- 1) Total length of piping for venting must not exceed limits stated in Table 8.
- 2) Vent piping must terminate in a 45° elbow if plastic piping is used or in an approved vent cap if using metal venting. Vent outlet must be at least 1 foot away and 1 foot above from the air inlet opening which must terminate in a double elbow facing downwards.
- 3) Vertical termination must be a minimum of 3 feet (1m) above the point of exit.
- 4) Vertical termination less than 10 feet (3.05m) from a parapet wall must be a minimum of 2 feet (0.61m) higher than the parapet wall.
- 5) **DO NOT** terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence.
- 6) Position the air inlet and vent terminations so they are not likely to be damaged by foreign objects, or exposed to build-up of debris.
- 7) Perform regularly scheduled inspections to ensure that the vent terminal is unobstructed.

### Location of a Vertical Air Inlet Opening

- 1) The total length of piping for inlet air must not exceed the limits given in Table 8.
- 2) The air inlet consists of two 90° elbows installed at the point of termination for the vertical air inlet pipe. A 90° elbow and a 90° street elbow may be used to make this assembly. If a straight piece of pipe is used between the two elbows, it should not exceed 6" (0.15m) in length. The air inlet opening must be at least 1 foot below the vent opening. The air piping must be no further than 2 feet (0.6m) from the center of the vent pipe. This arrangement avoids exhaust gases from re-circulating into the inlet air stream. Refer to Figure 10.
- 3) Air inlet must terminate at least 3 feet (1.0m) above the roof or normal snow levels and at least 1 foot (0.3m) below the vent termination.
- 4) Locate terminations so they are not likely to be damaged by foreign objects or exposed to build-up of debris.
- 5) Perform regularly scheduled inspections to ensure that the air inlet terminal is unobstructed.

**Figure 12: Vertical Direct Venting Configuration**



- 1) Total length of piping for venting or air must not exceed limits stated in Table 8.
- 2) Bottom of the termination shall be located at least 3 feet (1m) above grade or above normal snow levels. In all cases the appliance shall be installed in accordance with local codes
- 3) Termination **MUST NOT** terminate below a forced air inlet at any distance
- 4) Termination cannot terminate below grade. Position the termination where vapours will not damage walls or plants or may be otherwise objectionable.
- 5) Termination shall not be installed closer than 3 feet (1m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.
- 6) **DO NOT** terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 7) Position termination so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- 8) Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Keep the vent cap/terminal clear of snow, ice, leaves, debris etc. Some discolouration to exterior building surfaces is to


be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.

- 9) Perform regularly scheduled inspections to ensure that the termination is unobstructed.
- 10) Operate the appliance for one heat cycle to ensure combustion air and vent pipes are properly connected to the concentric vent termination connections.

### CAUTION

Do not operate appliance with the rain cap removed as this may result in the recirculation of flue products. Water may also flow into the combustion air pipe and into the burner enclosure.

**Figure 13: Concentric Vent Vertical Venting**



### Length of Air Inlet Pipe

The maximum total length of the sidewall or vertical roof top combustion air inlet pipe as installed from the appliance to the air inlet cap must not exceed 100 equivalent feet (30.5m) in length. Subtract 3 to 5 feet (1 to 1.5m) of equivalent length depending on centerline radius for each 90° elbow installed in the air inlet pipe system. Pressure drop in each 45° elbow will be half as much, 2 to 3 feet (0.6 to 1.0m).

## PART 3 GAS CONNECTION

Verify that the appliance is supplied with the type of gas specified on the rating plate. Consult factory for installations at high altitude.

### 3.1 GAS CONNECTION

- Safe operation of unit requires properly sized gas supply piping. See gas line sizing data.
- Gas pipe size may be larger than appliance connection.
- Installation of a union at the appliance gas line connection is required for ease of service and removal of the gas train.
- Install a manual main gas shutoff valve, outside of the appliance gas connection as require by local codes.
- A trap (drip leg) **MUST** be provided in the inlet gas connection to the appliance.
- Optional gas controls may require routing of bleeds and vents to the atmosphere, outside the building when required by local codes.

**Table 8: Recommended Gas Pipe Size**

Single Appliance Installation

(For distance from natural gas meter or propane second stage regulator)

Input	0-100 FT		101-200 FT		201-300 FT	
Btu/Hr, x1000	NAT.	L.P.	NAT.	L.P.	NAT.	L.P.
80	3/4"	1/2"	3/4"	1/2"	1"	3/4"
100	3/4"	1/2"	1"	3/4"	1"	3/4"
150	1"	3/4"	1 1/4"	1"	1 1/4"	1"
200	1"	3/4"	1 1/4"	1"	1 1/4"	1"
250	1 1/4"	1"	1 1/4"	1"	1 1/2"	1 1/4"
299	1 1/4"	1"	1 1/2"	1 1/4"	1 1/2"	1 1/4"
399	1 1/4"	1"	1 1/2"	1 1/4"	2"	1 1/2"
500	1 1/2"	1 1/4"	2"	1 1/2"	2"	1 1/2"
600	1 1/2"	1 1/4"	2"	1 1/2"	2"	1 1/2"
700	2"	1 1/2"	3"	2 1/2"	3"	2 1/2"
800	2"	1 1/2"	3"	2 1/2"	3"	2 1/2"

### 3.2 GAS PIPING

All gas connections must be made with pipe joint compound resistant to the action of liquefied petroleum and natural gas. All piping must comply with local codes and ordinances.

### 3.3 INSTALL PIPING

- The gas line should be sufficient to handle the total installed capacity. Verify pipe size with your gas supplier.
- Use approved piping as per code free from burrs.
- Install a manual main gas shutoff valve at the appliance gas inlet, outside of the appliance and before the gas valve.
- Run pipe to the Appliance gas inlet.
- Install a sediment trap in the supply line to the Appliance gas inlet.
- Apply a moderate amount of good quality pipe compound.
- For LP gas, consult your LP gas supplier for expert installation.

The appliance and its individual gas shut-off valve must be disconnected from the supply piping when pressure testing the gas supply piping at pressures above 1/2 PSI

**Table 9: Gas Pressures at Inlet to Appliance**

	PROPANE	NATURAL GAS
<b>Minimum (inches W.C.)</b>	11	3
<b>Maximum (inches W.C.)</b>	11	14

The gas supply line must be of adequate size to prevent undue pressure drop and must never be smaller than the size of the connection on the appliance. Sizing based on Table 4 or 6 is recommended, depending on model.

Before operating the appliance, the complete gas train and all connections must be tested using soap solution.

Verify that the appliance is supplied with the type of gas specified on the rating plate. Heating values of local natural gas are to be between 950 and 1010 Btu/ft<sup>3</sup>. Consult factory if heating values are outside this range or if a gas with a mixture of constituents is being used.

### 3.4 CHECKING GAS SUPPLY PRESSURE

- Turn main power switch to "OFF" position.
- Shut off gas supply at the manual gas cock in the gas piping to the appliance. If fuel supply is LP gas, shut off gas supply at the tank.
- **DM80 – 399:** Loosen the slotted screw from the gas pressure test port on the gas valve. Connect manometer or magnahelic gauge to test port. Range of scale should be 0 to 14 inch W.C. or greater to check inlet pressure.
- **DM500 – 800:** Remove the 1/8" hex plug from the gas pressure test port located upstream of gas valve. Install a pressure tapping suitable to connect to a manometer or magnahelic gauge. Range of scale should be 0 to 14 inch W.C. or greater to check inlet pressure.
- Turn on gas supply at field installed manual gas cock; turn on LP gas at tank if required.
- Turn power switch to "ON" position.
- Initialize call for heat.
- Observe the gas supply pressure as the burner fires at 100% of rated input. Supply pressure is to remain stable.
- Ensure inlet pressure is within specified range as specified in Table 9.
- If gas pressure is out of range, contact the gas utility, gas supplier, qualified installer or service agency to determine necessary steps to provide proper gas pressure to the control.
- If gas supply pressure is within normal range, proceed to remove gas manometer and tighten slotted screw on gas valve (DM80 – 399) or replace pressure tap fittings in the gas piping to the appliance (DM500 – 800). Turn power switch to "OFF" position.
- Turn on gas supply at the manual valve; turn on LP gas at tank if required.
- Turn power switch to "ON" position.
- Adjust set point to the desired water temperature.
- Check appliance performance by cycling the system while you observe burner response. The burner should ignite promptly. Flame profile should be stable, see section 11.2, Visually Check Main Burner Flames. Turn system off and allow burner to cool, then cycle burner again to ensure proper ignition and flame characteristics.

### IMPORTANT

Upon completion of initial installation or following any repair work on the gas system, leak test all gas connections with a soap solution while the main burner is firing. Immediately repair any leak found in the gas train or related components. **DO NOT** operate an appliance with a leak in the gas train, valves or related gas piping.

### 3.5 HIGH and LOW GAS PRESSURE SWITCHES (Optional)


High and low gas pressure switches are available as an option and are wired in series with the normally closed blocked flue switch. The high gas pressure switch is used to monitor the differential gas pressure between the outlet of the control valve and the fan inlet. If differential gas pressure exceeds the maximum setting of the pressure switch, the appliance will shut down and a Blocked Flue Error will be indicated on the display panel. The low gas pressure switch is to monitor the minimum incoming gas supply pressure supplied to the gas train. If gas pressure falls below the minimum setting of the pressure switch, the appliance will shut down and a Blocked Flue error will be displayed.

### 3.6 AIR/GAS RATIO VALVE


The main gas valve supplying gas to the burner on this appliance utilizes a servo pressure regulator providing a slow opening, fast closing safety shut off and air/gas ratio control for the gas combustion process. The valve is a 1:1 negative pressure gas valve. The valve performs the functions of a pressure regulator, safety shutoff, and air/gas ratio control. Full closing of the valve seat occurs in less than 0.8 seconds when the valve is de-energized. Operation of the gas valve in combination with the combustion air fan allows the burner input rate to vary from 20% to 100% based on temperature demand. The inlet gas supply pressure must be maintained within the specified minimum and maximum pressures as indicated in Table 9.

The air/gas ratio is preset at the factory and adjustment is not usually required if gas supply pressure is maintained within the specified range. There are no serviceable parts on the air/gas ratio valve control.


**Figure 14: DynaMax 80 – 250, 260 1:1 Air/Gas Ratio Control Valve**



**Figure 15: DynaMax 299 – 399 1:1 Air/Gas Ratio Control Valve**




**Figure 16: DynaMax 500 – 800 1:1 Air/Gas Ratio Control Valve**



### 3.7 BURNER

**Figure 17: DynaMax Burner**



This appliance uses a single cylindrical burner installed horizontally into the cavity located in the center of the heat exchanger. A unique burner is used for each one of the DynaMax models.

**Burners may NOT** be interchanged between different Btu/hr input models. The burner consists of a round mounting flange welded to a ported stainless steel mixing tube. This stainless steel tube is covered with a close fitting, knitted stainless steel metal fiber alloy material that forms the burner outer surface. The burner is setup to operate in blue mode and infrared operating condition should be avoided. Infrared operation will occur only if air to gas adjustments is incorrect. If infrared operation is noted the cause must be corrected.

The burner should be removed for inspection and cleaning on an annual basis. An appliance installed in a dust or dirt contaminated environment will require inspection and cleaning on a more frequent schedule. The fan assisted combustion process may force airborne dust and dirt contaminants, contained in the combustion air, into the burner. With sustained operation, non-combustible contaminants may reduce burner surface area, reduce burner input or cause non-warrantable damage to the burner.

Airborne contaminants such as dust, dirt, concrete dust or dry wall dust can be drawn into the burner with the combustion air and block the burner surface area. **DO NOT** operate this appliance during construction.

The spark igniter and flame sensor are removable from the combustion chamber mounting door without removing the burner assembly.

**Never use an open flame (match, lighter, etc.) to check gas connections.**



## PART 4 WATER CONNECTION

- Check all applicable local heating, plumbing and building safety codes before proceeding.
- If the appliance is installed above radiation level it must be provided with a low water cut-off device at the time of appliance installation (available from Camus). Some local codes require the installation of a low water cut-off on all systems.
- Before connecting DynaMax to piping, flush system thoroughly and refill with clean water and add chemical treatment to bring pH to 8.0 to 8.5 range.
- A pressure relief valve is supplied with each DynaMax. The relief valve must be mounted in a vertical position and piped to the floor in a manner acceptable to the enforcing authority.
- Be sure to provide unions and gate valves at inlet and outlet to the appliance so that it can be easily isolated for service.
- On combination heaters a flow setter valve at the appliance outlet facilitates setting of the desired outlet temperature at high fire. Refer to Section 12.9 Domestic Hot Water with Plate Heat Exchanger for more details
- This appliance is a low mass stainless steel tube design which provides for instant heat transfer. All appliances are supplied with an internal suitable specific pump mounted in place. When replacing the pump, replace with one of equal or better-performance.
- An air vent is supplied on the heat exchanger header to eliminate trapped air. Install venting devices at high points in the system as well to eliminate trapped air in the piping.
- Use suitable pipe hangers or floor stands to support the weight of all water and gas piping.
- The DynaMax must be installed so that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)
- Strainers are recommended to be installed into the system to prevent foreign objects from entering the heat exchanger.


### 4.1 FREEZE PROTECTION OUTDOOR INSTALLATION

- Appliance installations are not recommended outdoors or in areas where danger of freezing exists unless precautions are taken. Maintaining a mixture of 70% water and 30% propylene glycol is the preferred method of freeze protection in hydronic systems. **DO NOT** exceed a mixture of 50/50. This mixture will protect the appliance to approximately -35°F (-37°C).
- For outdoor installations a snow screen should be installed to prevent snow and ice accumulation around the appliance. Regular inspections should be made to ensure that air inlet and vent are free of snow and ice. Always consider the use of a shelter such as a garden shed in lieu of direct exposure of the appliance to the elements. The additional protection afforded by the shelter will help to minimize nuisance problems with electrical connections and will allow easier servicing of the appliance under severe weather conditions.

### 4.2 WARNING REGARDING CHILLED WATER SYSTEMS

When an appliance is connected to an air conditioning system where the same water is used for heating and cooling, the chiller must be piped in parallel with the appliance. Appropriate flow control valves; manual or motorized must be provided to prevent the chilled water from entering the appliance.

**Figure 18: Chilled Water System**



### 4.3 INLET AND OUTLET CONNECTIONS

- All water connections must meet American National Standard Pipe Threads (NPT).
- For ease of service, install unions on inlet and outlet of the appliance. The connection to the appliance marked "Inlet" on the header should be used for return from the system. The connection on the header marked "Outlet" is to be connected to the supply side of the system.

### 4.4 MINIMUM PIPE SIZE REQUIREMENTS

Minimum water pipe connections are as follows for DynaMax single unit installations. The equivalent number of straight feet of pipe for each valve and fitting in the connecting piping must be considered to properly arrive at the total equivalent feet of straight pipe in the field installed piping to the appliance. Consult factory if longer piping distances are required for a specific application. It is recommended to use copper piping for all system piping to reduce the possibility of the formation of deposits, which may result in heat exchanger starvation.

System pipe size must be in accordance with Table 11, and between supply and return lines, must not exceed 50 feet of equivalent length. Connection sizes at the heater are given in Tables 4 & 6. Any reduction in recommended pipe size may decrease flow resulting in high temperature rise across the heat exchanger, boiler noise, flashing to steam and non-warrantable heat exchanger damage.

**Table 10: Minimal System Pipe Size**

Input [BTU/hr]	Water Size, NPT* [in.]
80,000	1
100,000	1
150,000	1
199,000	1 1/4
250,000	1 1/4
299,000	1 1/2
399,000	2
500,000	2
600,000	2
700,000	2
800,000	2

\* Equivalent length must not exceed 50 equivalent feet

#### 4.5 HEAT EXCHANGER

This appliance uses precision formed stainless steel tubing to maximize the heat transfer process and achieve 97% steady-state efficiency. This heat exchanger is designed to withstand 160 PSIG working pressure.

A factory installed circulating pump ensures proper water flow during burner operation and creates enough velocity inside the stainless steel tubes and headers that prevents scaling.

#### 4.6 LOW WATER TEMPERATURE SYSTEMS

In applications where the heating system requires supply water temperatures below 110°F, connections may be made directly to the DynaMax. At incoming temperatures of 80°F or lower the DynaMax achieves maximum efficiency. Inlet temperatures must not drop below 40°F to prevent freezing.

#### 4.7 PIPING ARRANGEMENTS

The DynaMax boiler when configured as a hydronic heating boiler allows for 4 modes of operation and 3 modes of operation as a hot water heater. For more details on each of the operating modes refer to section 6.3 Central Heating Modes and 6.4 Domestic Hot Water Modes.

##### 4.7.1 Field Supplied Components

###### 1) Boiler system piping

Boiler system piping MUST be sized according to Table 11. Reducing the pipe size can restrict the flow rate through the boiler, causing boiler damage and will void the manufacturer's warranty.

###### 2) Isolation Valves

Use only full port ball valves. Failure to supply full port ball valves may result in reduced flow rate through the boiler, causing boiler damage and will void the manufacturer's warranty.

###### 3) Anti-Scald Mixing Valve

An anti-scaled mixing valve is recommended when DHW storage is above 120°F.

###### 4) Unions

Recommended for ease of serviceability.

###### 5) System Temperature Sensor (Cascade ONLY)

A system temperature sensor is to be installed in the main header at a point to detect controlled temperature and where it will not lead to short-cycling of the boiler.

An instantaneous water heater is designed to deliver hot water without the use of a storage tank. It is suitable for applications with variable load such as restaurants, condominiums, apartments and motels and typically used in

conjunction with tempering valves to achieve temperature control.


**Table 11: Flow and Pressure Drop at a Given Temperature Rise (Hydronic Heating)**

Input, Btu/Hr	30 °F (16.7 °C) Temp Rise		35 °F (19.4 °C) Temp Rise	
	USGPM (min. flow)	ΔP Ft.	USGPM. (min. flow)	ΔP Ft.
80,000	5.0	8.2	4.3	6.2
100,000	6.3	12.3	5.4	9.4
150,000	9.5	10.4	8.1	7.8
199,000	12.6	7.2	10.8	5.8
250,000	15.8	11.5	13.5	8.7
299,000	18.9	9.3	16.2	7.0
399,000	25.2	8.4	21.6	6.3
500,000	31.5	9.2	27.0	6.9
600,000	38.8	17.5	32.0	11.8
700,000	45.3	18.2	40.0	14.4
800,000	51.8	23.5	43.0	16.0

**Table 13: Flow and Pressure Drop at a Given Temperature Rise (DHW)**

Input, Btu/Hr	20 °F (11.1 °C) Temp Rise	
	USGPM (min. flow)	ΔP Ft.
80,000	7.5	11.5
100,000	9.4	26.9
150,000	14.0	27.8
199,000	19.2	25.9
250,000	23.5	28.3
299,000	28.8	25.8
399,000	38.4	23.9
500,000	48.6	29.4
600,000	57.6	34.2
700,000	70.4	40.0
800,000	77.6	43.2

## DynaMax Floor Mount Piping Diagrams



### 4.8 FLOW PROVING DEVICE (wall mount models and combination models only)

Figure 19: Flow Proving Device



The flow proving device is designed to detect when flow is present. This is done by detecting the amount of current (amperes) that exists in the neutral wire from the pump. When the current becomes too low a flow switch error is displayed indicating a lack of water inside the boiler. The flow proving device is provided on all DynaMax wall mount models (DM 80 – 250) and combination floor model units (213 – 803). This switch is factory wired.

Table 12: Flow Proving Device Indicator LED's

Wall Mount	
LED Illuminated	Symptom
Front	Normal operation
Rear	Current under trip point
Floor Mount	
LED Illuminated	Symptom
Left	Normal operation
Right	Current under trip point

When testing the operation of the flow proving device always ensure that 115Vac is being supplied to the pump.



#### 4.9 WATER FLOW SWITCH (Floor mount hydronic and DHW models only)

A water flow switch is shipped loose and is to be installed in the outlet piping on all floor model heating boilers (DM 211-801) and hot water supply heaters (DM 212 – 802). The flow switch is to be installed in a horizontal run of pipe in order to provide effective contact. The flow switch is to be wired into the DynaMax terminal board labelled 'Flow/LWCO'.

#### 4.10 LOW WATER CUTOFF (If Equipped)

If this boiler is installed above radiation level, a low water cut-off device must be installed at the time of boiler installation. Some local codes require the installation of a low water cut-off on all systems. Electronic low water cut-offs are available as a factory supplied option on all models. Low water cut-offs should be tested every six months. The normally open switch contact of the low water cutoff is to be wired in series with the flow switch. This can be wired into the DynaMax terminal labelled 'Flow/LWCO'.

#### CAUTION

Remove jumper when connecting to 24 VAC circuit.

Figure 20: Low Water Cut Off Electrical

#### Connections (Watts)





Figure 21: Low Water Cut Off Electrical Connections (ITT)



#### 4.11 RELIEF VALVE

This appliance is supplied with a relief valve sized in accordance with ASME Boiler and Pressure Vessel Code, Section IV ("Heating Boilers"). This component is shipped loose. No valve is to be placed between the relief valve, and the appliance. To prevent water damage, the discharge from the relief valve shall be piped to a suitable floor drain for disposal when relief occurs. No reducing couplings or other restrictions shall be installed in the discharge line. The discharge line shall allow complete drainage of the valve and line. Relief valves should be manually operated at least once a year.

#### CAUTION

Avoid contact with hot discharge water

#### 4.12 DHW TUNING VALVE (combination models only)

A DHW tuning valve is provided with all DynaMax combination models. In cases where flow control is not possible by the end user the DHW tuning valve is designed to act as a maximum flow controller. The tuning valve is designed to provide the correct amount of hot water for each particular DynaMax model and application. Refer to section 12.9 Domestic Hot Water with Plate Heat Exchanger for further details.

## PART 5 ELECTRICAL & CONTROLS

### **⚠ DANGER**

IT IS EXTREMELY IMPORTANT THAT THIS UNIT BE PROPERLY GROUNDED!

### 5.1 ELECTRICAL CONECTIONS

DynaMax Maximum Amp Draw			
Model	Voltage Requirement	Full Load Amps [Amperes]	Maximum Over Current Protection [Amperes]
81, 82, 83	120VAC, 60Hz, Single Phase	4	15
101, 102, 103		4	15
151, 152, 153		4	15
201, 202, 203		4	15
211, 212, 213		4	15
251, 252, 253		4	15
261, 262, 263		4	15
291, 292, 293		4	15
391, 392, 393		4	15
501, 502, 503		4	15
601, 603		4	15
701, 703		6	15
801, 803		6	15
602, 702, 802	230VAC, 60Hz, Single Phase	8	15

The appliance, when installed, must be electrically grounded in accordance with the requirements of the authority having jurisdiction or in the absence of such requirements, with the latest edition of the National Electrical Code ANSI/NFPA No. 70. When the unit is installed in Canada, it must conform to the Canadian Electrical Code, C22.1, Part 1 and/or local Electrical Codes.

- All wiring between the appliance and field installed devices shall be made with wire having minimum 220°F (105°C) rating.
- Line voltage wire exterior to the appliance must be enclosed in approved conduit or approved metal clad cable.
- The pump must run continuously when appliance is being fired.
- To avoid serious damage, DO NOT ENERGIZE the appliance until the system is full of water. Ensure that all air is removed from the pump housing and piping before beginning initial operation. Serious damage may result if the appliance is operated without proper flow.
- Provide the appliance with proper overload protection.

### 5.2 HIGH LIMIT

A manual reset fail-safe high limit aqua-stat control is inside the appliance and the control bulb is installed in a dry well in the heat exchanger outlet. The setting of this control limits maximum discharge water temperature to 210°F (CPVC, AL29-4C, Stainless) and 185°F (PVC). The temperature of

the outlet water in the heat exchanger must drop a minimum of 30°F (16.7°C) below the setting of the high limit control before the reset function can be activated.

### 5.3 DYNAMAX CONTROLLER

This appliance uses a direct spark ignition control system. The operation of the DynaMax Controller for the direct spark igniter proves the presence of main flame using a flame sensor proof current (1.25µA). A status of Ignition Error will be displayed on the main panel if the boiler fails to light after three (3) ignition attempts.

Figure 22: DynaMax Controller




Table 13: Connector Description

Connector	Connector Description
J2	Provides 120V to the DynaMax Controller
J6	3-Way Diverter Valve
J7	On-Board Pump
J13	High-Limit, Gas Valve, Flame Sensor
J9	Fan Power, Fan Modulation
J5	Various Sensors
J16	Safety Switches
J12	Spark Return Signal
T2	Spark Igniter
F1	3.15A Fuse

#### 5.3.1 SERVICE PARTS

The DynaMax Controller is not repairable. Any modification or repairs will invalidate the warranty and may create hazardous conditions that result in property damage, personal injury, fire, explosion and/or toxic gases. A faulty direct spark igniter **MUST** be replaced with a new factory part. **DO NOT** use general purpose field replacement parts. Each appliance has one DynaMax Controller, one direct spark igniter and one flame sensor. A list of recommended spare parts is available.

#### 5.3.2 IGNITION MODULE LOCKOUT FUNCTIONS

The DynaMax Controller may lockout in either a manual reset condition requiring pushing the reset button to recycle the control for a CSD1 requirement or an automatic reset condition. Pushing the reset button on the control panel is the only way to reset the DynaMax Controller that is in a hard lockout condition. The reset button is active after the post purge cycle when there is a lockout condition as indicated by the LCD display. Turning the main power "OFF" and then "ON" or cycling the thermostat will not reset a hard lockout condition. Wait five seconds after turning on the main

power before pushing the RESET button when the DynaMax Controller is in a manual reset condition. Wait for the status LCD display to refresh indicating that the DynaMax Controller is ready before releasing the reset button. The DynaMax Controller will go into an automatic reset condition, if the fault is not corrected, the boiler will stay in the automatic reset state. Once the fault is corrected, the boiler will automatically return to normal operating state.

## 5.4 ERROR TABLE

### 5.4.1 Manual Reset Codes

Table 14: Manual Reset Codes

Error	Int #	Description
IGNIT_ERROR	1	Three unsuccessful ignition attempts in a row
GV_RELAY_ERROR	5	Problems with gas valve relay = internal hardware error (pump not running)
SAFETY_RELAY_ERROR	6	Problems with safety relay = internal hardware error (pump not running)
FAN_ERROR	8	Fan deviation more than 300 rpm longer than 1 minute (when fan speed > 4200 rpm this error is ignored)
RAM_ERROR	9	Internal software error
WRONG_EEPROM_SIGNATURE	10	Contents of e2prom is not up-to-date
E2PROM_ERROR	12	No communication with E2prom
STATE_ERROR	13	Internal software error
ROM_ERROR	14	Internal software error
15MS_XRL_ERROR	16	Internal software error
T_MAX_LOCK_ERROR	18	Overheat stat is open
STACK_ERROR	19	Internal software error
FLAME_OUT_TOO_LATE_ERROR	20	Flame still present 10 sec. after closing the gas valve
FLAME_ERROR_1	21	Flame detected just before gas valve opened
20MS_XRL_ERROR	22	Internal software error
41MS_ERROR	23	Internal software error
TOO_MANY_FLAME_FAILURES	24	Three times flame lost during one demand
FLAG_BYTE_INTEGRITY_ERROR	27	Internal software error
AD_HI_CPL_ERROR	28	Internal software error
AD_LO_CPL_ERROR	29	Internal software error
REGISTER_ERROR	30	Internal software error

To eliminate the hard lockout error,

- 1) Wait until the boiler has completed its post-purge cycle, if applicable
- 2) Press and hold the 'RESET' button until the display reverts back to showing the supply temperature
- 3) Release the RESET button, the hard lockout has been cleared

### 5.4.2 Automatic Reset Codes

Table 15: Automatic Reset Codes

Error	Int #	Description
E2PROM_READ_ERROR	0	Problems reading from or writing to e2prom
REFHI_TOO_LO_ERROR	31	Internal hardware error
REFHI_TOO_HI_ERROR	32	Internal hardware error
REFLO_TOO_LO_ERROR	33	Internal hardware error
REFLO_TOO_HI_ERROR	34	Internal hardware error
STACK_TEMP_ERROR	35	Stack sensor > set point + diff. See chapter
FLAME_ERROR_2	36	False flame detected
LOW_WATER_CUTOFF_ERROR	37	Water pressure is too low
INLET_TEMP_ERROR	40	Inlet temperature is above 90 degrees
WD_50HZ_ERROR	43	No earth connected or internal hardware error
PHASE_ERROR	44	Phase and neutral of mains supply are reversed
NET_FREQ_ERROR	45	Mains frequency differs more than 2% from 60Hz
FAULTY_EARTH_ERROR	46	Earth connection is not ok
WD_COMMUNICATION_ERROR	47	Internal hardware error
APPLIANCE_SELECTION_ERROR	48	Appliance selection code and resistor do not match. This is only checked at startup.
T_SUPPLY_OPEN	51	Supply sensor not connected
T_INLET_OPEN	52	Inlet sensor not connected
T_DHW_OPEN	55	DHW sensor not connected
T_SYSTEM_OPEN	56	System sensor not connected
T_FLUE_OPEN	57	Flue sensor not connected
T_SUPPLY_SHORTED	59	Supply sensor shorted
T_INLET_SHORTED	60	Inlet sensor shorted
T_STACK_SHORTED	65	Stack sensor shorted
T_DHW_SHORTED	63	DHW sensor shorted
T_SYSTEM_SHORTED	64	System sensor shorted
BLOCKED_FLUE_ERROR	66	Blocked flue switch tripped
FLOW SW. NOT CLSD.	68	Flow switch not closed

## PART 6 CONTROL PANEL

### 6.1 DYNAMAX CONTROLLER

The appliance is provided with an operator interface panel at the front. On a DynaMax Wall Hung boiler the DynaMax Controller can be accessed by removing the upper stainless steel jacket and the lower black sheetmetal jacket which are each held on by two (2) screws. On a DynaMax Floor Mount boiler the DynaMax Controller can be accessed by carefully lifting off the black-coloured Top cover which is held on by four (4) snap lock fasteners.

The Boiler Temperature Controller (BTC) for this appliance is a proprietary Camus DynaMax Controller. It initiates the local call for heat and sets the target supply (appliance outlet) water temperature. This controller accommodates heating and domestic water control with multiple modes of operation which provide set point as well as reset control. It provides the following:

- Readings of inlet and outlet water temperatures, stack temperatures, domestic hot water temperature, flame current, status of heater operation, etc.
- Operation as an auto reset limit.
- Operation as a control for discharge water temperature.
- Optional tank mounted sensor used in conjunction with outlet sensor for domestic hot water.
- Adjustable target temperature
- Display of run hours for maintenance purposes. Counter displays run time up to 10,000 hours. Pressing the **RESET** button will reset the counter.
- Molex, Stocko and AMP connectors for ease of service.
- Error message display.

### 6.2 SETTING THE DYNAMAX CONTROLLER

Press the **MENU** button and then select the desired setting using the **PREVIOUS** and **NEXT** Buttons. When the desired setting is satisfied press the **ENTER** key and this will save the last setting. In normal operating mode the inlet temperature, outlet temperature, and ON hours can be viewed by pressing the **PREVIOUS** and **NEXT** key. After checking the settings allow the control to return to normal operation on its own.

### 6.3 CENTRAL HEATING MODES

#### Mode 0: Central Heating without Outdoor Reset

In this mode no outdoor sensor is needed. If the room thermostat closes, the pump is switched on.

##### Burner On:

Supply Temp < CH Setpoint – CH Hysteresis

##### Burner Modulation:

CH Setpoint

##### Burner Off:

Supply Temp > CH Setpoint + CH Hysteresis

If the room thermostat opens the burner is switched off and the pump runs on for post pump (default: 30 sec).

The anti-freeze monitor on each boiler will monitor the inlet water temperature and when it drops below 50°F (10°C) it will bring on the pump to prevent freezing of the heat exchanger.

#### Mode 1: Central Heating with Outdoor Reset and Thermostat Control

This mode will only function when an outdoor sensor is connected. The set point is calculated depending on the outdoor temperature and the burner will react on the room thermostat. The central heating set point is calculated as follows:

$$\text{ch\_setpoint} = t\_day\_ref + [(68 - T_{\text{outdoor}}) * \text{Slope}]$$

To assist with programming a suitable outdoor reset curve it would be advised to consult a qualified service technician using **DynaMax Outdoor Reset Calculator.xls**

$t\_day\_ref$  is the reference temperature for central heating set point when  $T_{\text{outdoor}}$  is 68°F (20°C).  $T\_day\_ref$  is a user settable parameter.

The Slope can be set via the menu between 0.1 to 5.0 with steps of 0.1.

The calculated central heating set point is limited between 41°F (5°C) and 194°F (90°C).

The outdoor temperature used for the central heating set point calculation is measured once a minute and averaged with the previous measurement. This is done to avoid drastic changes to the boiler when outdoor temperature fluctuates rapidly.

##### Burner On:

Supply Temp < CH Setpoint – CH Hysteresis

##### Burner Modulation:


CH Setpoint

##### Burner Off:

Supply Temp > CH Setpoint + CH Hysteresis

The anti-freeze monitor on each boiler will monitor the inlet water temperature and when it drops below 50°F (10°C) it will bring on the pump to prevent freezing of the heat exchanger.

Figure 22: Outdoor Reset Curve



### Mode 2: Central Heating with Outdoor Reset

This mode will only function when an outdoor sensor is connected. The set point is calculated depending on the outdoor temperature. The central heating set point is calculated as follows:

$$\text{ch\_setpoint} = \text{t\_day\_ref} + [(68 - \text{T\_outdoor}) * \text{Slope}]$$

t\_day\_ref is the reference temperature for central heating set point when T\_outdoor is 68°F (20°C). T\_day\_ref is a user settable parameter.

The Slope can be set via the menu between 0.1 to 5.0 with steps of 0.1.

The calculated central heating set point is limited between 41°F (5°C) and 194°F (90°C).

#### **Burner On:**

Supply Temp < CH Setpoint – CH Hysteresis

#### **Burner Modulation:**

CH Setpoint

#### **Burner Off:**

Supply Temp > CH Setpoint + CH Hysteresis

Overnight an input signal from a room thermostat (RT) can lower the ch\_setpoint. When the RT input closes the ch\_setpoint will also be lowered by t\_night\_reduction.

The anti-freeze monitor on each boiler will monitor the inlet water temperature and when it drops below 50°F (10°C) it will bring on the pump to prevent freezing of the heat exchanger.

### Mode 3: Central Heating with Constant Temperature Loop

No outdoor sensor is needed. The supply temperature is kept constantly at the set point temperature. The burner is controlled in a similar way as Mode 0. When the room thermostat contact closes the ch\_setpoint will be decreased with t\_night\_reduction. The pump is always on in this condition.

#### **Burner On:**

Supply Temp < CH Setpoint – CH Hysteresis

#### **Burner Modulation:**

CH Setpoint

#### **Burner Off:**

Supply Temp > CH Setpoint + CH Hysteresis

## **6.4 DOMESTIC HOT WATER MODES**

### Mode 0: Disables Domestic Hot Water

No domestic hot water is available; therefore the DHW sensor is not supplied.

### Mode 1: Direct/Indirect DHW Storage Tank with 10kΩ Temperature Sensor

The DHW temperature in the tank is measured with a storage tank sensor and set with parameter DHW\_setpoint.

#### **DHW Demand:**

DHW Temp < DHW Setpoint – DHW Store hyst down

#### **Burner Start:**

DHW Temp < DHW Setpoint + DHW store supply extra – DHW supp hyst down

#### **Burner Modulation:**

Supply Temp = DHW Setpoint + DHW store supply extra

#### **Burner Stop:**

DHW Temp > DHW Setpoint + DHW store supply extra + DHW supp hyst up

The anti-freeze monitor on each boiler will monitor the inlet water temperature and when it drops below 50°F (10°C) it will bring on the pump to prevent freezing of the heat exchanger.

### Mode 2: Direct/Indirect DHW Storage Tank with Aquastat

When the aquastat closes the control detects a demand for the storage tank and starts the pump. Operation of Mode 2 is identical to the operation of Mode 1, but an aquastat replaces the use of a sensor in the storage tank.

#### **Burner Start:**

Supply Temp < DHW Setpoint – DHW supp hyst down

#### **Burner Modulation:**

DHW Setpoint

#### **Burner Stop:**

Supply Temp > DHW Setpoint + DHW supp hyst up

### Mode 4: Combination Boiler using Plate Heat Exchanger and 10kΩ DHW Temperature Sensor

In this configuration the boiler can be used for space heating and indirect domestic hot water. Camus supplies an on-board brazed plate heat exchanger, a pump and a 3-way diverter valve.

When a heat demand is detected the pump will run and the 3-way diverter valve switches over to the hydronic heating loop. The pump continues to run until the 'post pump CH period' is complete after cycling through a heat demand cycle. When there is no heat demand the pump will turn off individually controlled zone pumps will draw hot water from the manifold and return from the zone to the manifold.

The temperature of the water leaving the plate heat exchanger is constantly monitored and when it drops below 'dhw\_setpoint – dhw\_hyst\_down', the on-board pump activates to satisfy a demand for DHW and the 3-way diverter valve switches over to DHW demand. If a central heating demand is present when a DHW demand occurs, the heating demand will be interrupted resulting in domestic hot water priority. The 3-way valve shall switch over from hydronic heating to DHW demand and the boiler will continue to function in this state until DHW demand ends. If hydronic demand is still present after DHW demand ends the 3-way valve switches over to hydronic heating. This results in zero lag, as the burner does not restart when switching between hydronic heating and DHW demand.

Due to the use of a plate heat exchanger a Pre-Heat function is implemented in the algorithm. This ensures the plate is always warm and prevents the user from receiving an initial blast of cold water when they first turn on the tap. The Pre-Heat function is enabled after 2 minutes of burner shut off. If the DHW sensor detects that the temperature is below 'Pre Heat set point – pre heat hyst down' the boiler will initiate the ignition sequence and the burner will fire at minimum fire until the DHW sensor temperature is equal to the Pre Heat Setpoint. The Pre Heat function will only activate when a DHW demand is non-existent.

The anti-freeze monitor on each boiler will monitor the inlet water temperature and when it drops below 50°F (10°C) the pump will be activated to prevent the heat exchanger from freezing.




## PART 7 COMPONENTS

### 7.1 DIRECT SPARK IGNITER

The direct spark igniter is inserted directly through the combustion chamber front door and held in place by two torx-20 screws. Care must be taken when removing and/or installing the igniter. Always remove the igniter prior to removing the fan assembly for inspection of the burner and heat exchanger.

**Figure 23: Direct Spark Igniter**




During a trial for ignition sequence a properly operating igniter will generate a continuous spark with a 9/64" (3.6mm) spark gap. It is recommended to clean the direct spark igniter using steel wool as required. **DO NOT** use sandpaper or grit-cloth since this will contaminate the metal surface.

### 7.2 FLAME SENSOR

The flame sensor is inserted directly through the combustion chamber front door and is screwed into the combustion chamber front door by torx-20 screws. Care must be taken, when installing the flame sensor, to align it perpendicular to the fan flange and parallel to the burner tube and not to over tighten.

**Figure 24: Flame Sensor**




The ignition module relies on the flame sensor to provide a flame rectification signal. Oxide deposits, improper placement or damaged ceramic insulator will result in insufficient signal leading to ignition module lock out. For proper operation minimum 1.25  $\mu$ A DC must be fed back to the module. Oxide deposit on the sensor rod must be removed with steel-wool. **DO NOT** use sand-paper or grit-cloth since this will contaminate the metal surface.

### 7.3 COMBUSTION AIR FAN

DynaMax uses a modulating air fan to provide combustible air/gas mix to the burner and push the products of combustion through the heat exchanger and venting system. The fan assembly consists of a sealed housing and fan wheel constructed from spark resistant cast aluminum. The fan is operated by a fully enclosed 120 VAC, Single-Phase EC/DC electric motor. The fan housing and motor assembly is fully sealed and **SHOULD NOT** be field serviced. The power draw of the motor is proportional to the modulated gas input rate of the appliance.

### 7.4 GAS VALVE

**Figure 25: Venturi and Gas Valve Arrangement**



The Gas Valve supplied with the DynaMax boiler is a combined valve/venturi assembly. A servo pressure regulator is incorporated into the gas valve to provide stable gas supply. Pressure taps are provided to check inlet and outlet gas pressures. An internal fine mesh screen is incorporated in the inlet of the gas valve to prevent debris from entering the combustion chamber. Gas valves are factory set at low and high fire and modulates to maintain combustion characteristics across the full operating range.

### 7.5 OUTER JACKET

The outer jacket assembly is constructed from mirror finish stainless steel. This ensures a long life for the jacket assembly, with full integrity

## PART 8 LABVISION SOFTWARE

### NOTE

LabVision software is available on request from the factory and is not shipped with the boiler/ water heater.  
LabVision is compatible with Windows XP (32-bit, 64-bit) / Windows 7 (32-bit, 64-bit) operating systems.


To operate LabVision software a Laptop and a USB A-to-B connection cable are needed, as shown.

**Figure 26: USB A-to-B Cable**




### 8.1 INSTALLING LABVISION DRIVER ON WINDOWS XP


- 1) Extract/Unzip D2XX driver file on to your computer (preferably your desktop)
- 2) Plug in the USB A-to-B cable to your laptop and your DynaMax. The following balloon will appear on your desktop.




- 3) Select "No, not this time", press **[Next]**




- 4) Select "Install from a specific location (Advanced)"



- 5) Press **[Browse]** and locate the D2XX file on your computer and press **[Next>]**



- 6) Press **[Continue Anyway]**



### 8.2 INSTALLING LABVISION DRIVER ON WINDOWS 7

- 1) Extract/Unzip D2XX driver file on to your computer (preferably your desktop)
- 2) Plug in the USB A-to-B cable to your laptop and your DynaMax. The following balloon will appear on your desktop.
- 3) Follow steps 3 through 6 in Section 8.1 Installing LabVision Driver on Windows XP.

### 8.3 STARTING UP LAB VISION

Locate the file named LabVision.exe, the appearance of the icon is shown:

**Figure 27: LabVision Icon**




When a connection between LabVision and the DynaMax boiler is established the blue status bar on the bottom-right will scroll from right-to-left and back again.

If a connection is not established between LabVision and the DynaMax boiler, a proper connection will need to be established before advancing to the next steps.

- Go to Options > Communication > Preferences
- A Preferences screen will pop up
- Under the Project Tab in the Protocol box select the Argus Link connection




**Figure 29: Selecting Argus Link Protocol**



- Click on the Communication Tab
- In the Communication Port pull down menu select the address of Argus Link USB port.
- Click [OK]
- Use the pull down menu to jump to the desired mode of operation.

**Figure 30 : Selecting Communication Port**



The three blue status bars located at the bottom-right of the screen will move left-to-right and back again. This confirms that a successful connection has been established between LabVision and the DynaMax boiler.

USB connector address is shown in the bottom-left.


**NOTE**

Do not make any other parameter or setting changes other than those stated in the manual as they will have a detrimental effect to the DynaMax.

## 8.4 ADJUSTING FAN SPEEDS

Use the pull down menu to access DynaMax settings:


**Figure 31: Pull Down Menu**



To adjust ignition fan speeds. Use the pull down menu or the function keys on the keyboard, select Settings. This will bring up the Settings screen.

Parameters shown in blue text can be adjusted. To change a blue coloured parameter, place the cursor on top of a parameter and double-click. This will bring up a window to enter the desired values of operation.

**Figure 32: Settings Screen**



- The Appliance name is listed under Appliance Type
- Fan speeds are listed which corresponds to the appliance address, listed below:

**Table 17: Appliance Type Designations**

Appliance Type	DynaMax Model	Appliance Type	DynaMax Model
0	80	7	299
1	100	8	399
2	150	9	500
3	200	10	600
4	210	11	700
5	250	12	800
6	260		

### NOTE

Only change the fan speed settings with the associated boiler, as only this will have an effect on boiler performance.

## 8.5 LABVISION CENTRAL HEATING

Use the pull down menu and select Central Heating to adjust parameters in Central Heating. Before any parameters can be adjusted the blue status bar must track left-to-right and back again. Refer to Section 8.1 to resolve connection issues.

Figure 33: Central Heating Screen




Figure 34: Central Heating Temperature Screen

<b>Temperatures</b>	
T_FLUE [°F] : 112,5	FLUE_OK_FLAG : 1
T_SYSTEM [°F] : 71,7	
T_SUPPLY [°F] : 125,3	STAY_BURNING_FLAG : 1
	START_BURNING_FLAG : 1
T_RETURN [°F] : 130,7	
T_DHW_OUT [°F] : 130,1	
T_OUTDOOR_MEAN [°F] : -8,5	

Real-time temperatures are updated on screen, this includes:

- Stack/Flue Temperature (T\_FLUE)
- System Temperature (T\_SYSTEM)
- Outlet/Supply Temperature (T\_SUPPLY)
- Inlet/Return Temperature (T\_RETURN)
- DHW Supply Temperature (T\_DHW\_OUT)
- Outside Temperature (T\_OUTDOOR\_MEAN)

The CH demand switches between on/off depending on whether or not there is a demand for central heating. The other parameters are designed for internal control purposes.

Figure 35: Central Heating Input Screen

### CH Inputs

RT\_input : Open  
CH\_REQUEST : on  
RT\_BUFFER : 11111111  
CH demand : off

Table 18: CH Input Screen Parameters

Parameter	Parameter Description
CH demand	Displays the state of the room thermostat. ON: thermostat closed OFF: thermostat open
CH_REQUEST	Displays the response of the boiler. ON: Start ignition sequence OFF: Standby

### 8.5.1 Central Heating Mode, Installer Level

Figure 36: Central Heating Mode Settings

<b>CH Settings</b>	
	CH_MODE : 0
	E2PROM_CH_SETPOINT [°F] : 160
	T_CH_SETPOINT_MIN [°F] : 41
	T_CH_SETPOINT_MAX [°F] : 185
	CH_SETPOINT [°F] : 160
	CH_HYSTERESE [°F] : 9
	ANTI_CYCLE_PERIOD [sec] : 20
	ANTI_CYCLE_TIMER : 0
	POST_PUMP_CH_PERIOD [sec] : 60
	PID_P_CH : 27
	PID_I_CH : 15
	PID_D_CH : 128

The following parameters can be adjusted:

Table 19: CH Mode = 0 Parameters

Parameter	Parameter Description
CH_Setpoint	<b>CH Mode = 0, 1, 2, 3</b> To provide a target set point for the heating system. (Default: 160°F)
CH_Hysteresis	<b>CH Mode = 0, 1, 2, 3</b> To provide a modulation rate above and below CH_setpoint. For example, if the value is 10°F and the set point is 160°F, the boiler will start the ignition sequence at 150°F and shut off at 170°F. (Default: 9°F)
Post_Pump_CH_Period	Time the on-board pump continues to circulate after the burner has shut off and completed its post-purge cycle. (Default: 60 sec)

To change a blue coloured parameter, place the cursor on top of a parameter and double-click. This will bring up a window to enter the desired values. Take note of the minimum and maximum values that can be entered, as the values entered **MUST** be within this range.

The Anti\_Cycle\_Period is designed to prevent the boiler from short-cycling. The preset time must be satisfied before the boiler will start up.

### 8.5.2 Central Heating Mode = 1, 2, 3 Installer Level

**Figure 37: Central Heating Mode = 1, 2, 3 Settings**

**Settings for weather compensation**

CH mode : Normal operation  
 CH setpoint [°F] : 160  
 t day ref [°F] : 86  
 Slope : 1,0  
 CH Setpoint Min [°F] : 41  
 CH Setpoint Max [°F] : 185  
 T Night Reduction [°F] : 18  
 Weather comp. setpoint [°F] : 68  
 Quick test weather flag : 0

Formula [Metric units] :  $CH\_setpoint = t\_day\_ref + ((20 - T\_outdoor) * Slope)$   
 Formula [Imperial units] :  $CH\_setpoint = t\_day\_ref + ((68 - T\_outdoor) * Slope)$

OTC CH setpoint [°F] : 162

The following parameters can be adjusted:

**Table 20: CH Mode = 1 Parameters**

Parameter	Parameter Description
t_day_ref	<b>CH Mode 1, 2</b> To determine the outdoor reset temperature. The control uses the following algorithm to adjust the CH_setpoint accordingly: $CH\_Setpoint = t\_day\_ref + [(68 - T\_Outdoor) * Slope]$ (Default: 86°F)
Slope	<b>CH Mode 1, 2</b> To determine the outdoor reset temperature. See t_day_ref to understand how Slope affects CH_Setpoint. (Default: 1.0)
T_night_reduction	<b>CH Mode 2</b> If setting an alternate temperature for night time usage is desired. This parameter is only engaged when the Room Stat contacts are closed. (Default: 18°F)
Weather_setpoint	<b>CH Mode 2</b> When the outdoor temperature is below the preset Weather_setpoint a CH demand is created. Therefore, the CH demand is not dependent on Room Temperature input. (Default: 68°F)

To change a blue coloured parameter, place the cursor over a parameter and double-click. This will bring up a window to enter the desired values of operation. Take note of the minimum and maximum values that can be entered, as the values entered MUST be within this range.

### 8.6 LABVISION DOMESTIC HOT WATER

Use the pull down menu and select DHW Mode 4 to adjust parameters. Before the parameters can be adjusted the blue status bar must track left-to-right and back again. Refer to Section 8.1 to resolve connection issues.

Real-time temperatures are tracked by LabVision and are displayed on the screen. The temperatures tracked are:

- Outlet/Supply Temperature (T\_SUPPLY)
- Inlet/Return Temperature (T\_RETURN)
- DHW Supply Temperature (T\_DHW\_OUT)

**Figure 38: DHW Temperature Screen**

**Temperatures**

SUPPLY\_TEMP [°F] : 125,4  
 T\_RETURN [°F] : 130,6  
 T\_DHW\_OUT [°F] : 130,1

The DHW section of the screen displays the request that the DynaMax boiler is responding to. The values for the 4 parameters: Storage cold, Tap flow, DHW request, and Pre heat vary from 0 (off) and 1 (on). This information is also listed under the General section as well.

**Figure 39: DHW Inputs**

**DHW inputs**

Storage cold : 0  
 Store warm hold : 0  
 DHW request : 0  
 Pre heat : 0

The Pre heat and Tap flow screens are designed to keep the DynaMax operating at its optimum setting, and therefore these parameters will be preset and cannot be changed.

#### 8.6.1 DHW Mode = 0, Installer Level

No parameter changes can be made in this mode as this mode is used for a DynaMax Heating boiler.

#### 8.6.2 DHW Mode 1, 2 Installer Level

**Figure 40: DHW Mode 1, 2 Settings**

**DHW settings**

DHW\_MODE : 4  
 Dhwh\_Setpoint [°F] : 120  
 Post pump DHW period [sec] : 60  
 DHW store hyst up [°F] : 4  
 DHW store hyst down [°F] : 4  
 DHW store supply extra [°F] : 20  
 DHW supp hyst up [°F] : 4  
 DHW supp hyst down [°F] : 4  
 DHW store hold warm [°F] : 4  
 PID\_P\_DHW : 10  
 PID\_I\_DHW : 25  
 PID\_D\_DHW : 0

The following parameters can be adjusted:

**Table 21: DHW Mode 1, 2 Parameters**

Parameter	Parameter Description
DHW_Setpoint	To provide a target set point for the storage tank. (Default: 120°F)
DHW store hyst up	To detect the start of a storage tank demand. (Default: 4°F)
DHW store hyst down	To detect the end of a storage tank demand (Default: 4°F)
DHW store supply extra	Additional increase in the set point temperature above Dhwh_Setpoint (Default: 20°F)
DHW supp hyst up	To provide a modulation rate above Dhwh_setpoint (Default: 4°F)
DHW supp hyst down	Supply temperature below Dhwh_Setpoint to start ignition sequence. (Default: 4°F)
DHW store hold warm	When the storage tank temperature drops below this value the boiler will fire at minimum fire. This functionality is only activated when the boiler is in Standby mode. (Default: 120°F)

#### DHW Mode 1

##### DHW Demand:

DHW Sensor < DHW Setpoint – DHW Store hyst down

##### Burner Start:

DHW Sensor < DHW Setpoint + DHW store supply extra – DHW supp hyst down  
Burner Modulation: DHW Setpoint + DHW store supply extra

##### Burner Stop:

DHW Sensor > DHW Setpoint + DHW store supply extra + DHW supp hyst up

#### DHW Mode 2

##### Burner Start:

Supply Temp < DHW Setpoint – DHW supp hyst down

##### Burner Modulation:

DHW Setpoint

##### Burner Stop:


Supply Temp > DHW Setpoint + DHW supp hyst up

To change a blue coloured parameter, place the cursor over a parameter and double-click. This will bring up a window to enter the desired values of operation. Take note of the minimum and maximum values that can be entered, as the values entered MUST be within this range

#### 8.6.3 DHW Mode 4, Installer Level

This mode can **ONLY** be accessed on a DynaMax Combination model using a plate type heat exchanger. Use the pull down menu and select DHW Mode 4 to adjust parameters. Before parameters can be adjusted the blue status bar must track left-to-right and back again. Refer to Section 8.1 to resolve connection issues.

**Figure 41: DHW Mode 4 Screen**



**Table 22: DHW Mode 4 Parameters**

Parameter	Parameter Description
DHW_Setpoint	To provide a target set point for DHW. (Default: 120°F)
DHW hysteresis up	To provide modulation rate above DHW set point. (Default: 9°F)
DHW hysteresis down	To provide modulation rate below DHW set point. (Default: 4°F)
Pre Heat Setpoint	When the plate heat exchanger outlet/supply temperature drops below this value the boiler will fire at minimum fire. This functionality is only activated when the boiler is in Standby mode. (Default: 110°F)
Pre Heat hyst_up	To provide modulation rate above Pre-heat set point for the plate heat exchanger during pre-heat. (Default: 0°F)
Pre Heat hyst_down	To detect the start of the pre-heat sequence below Pre Heat Setpoint. (Default: 9°F)

**Table 23: Status Readouts (Read Only)**

Parameter	Parameter Description
PRE HEAT	Keeps the plate heat exchanger warm. This is accomplished by firing the boiler at minimum fire. This process repeats itself with a 2 minute gap in between firing if the plate has not reached Pre Heat Setpoint.
TAP	When there is a domestic demand and the burner will fire until DHW_Setpoint is satisfied.

## DHW Priority

When both a CH demand and DHW demand exist simultaneously, DHW will always have priority. When DHW demand ends the boiler will check the Outlet Temperature sensor or System Sensor and Room Thermostat switch to determine if CH demand exists.

Flame rod current in  $\mu\text{A}$  can be observed. Fan speeds cannot be altered here, instead they are varied under the Settings screen. This is covered in Section 8.2 of this manual The Maximum Stack Setpoint Temperature and the Flue Diff. Temperature cannot be changed to preserve reliable and efficient performance.

**Figure 43: DHW Mode 4 General Screen**

**General**

STATE : STANDBY\_0  
STATUS : STANDBY  
ERROR\_NUMBER : 255  
-> No error

Flame rod : 0    Flame current : 0,0  $\mu\text{A}$

Blocked flue switch : Closed (Flue not blocked)  
Primary flow switch : Closed (Flow)

Target fan speed [rpm] : 0  
Actual fanspeed [rpm] : 0  
Min speed [rpm] : 1500  
Ignition speed [rpm] : 2986  
Max speed [rpm] : 6690  
Pre purge period [sec] : 6  
Post purge period [sec] : 30    <- Default setting  
Post purge period adjust [sec] : Default setting used    <- Adjusted setting

Pump : DHW

To change a blue coloured parameter, place the cursor over a parameter and double-click. This will bring up a window to enter the desired values of operation. Take note of the minimum and maximum values that can be entered, as the values entered MUST be within this range

**Figure 44: DHW Mode = 4 Settings**

**DHW settings**

DHW_MODE : 4	PID_P_DHW : 10
Pre_Heat_Setpoint_ECO [°F] : 113	PID_I_DHW : 25
Dhw_Setpoint [°F] : 120	PID_D_DHW : 0
DHW hystereses up [°F] : 9	
DHW hystereses down [°F] : 4	
Post pump DHW period [sec] : 60	

## 8.7 LABVISION CASCADE

When connected in a cascade setup the Master boiler can control up to 7 slave boilers (ie. a total of 8 boilers) from the control panel of the Master Boiler. All control operation can be performed on the Master boiler, which can then relay the relevant information to the slave boilers. Therefore a direct connection to the Master Boiler and LabVision is required for communication using LabVision.

When the master boiler detects a heat demand for CH this boiler will start and uses it own parameters for CH demand. If after cascade\_delay\_time the system temperature is still below the set point the next boiler will start.

When the master temperature ( $T_{\text{system}}$ ) plus cascade\_hyst is greater than the set point a boiler will be stopped. If after a period of cascade\_delay\_time this situation is still present the next boiler is switched off.

In a situation where there is an installation of more than 8 DynaMax boilers in the Cascade system, a Zone Master can be ordered with the system. This Zone Master functions in the same way as the DynaMax Controller controlling the Cascade function and can support up to 64 DynaMax boilers.

### Sequence of Operation:

When a boiler is set as MASTER (address =1), the controller of this boiler will drive the cascade. THE CH mode of the master boiler is applicable for the total cascade system.

- The outdoor temperature sensor connected to the MASTER will be the outdoor sensor for the cascade system
- The system temperature sensor connected to the MASTER will be the control sensor for the cascade supply temperature.
- The thermostat connected to the MASTER will be the CH heat demand input for the cascade system.

When demand for CH present the first boiler will start and uses its own parameters for CH demand. After a period of CC\_TIME the MASTER compared the system temperature with the cascade set point and will check if:

- 1) **An additional boiler is needed**  
 $T_{\text{system}} > \text{CH set point} - \text{cc\_hyst}$
- 2) **Number of boilers remain the same**  
 $T_{\text{system}} > \text{CH\_setpoint} - \text{cc\_hyst}$  **AND**  
 $T_{\text{system}} < \text{CH set point} + \text{cc\_hyst}$
- 3) **A boiler should stop.**  
 $T_{\text{system}} > \text{CH\_setpoint} + \text{cc\_hyst}$




## Staging Operation

The control supports a function to rotate the boilers on a timely basis. With parameter CC\_STAGE\_TIME the time can be set after which the start and stop sequence of the cascade boilers changes.

**Table 24: Staging Sequence**

cc_stage_time	Start/Stop sequence
1 x cc_stage_time	1-2-3-4-5..x
2 x cc_stage_time	2-3-4-5..x-1
3 x cc_stage_time	3-4-5..x-1-2
4 x cc_stage_time	4-5..x-1-2-3
5 x cc_stage_time	5..x-1-2-3-5

**Figure 45: Cascade Screen**



The following parameters can be adjusted:

**Table 25: Cascade Parameters**


Parameter	Parameter Description
CC_HYST	This parameter is entered to provide a modulation rate above and below the set point. This value must be smaller than the CH_Hysteresis. (Default: 5°F)
CC_TIME	This parameter is entered to implement a delay time between the startup of one boiler to the next. This timer starts when a flame signal is detected from the first boiler. (Default: 120 sec)
CC_STAGE_TIME	Period after which boiler start-up order changes (Default: 100 hrs)

Refer to section 12.14 Cascade Setup to install a Cascade system setup.

## 8.8 DATA LOGGING


LabVIEW software also comes equipped with data logging capability which has the ability to track return/supply, DHW temperatures, actual and target fan speed, state and status in a graph as the boiler is operating. This is a beneficial feature as it improves the ability to troubleshoot and diagnose issues in the field.

**Figure 46: Data Logging Screen**



To select the parameters that need to be viewed or recorded, a Parameter Selection Box on the bottom left-side of the screen contains all the parameters that LabVIEW can track. To view or record the parameter that is required, click the check box beside each parameter. When finished selecting the parameters required, click on Update and this will refresh the logging screen.

**Figure 47: Parameter Selection Box**



To adjust the viewing area, this can be done by adjusting the margins for the left y-axis, right y-axis and the timeframe with which to view.

**Figure 48: Adjust Viewing Area**




To record the data that is shown on screen, go to the Toolbar and click on Logging > Start Logging. A window will pop up on screen asking for a file name for the log file to be captured. DO NOT change the file type, as LabVIEW must record the log file as .Csv. As soon as file name is confirmed by clicking on 'Open', LabVIEW begins capturing the data immediately.

Also notice that the status bar has changed from blue to red. This demonstrates that LabVIEW is recording to the log file specified. The amount of data collected can be limited to a certain size inside LabVIEW. When a maximum memory limit is set, this results in over-writing previously written data in the same log. Therefore it captures the most recent amount of data. To prevent this from occurring this feature can be turned off by clicking on Options > Options > Logging tab and uncheck the parameter 'Limit Logfile'. With this

feature disabled the log file will be dependent on time as opposed to memory size.

**Figure 49: Unlimited Log File Size**



When logging is complete click on Logging > Stop Logging. Notice that the status bar has changed from red to blue. This informs that Logging is complete.

To view a log file, Camus recommends using Microsoft® Excel.

#### 8.8.1 Procedure for Viewing Log Files in Microsoft® Excel

- 1) Open Microsoft® Excel
- 2) Use a new spreadsheet, if Microsoft® Excel fails to load a new spreadsheet. Click on File > New..
- 3) Data > Import External Data > Import Data..
- 4) A window appears titled 'Select Data Source'
- 5) Identify the log file that was created and double-click it
- 6) A new window will pop up titled 'Text Import Wizard'. Select Delimited. Click Next.
- 7) Place a checkmark beside 'Tab' and 'Semi-Colon' from the checkboxes provided. Click Next.
- 8) In the 'Column data format' section of the window, ensure that 'General' is selected. Click Finish.
- 9) An 'Import Data' window will appear and check to see that 'Existing Worksheet' is selected and the text box reads: '=Sheet1!\$A\$1' or '= \$A\$1'. This allows the data to start to importing the data at cell 'A1' of the spreadsheet.
- 10) Click OK.
- 11) The log file will appear on the spreadsheet.

#### 8.8.2 Analysis of Microsoft® Excel Log File

The log file parameters are divided into columns with a reference to the time of data collection on each row. The Status and State parameters are identified by numbers and these can be translated into a description, listed below.

**Table 26: Description of State and Status Parameters**


State		Status	
#	Description	#	Description
0	RESET_0	0	STANDBY
1	RESET_1	10	ALARM
2	STANDBY_0	14	BLOCK
3	SAFETY_ON	15	FROST_PROTECT
4	SAFETY_OFF	16	CH
5	PRE_PURGE	17	RESET_STATE
6	PRE_PURGE_1	18	STORAGE
7	IGNIT_0	19	TAP
8	IGNIT_1	20	PRE_HEAT
9	BURN_0		
10	POST_PURGE_0		
11	POST_PURGE_1		
12	PUMP_CH_0		
13	PUMP_CH_1		
14	PUMP_HW_0		
15	PUMP_HW_1		
16	ALARM_1		
17	ERROR_CHECK		
18	BURNER_BOOT		
19	CLEAR_E2PROM_ERROR		
20	STORE_BLOCK_ERROR		
21	WAIT_A_SECOND		



## 8.9 Error History

LabVision has the ability to record past blocking (E) and lockout (A) errors. To access this feature use the pull down menu and select History.


**Figure 50: Error History**



The blocking and lockout errors are separated into their own respective rows and are identified by their respective error codes. This assists with diagnostic and service work as the behaviour of the boiler can be tracked.

This screen also provides information of the number of Successful Ignitions, Failed Ignitions and Flame failures due to a lost flame signal.

**Figure 51: History and Diagnostic Information**




Due to a large number of error codes that can be presented, LabVision comes complete with a feature in which to provide a description of each error code. Double click on the phrase 'Enter error number here for description' and a window will appear allowing the installer to identify the error.

**Figure 52: Error Query**



Temperature Quick Reference	
°C	°F
-40	-40
-35	-31
-30	-22
-25	-13
-20	-4
-15	5
-10	14
-5	23
0	32
5	41
10	50
15	59
20	68
25	77
30	86
35	95
40	104
45	113
50	122
55	131
60	140
65	149
70	158
75	167
80	176
85	185
90	194
95	203
100	212

## PART 9 DYNAMAX CONTROL PANEL



## 9.1 INTRODUCTION TO THE DYNAMAX CONTROL PANEL

For times when a notebook computer is not available, a service technician will still be able to perform all the functions described in LabVision, except for the logging aspect.

The menu structure for the DynaMax Control Panel was designed to be intuitive and easy to use for a first time user. To maintain the DynaMax boiler at its correct settings three levels of security is provided. User, Installer and Factory with an increasing amount of parameters that can be adjusted with each higher level of access. This is done to provide an easy means of communication for the end user and a more indepth approach for factory and installers when installing and troubleshooting.

**Figure 53: DynaMax Control Panel Layout**



**Table 27: DynaMax Control Panel Key Functions**

KEY	KEY DESCRIPTION
MENU	The MENU display is shown when pressed.
RESET	Only used during a lockout error situation
ENTER	Confirms selection of a parameter or parameter value
PREVIOUS	Scroll backward through the parameter structure
NEXT	Scroll forward through the parameter structure
UP	Increase a parameter value
DOWN	Decrease a parameter value

### Levels of Access

Three access levels to simplify the use of the boiler.

**User** – Access to general boiler and display settings and will allow adjustments to the central heating and domestic hot water setpoint.


**Installer** – Access to all user parameters and allows for changes to additional boiler parameters to allow for ease of startup and serviceability.

**Camus** – Full access to DynaMax parameters and is only open to Camus personnel.

### Startup Display

Upon startup of the DynaMax boiler the DynaMax Control Panel startup display is shown. This display is shown for 5 seconds upon startup. The Version # relates to the version of software uploaded onto the boiler control.

**Figure 54: DynaMax Home Screen**



The display panel then defaults to the next screen which provides System, Boiler and Hot Water temperature. For a DynaMax heater that does not have domestic hot water capability the status will display OFF.

A temperature readout of supply temperatures from the boiler will be displayed. If the DynaMax is a water heater or a combination unit it will also display the Hot Water temperature.

**Figure 55: Temperature and Status**




**Table 28: Temperature and Status Display Readout**

	DISPLAY READOUT	DESCRIPTION
System	ON	Heat Request
	OFF	No Heat Request
	DHW	DHW Request
	ERR	Lockout/ Blocking Error
Boiler	ON	Burner On, Responding to CH Demand
	OFF	Burner Off
Hot Water	ON	Burner On, Responding to DHW Demand
	OFF	Burner Off

## 9.2 MENU SCREEN

From TEMPERATURE AND STATUS display;







- 1) Press **[MENU]** button.

<i>Display</i>	<i>Display Readout</i>	<i>Description</i>
	System Monitor	Monitor Central Heating and DHW settings, if equipped. System Monitor will be open to all levels of access.
	Display Options	Changes to Languages, Date and Time, and Units of measurement. The default setting is English, Fahrenheit and Imperial. 'Display Options' will be open to all levels of access
	Appliance Settings	Changes boiler characteristics. The User level will have access to the first screen inside Appliance Settings which allows for changes in Central Heating setpoint. A 4-digit personal identification number (PIN) needs to be entered before moving further into the controller. If an incorrect PIN# is entered this will result in an error displayed on screen.
	Errors	Displays the lockout or error code along with a description of the error.

### 9.3 SYSTEM MONITOR DISPLAY

From MENU display;

- 1) Use [NEXT] to select 'System Monitor'
- 2) Press [ENTER]

Display	Display Readout		Description
	Active Program	MASTER	Boiler is designated as a Master boiler in the cascade setup
		SLAVE	Boiler is designated as a Slave boiler in the cascade setup
	PUMP	ON	Pump is active
		OFF	Pump is inactive (idle)
	STATUS	Standby	Heating and DHW Request (if equipped) is satisfied
	Outd		Outdoor Temperature (if equipped)
	In		Boiler Return/Inlet Water Temperature
	Out		Boiler Supply/ Outlet Water Temperature
	Setp		CH Setpoint Temperature
	Flue		Boiler Flue Temperature
	DHW		DHW Temperature (if equipped)
	In		Boiler Return/Inlet Water Temperature
	Out		Boiler Supply/ Outlet Water Temperature
	Setp		DHW Setpoint Temperature
	Flue		Boiler Flue Temperature
	Sys		System Temperature of Primary Loop
	In		Return/Inlet Temperature to Boiler
	Out		Supply/Outlet Temperature to Boiler
	Setp		Central Heating Setpoint
	Flue		Flue Temperature
	Total Run Time Since Installation		Monitors the amount of operational time since the DynaMax was installed. The timer starts counting as soon as it receives a flame signal to the time the flame signal disappears
	Min.		Programmed Minimum Fan Speed
	Max.		Programmed Maximum Fan Speed
	Ign.		Programmed Ignition Fan Speed
	Actual		Actual Fan Speed updated in real-time
	Flame Current		7-9µA: High Fire 3-5 µA: Low Fire
	Software Version		MN: 848MN-7R software version RC: 848-RC software version
	RC V.:		
	MN V.:		

## 9.4 DISPLAY OPTIONS DISPLAY

From MENU display;

- 1) Use **[PREVIOUS]/[NEXT]** button to select 'Display Options'.
- 2) Press **ENTER**

<i>Display</i>	<i>Display Readout</i>	<i>Description</i>
<div> <b>DISPLAY SETTINGS</b>  <b>→Language</b>  <b>Date and Time</b>  <b>Units</b> </div>	Language	Allows the control to be set to English (default), French or Spanish
	Date and Time	Allows the Date and Time to be changed
	Units	Allows the control to be set to Imperial (default) or Metric units
<div> <b>DATE AND TIME</b>  <b>Wednesday</b>  <b>22 JUN 2008</b>  <b>15:17</b> </div>	Date and Time	<ol style="list-style-type: none"> <li>1) Use <b>[NEXT]</b> to view DATE AND TIME display</li> <li>2) Use <b>[UP]/[DOWN]</b> and the cursor arrow will point to either the Day, Date or Time</li> <li>3) Press <b>[ENTER]</b> to change a parameter. The parameter will begin to flash</li> <li>4) Use <b>[UP]/[DOWN]</b> to change parameter value.</li> <li>5) Press <b>[ENTER]</b> to confirm.</li> </ol>
<div> <b>UNITS</b>  <b>→Imperial</b>  <b>Metric</b> </div>	Units	<ol style="list-style-type: none"> <li>1) Use <b>[NEXT]</b> to view UNITS display</li> <li>2) Use <b>[UP]/[DOWN]</b> to select the desired unit of measurement</li> <li>3) Press <b>[ENTER]</b> to confirm.</li> </ol>



## 9.5 CENTRAL HEATING DISPLAY

- 1) Use [PREVIOUS]/[NEXT] button to select 'Appliance Settings'.
- 2) Press ENTER

Display	Display Readout	Description
<div> APPLIANCE SETTINGS ▲  →Central Heating  Domestic Hot Water  Cascade Control ▼  Boiler Control </div>	Central Heating	Enters Central Heating branch of display
<div> CENTRAL HEATING  Enter Desired Temp.:  (45..194):  CH_Setpoint 160°F </div>	Setpoint	Allows adjustment of Setpoint. The Setpoint is controlled to the boiler outlet sensor. (Default: 160°F)
<div> CENTRAL HEATING  Enter PIN# To Access  Additional  Parameters: 0000 </div>	PIN# Access	<ol style="list-style-type: none"> <li>1) Use [NEXT] to enter INSTALLER ACCESS display</li> <li>2) Use [UP/DOWN] to enter desired PIN #.</li> <li>3) Press [ENTER] to confirm.</li> </ol>
<div> CH PARAMETER  CH MODE # (0-3):  0 </div>	CH Mode of Operation	Mode 0: Central Heating Without Outdoor Reset Mode 1: Central Heating with Outdoor Reset and Thermostat Control Mode 2: Central Heating with Outdoor Reset Mode 3: Central Heating with Constant Temperature Loop
<div> CH PARAMETER MODE 0  CH Setpoint ▲  (45..194): ▼  160°F </div>	CH_Setpoint (Mode 0, 3)	Allows adjustment of Setpoint. The Setpoint is controlled to the boiler outlet sensor. (Default: 160°F)
<div> CH PARAMETER MODE  CH Hysteresis ▲  (-9..36): ▼  9°F </div>	CH_Hysteresis (Mode 0, 1, 2, 3)	To provide modulation rate above and below CH_setpoint. For example, if the value is 10°F and the setpoint is 160°F, the boiler will begin to modulate at 155°F and shut off at 165°F. (Default: 9°F)
<div> CH PARAMETER MODE 2  T_day_ref  (16..122):  86°F </div>	T_day_ref (Mode 1, 2)	To determine the outdoor reset temperature. The control uses the following algorithm to adjust the CH_setpoint: $CH\_Setpoint = T\_day\_ref + [(70 - T\_Outdoor) * Slope]$ . (Default: 86°F)
<div> CH PARAMETER MODE  Slope ▲  (0.1..5.0): ▼  1.0 </div>	Slope (Mode 1, 2)	To determine the outdoor reset temperature. See T_day_ref to understand how Slope affects CH_Setpoint. (Default: 1.0)

Display	Display Readout	Description
CH PARAMETER MODE 2 T_night_reduction ( 0..90 ): 18 °F	T_night_reduction (Mode 2,3)	Temperature for night time usage This parameter is only engaged when the external clock is satisfied. (Default: 18°F).
CH PARAMETER MODE Weather_setpoint ▲ ( 32..122 ): ▼ 68 °F	Weather_setpoint (Mode 2)	When the outdoor temperature is below the preset Weather_setpoint a CH demand is created. Therefore, the CH demand is not dependent on Room Temperature input. (Default: 68°F)

## 9.6 DOMESTIC HOT WATER DISPLAY

- 1) Use [PREVIOUS]/[NEXT] button to select 'Appliance Settings'.
- 2) Press ENTER

Display	Display Readout	Description
APPLIANCE SETTINGS ▲ Central Heating → Domestic Hot Water Cascade Control ▼ Boiler Control	Domestic Hot Water	Enters Domestic Hot Water branch of display
DOMESTIC HOT WATER Enter Desired Temp.: ( 45..194 ): DHW_Setpoint 120 °F	DHW Setpoint	Allows adjustment of Setpoint. The set point is controlled to the boiler outlet sensor. (Default: 120°F)
DHW PARAMETER Enter PIN# To Access Additional Parameters: 0000	PIN# Access	1) Use [NEXT] to enter INSTALLER ACCESS display 2) Use [UP/DOWN] to enter desired PIN #. 3) Press [ENTER] to confirm.
DHW PARAMETER DHW MODE # ( 0 - 4 ) :	DHW Mode of Operation	Mode 0: Disables DHW Functionality Mode 1: DHW Storage Tank with Temperature Sensor Mode 2: DHW Storage Tank with Aquastat Mode 4: Combination Boiler using Plate Heat Exchanger and DHW Temperature Sensor
DOMESTIC HOT WATER Enter Desired Temp.: ( 45..194 ): DHW_Setpoint 120 °F	DHW Setpoint	Allows adjustment of Setpoint. The Setpoint is controlled to the boiler outlet sensor. (Default: 120°F)

Display	Display Readout	Description
DHW PARAMETER MODE 1 DHW_store_hyst_up ▲ ( 0 . . 3 6 ) : ▼ 9 ° F	DHW_Store_Hyst_Up (Mode 1)	Used to end a call for heat (Default: 9°F)
DHW PARAMETER MODE 1 DHW_store_hyst_down ▲ ( 0 . . 3 6 ) : ▼ 4 ° F	DHW_Store_Hyst_Down (Mode 1)	Used to start a call for heat (Default: 4°F)
DHW PARAMETER MODE 1 DHW_store_supply_ ▲ extra ▼ ( 0 . . 5 4 ) : 2 0 ° F	DHW_Store_Supply_Extra (Mode 1)	Increases the target outlet temperature (Default: 20°F)
DHW PARAMETER MODE 1 DHW_supp_hyst_up ▲ ( 0 . . 3 6 ) : ▼ 9 ° F	DHW_Supp_Hyst_Up (Mode 1, 2)	Temperature above set point to stop burner for DHW. This parameter is to match DHW_store_hyst_up (Default: 9°F)
DHW PARAMETER MODE 1 DHW_supp_hyst_down ▲ ( 0 . . 3 6 ) : ▼ 4 ° F	DHW_Supp_Hyst_Down (Mode 1, 2)	Temperature above set point to stop burner for DHW. This parameter is to match DHW_store_hyst_down (Default: 9°F)
DHW PARAMETER MODE DHW_hyst_up ▲ ( 0 . . 3 6 ) : ▼ 9 ° F	DHW_Hyst_up (Mode 4)	To provide modulation rate above the DHW_setpoint. (Default: 9°F)
DHW PARAMETER MODE DHW_hyst_down ▲ ( 0 . . 3 6 ) : ▼ 4 ° F	DHW_hyst_down (Mode 4)	To provide modulation rate below the DHW_setpoint. (Default: 4°F)
DHW PARAMETER MODE Pre-Heat Setpoint ▲ ( 1 0 0 . . 1 4 0 ) : ▼ 1 1 0 ° F	Pre-Heat Setpoint (Mode 1, 4)	During a DHW request, the user will not be subjected to a stream of cold water when the tap is first turned on. This also creates a buffer zone for the boiler to fire up and modulate. (Default: 110°F)
DHW PARAMETER MODE Pre-Heat hyst_up ▲ ( 0 . . 3 6 ) : ▼ 0 ° F	Pre-Heat hyst_up (Mode 1, 4)	To provide modulation rate above Pre-heat setpoint for the plate heat exchanger during pre-heat. (Default: 0°F)
DHW PARAMETER MODE Pre-Heat hyst_down ▲ ( 0 . . 3 6 ) : ▼ 9 ° F	Pre-Heat hyst_down (Mode 1, 4)	To provide modulation rate below Pre-heat set point for the plate heat exchanger during pre-heat. (Default: 9°F)





## 9.7 CASCADE CONTROL

- 1) Use [PREVIOUS]/[NEXT] button to select 'Appliance Settings'.
- 2) Press ENTER

Display	Display Readout	Description
APPLIANCE SETTINGS ▲ Central Heating Domestic Hot Water → Cascade Control ▼ Boiler Control	Cascade Control	Enters Cascade branch of display
CASCADE PARAMETER ▲ Address Selection: (0..8) Standalone Boiler ▼	Master/Slave Selection	1) Use [UP]/[DOWN] to select the option of a 'MASTER Boiler' or 'SLAVE Boiler'. 2) Press [ENTER] to confirm. 3) If 'SLAVE Boiler' is selected assign it an address of '2' if this is the boiler immediately after the 'MASTER Boiler'. Assign a number of '3' if it is the third boiler in the system. Continue this until all boilers have been assigned an address. Use [UP]/[DOWN] to select the correct address 4) Press [ENTER] to confirm.
CASCADE PARAMETER ▲ Cascade Delay Time (1..15) 120 sec ▼	Cascade Delay Time	Delay time for switching on/off next boiler when ch_setpoint is (not) satisfied. (Default: 120°F)
CASCADE PARAMETER ▲ Cascade Hysteresis (0..36) 5°F ▼	Cascade Hysteresis	Hysteresis to start and stop the next slave boilers. (Default: 5°F)
CASCADE PARAMETER ▲ Lead Lag Time (0..2000) 0 hrs ▼	Lead Lag Time	Period after which boiler start-up order changes. (Default: 100 hrs)
CASCADE PARAMETER ▲ System Sensor Enable Enabled ▼	System Sensor Enable	When enabled the system sensor will regulate the firing rate of the boilers. When disabled the firing rate is dictated by the supply sensor of the Master boiler
CASCADE PARAMETER ▲ Cascade Mode DHW ▼	Cascade Mode	CH&DHW: Central Heating & Domestic Hot Water DHW/SENS: Domestic Hot Water using a sensor DHW/STAT: Domestic Hot water using an aquastat


## 9.8 BOILER CONTROL

- 1) Use [PREVIOUS]/[NEXT] button to select 'Boiler Control'.
- 2) Press ENTER

Display	Display Readout	Description
	Boiler Control	Enters Boiler Control branch of display
	Pre Purge Period	Sets the pre purge time for before ignition occurs (Default: 10 seconds)
	Post Purge Period	Sets the post purge time after a call for heat ends (Default: 30 secs for wall hung units, 100 secs for floor mount units)
	System Test	Manual override of fan speeds for a time of 10 minutes. Fan speeds can vary from Off, Minimum Power, Ignition Power or Maximum Power

## 9.9 ERROR SCREEN

- 1) Use [PREVIOUS]/[NEXT] to select 'Errors'
- 2) Press [ENTER].

Display	Display Readout	Description
	Error Screen	<p><b>Lockout:</b> This will display 'Blocking' or 'Lockout' depending on the error</p> <p><b>Int.nr:</b> This will display the error code in the form of an internal number (Lockout code, Table 5.4.1) or (Blocking error, Table 5.4.2)</p> <p><b>Error Description:</b> The error description block shall display the error in text.</p>

## PART 10 TROUBLESHOOTING

Table 29: Troubleshooting Table

COMPONENT	FAILURE MODE	ANALYSIS
Incoming Power	<ul style="list-style-type: none"> <li>Two wires interchanged</li> </ul>	<ul style="list-style-type: none"> <li>No effect on safety</li> <li>Live and Neutral wires are interchanged.</li> </ul>
Transformer Tripped	<ul style="list-style-type: none"> <li>The 24Volts and 120 Volts wired are interchanged</li> </ul>	<ul style="list-style-type: none"> <li>Transformer immediately burns out, replace transformer</li> <li>Fuse on DynaMax Controller blows, replace 3.15A fuse located at F1 on DynaMax Controller.</li> </ul>
Pump Fails to Circulate	<ul style="list-style-type: none"> <li>Wiring Issue</li> </ul>	<ul style="list-style-type: none"> <li>Check that wires are correctly wired from the DynaMax Controller to the pump delay relay.</li> <li>Check that 115V is delivered to pump coil.</li> </ul>
	<ul style="list-style-type: none"> <li>Faulty Pump on a wet rotor pump</li> </ul>	<ul style="list-style-type: none"> <li>Pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually</li> <li>Replace Pump</li> </ul>
	<ul style="list-style-type: none"> <li>Air in the piping system</li> </ul>	<ul style="list-style-type: none"> <li>Purge all air from the piping system</li> </ul>
	<ul style="list-style-type: none"> <li>Internal Fault on DynaMax Controller</li> </ul>	<ul style="list-style-type: none"> <li>Replace DynaMax Controller</li> </ul>
Relief Valve	<ul style="list-style-type: none"> <li>System pressure exceeds relief valve setting</li> </ul>	<ul style="list-style-type: none"> <li>Replace the standard relief valve with a higher rated valve up to the maximum pressure of the heat exchanger.</li> <li>Improperly sized expansion tank.</li> </ul>
Flow Proving Device/ LWCO	<ul style="list-style-type: none"> <li>Flow Proving Device/ LWCO contacts are open</li> </ul>	<ul style="list-style-type: none"> <li>Verify LED's on current sensing transformer during a heat demand (wall hung)</li> <li>Check flow switch paddle (floor mount)</li> <li>Verify for closed valves or obstructions in boiler piping</li> <li>Verify that all air has been purged from the system</li> <li>Verify that wiring is correct</li> </ul>
	<ul style="list-style-type: none"> <li>Blown Fuse</li> </ul>	<ul style="list-style-type: none"> <li>Replace 3.15A Fuse located at F1 on DynaMax Controller.</li> <li><b>DO NOT</b> use alternates as it may damage the DynaMax Controller</li> </ul>



SYMPTOM	FAILURE MODE	ANALYSIS
<p><b>Flame Failure</b> (Pressing the manual RESET on the DynaMax Control Panel will be required to restart the ignition sequence)</p>	<ul style="list-style-type: none"> <li>• The boiler has failed to ignite the burner after 3 unsuccessful attempts</li> </ul>	<ul style="list-style-type: none"> <li>• Verify that all air has been purged from gas line</li> <li>• Inspect spark electrode and related wiring for damage and connection errors</li> <li>• Verify that the ignition fan speed is set to 3000 RPM through fan diagnostics screen.</li> <li>• Verify that boiler is properly grounded</li> <li>• Verify incoming gas supply pressure and that it coincides with Table 9.</li> <li>• Verify that the vent/ air inlet piping (if equipped) are correctly installed and obstructions are not present.</li> <li>• Verify 120 VAC and 24 VAC is being supplied to the gas valve transformer from the DynaMax Controller during ignition. Check wiring from DynaMax Controller, Gas Valve Transformer and Gas Valve Relay. If a signal cannot be detected, the DynaMax Controller needs to be replaced</li> <li>• If 24 VAC is present, check the outlet of the valve to ensure that gas is flowing. With a manometer connected to the outlet pressure tap of the gas valve a negative pressure should be present during pre-purge. When the valve is energized a change in pressure should occur, if no change is detected the gas valve has failed to open or it is passing insufficient amount of gas. If this is an initial startup increase the low fire gas setting by ¼ turn clockwise.</li> <li>• Inspect flame sensor and associated wiring. Replace if necessary</li> <li>• Inspect the burner. Refer to Burner Maintenance in section 11.7</li> <li>• Replace the DynaMax Controller</li> </ul>
<p><b>Flame Disappears During a Run Cycle</b> (Pressing the manual RESET on the DynaMax Control Panel will be required to restart the ignition sequence)</p>	<ul style="list-style-type: none"> <li>• The DynaMax boiler was running and flame signal suddenly disappeared. This condition occurred 3 times.</li> </ul>	<ul style="list-style-type: none"> <li>• Verify that minimum fan speed is greater than 2500 RPM</li> <li>• Verify that all air has been purged from gas line</li> <li>• Inspect spark electrode and related wiring for damage and connection errors.</li> <li>• Verify that boiler is properly grounded</li> <li>• Verify incoming gas supply pressure and that it coincides with Table 9.</li> <li>• Verify that the gas line connections to the boiler are adequate</li> <li>• Verify that the vent/ air inlet piping (if equipped) are correctly installed and obstructions are not present</li> <li>• Verify 120 VAC is being supplied to the transformer from the DynaMax Controller during ignition. If a signal cannot be detected, the DynaMax Controller needs to be replaced</li> <li>• Verify that 24 VAC is being supplied to the gas valve during ignition. If a signal cannot be detected, the transformer needs to be replaced</li> <li>• Inspect flame sensor and associated wiring. Replace if necessary</li> <li>• Inspect the burner. Refer to Burner Maintenance in section 11.7</li> <li>• Replace the DynaMax Controller if necessary</li> </ul>

SYMPTOM	FAILURE MODE	ANALYSIS
<b>Noisy Operation</b>	<ul style="list-style-type: none"> <li>Supply Gas Issue</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Part 3 Gas Connection in this manual.</li> <li>Natural Gas Pressure should read between 3" w.c. and 14" w.c.</li> <li>L.P. Gas Pressure should be at 11" w.c.</li> </ul>
	<ul style="list-style-type: none"> <li>Air/Gas Mixture Issue</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Gas Valve Adjustment Procedure in section 10.2 of this manual for the proper combustion setting.</li> </ul>
	<ul style="list-style-type: none"> <li>Air Inlet and/or Vent configuration</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Part 2 Air Inlet and Venting</li> </ul>
	<ul style="list-style-type: none"> <li>Dirty/ Damaged burner</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Burner Maintenance in section 11.7 of this manual for the burner removal and inspection procedure. Clean or replace the burner, if required.</li> </ul>
	<ul style="list-style-type: none"> <li>Air in the piping system</li> </ul>	<ul style="list-style-type: none"> <li>Purge all air from the piping system</li> </ul>
	<ul style="list-style-type: none"> <li>Incorrect igniter gap</li> </ul>	<ul style="list-style-type: none"> <li>Check that spark gap is 9/64"</li> </ul>
<b>Auto Reset High Limit Trips</b>	<ul style="list-style-type: none"> <li>The supply/ outlet temperature has exceeded 210°F.</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the system is full of water and that all air has been properly purged from the system.</li> <li>Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 13 of this manual.</li> <li>Verify that 120VAC is being supplied to the boiler pump on a call for heat. If voltage cannot be detected check wiring.</li> <li>Verify that the pump is circulating when 120VAC is detected. If not, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually</li> <li>If 120VAC is present during a call for heat, but the pump still does not circulate, replace the pump.</li> <li>Replace the main DynaMax Controller if necessary</li> </ul>
<b>Manual Reset High Limit Trips</b> (Pressing the manual RESET on the DynaMax Control Panel will be required to restart the ignition sequence)	<ul style="list-style-type: none"> <li>Manual Reset Safety High Limit tripped, supply/outlet temperature in excess of 210°F</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the capillary tube is broken. If this is the case, replace Manual Reset High Limit</li> <li>Verify that the system is full of water and that all air has been properly purged from the system.</li> <li>Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 13 of this manual.</li> <li>Verify that 120 VAC is being supplied to the boiler pump on a call for heat. If voltage cannot be detected check wiring.</li> <li>Verify that the pump is circulating when 120 VAC is supplied. If so, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually.</li> <li>If 120 VAC is present during a call for heat, but the pump still does not circulate, replace pump.</li> </ul>
<b>Fan Speed Too Low</b>	<ul style="list-style-type: none"> <li>Actual fan RPM is 30% slower than target fan speed.</li> </ul>	<ul style="list-style-type: none"> <li>Verify wiring connections at the fan and DynaMax Controller.</li> <li>Replace the fan</li> <li>Replace the DynaMax Controller.</li> </ul>
<b>Fan Speed Too High</b>	<ul style="list-style-type: none"> <li>Actual fan RPM is 30% faster than what is required.</li> </ul>	<ul style="list-style-type: none"> <li>Vent/ Air Inlet Lengths exceed the maximum allowed equivalent lengths. Refer to Air Inlet and Venting Section in Part 2 of this manual.</li> <li>Verify that there are no obstructions in the vent/ air inlet pipes or at terminations</li> <li>Verify wiring connections at the fan and DynaMax Controller.</li> <li>Replace the fan</li> <li>Replace the DynaMax Controller.</li> </ul>

SYMPTOM	FAILURE MODE	ANALYSIS
<b>Flue Gas Error</b>	<ul style="list-style-type: none"> <li>Stack temperature has exceeded the limit set on the boiler.</li> </ul>	<ul style="list-style-type: none"> <li>Measure the resistance of the flue sensor at room temperature, it should be approximately 10kΩ.</li> <li>PVC: 149°F</li> <li>CPVC: 194°F</li> <li>Stainless Steel, AL29-4C: 210°F</li> </ul>
<b>Sensor Not Connected</b>	<ul style="list-style-type: none"> <li>Supply sens open</li> <li>Return sens open</li> <li>Stack sens open</li> <li>DHW sens open</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the sensors are connected</li> <li>Verify that they are wired correctly.</li> <li>Measure the resistance of the sensors, 10kΩ sensors.</li> <li>Replace the sensor if necessary</li> </ul>
<b>Sensor Shorted</b>	<ul style="list-style-type: none"> <li>Supply sens shorted</li> <li>Return sens shorted</li> <li>Stack sens shorted</li> <li>DHW sens shorted</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the sensors are connected</li> <li>Verify that they are wired correctly.</li> <li>Measure the resistance of the sensors, 10kΩ sensors.</li> <li>Replace the sensor if necessary</li> </ul>
<b>Fan Not Turning</b>	<ul style="list-style-type: none"> <li>A33 shown on display. Fan refuses to rotate</li> </ul>	<ul style="list-style-type: none"> <li>Check fan power wires</li> <li>Fan signal wires are interchanged</li> <li>Minimum fan speed must be greater than 1500 RPM</li> </ul>
<b>Air Switch</b>	<ul style="list-style-type: none"> <li>Blocked flue error</li> <li>Check gas pressure switches, if equipped</li> </ul>	<ul style="list-style-type: none"> <li>Air Switch wire(s) is/are loose</li> <li>Air Switch is set too tight, reduce sensitivity by turning screw ¼ turn clockwise.</li> </ul>
<b>Flame Detection is out of Sync</b>	<ul style="list-style-type: none"> <li>Flame detection is present when no visible signs of a flame exist</li> </ul>	<ul style="list-style-type: none"> <li>Verify supply voltage for proper polarity.</li> <li>Check external wiring for voltage feedback</li> <li>Check internal wiring for proper connections</li> <li>Check the flame sensor and verify that it is clean</li> <li>Replace DynaMax Controller</li> </ul>
<b>Blank Display Screen</b>	<ul style="list-style-type: none"> <li>Blank display screen</li> </ul>	<ul style="list-style-type: none"> <li>Check S4 switch position on ignition module. Switch is pushed towards J5 connector</li> <li>Check that display is connected to the standalone connector on the back of the display</li> <li>Replace fuse with factory 3.15A fuse.</li> <li><b>DO NOT</b> use alternates as it may damage the DynaMax Controller</li> </ul>

## 10.1 SETTING THE CORRECT COMBUSTION

- 1) Switch the main power off to the boiler by placing the toggle switch in the 'OFF' position
- 2) Switch the main power on to the boiler and adjust set point so that boiler begins ignition sequence.
- 3) Observe the boiler as it goes through its startup cycle and operates at high fire. This cycle is detailed on Table 41 in section 12.14 Ignition Cycle.
- 4) Insert the combustion measurement probe into the stack when high fire operation is observed. Check to see that fan is running at maximum fan speed using the Control Panel.
- 5) The combustion values should reside in the range listed in Table 38. If combustion values are not within this range refer to Section 10.2 Gas Valve Adjustment Procedure to correct this issue.

**Table 30: Combustion Values**

	Natural Gas		Propane	
	CO <sub>2</sub>	CO	CO <sub>2</sub>	CO
<b>Max. Fire</b>	8.5% - 9.0%	<100 PPM	9.5% - 10.0%	<100 PPM
<b>Min. Fire</b>	8.0% - 8.5%	<100 PPM	9.0% - 9.5%	<100 PPM

- 6) When the combustion values are satisfied record these values as Camus requires these for warranty purposes.
- 7) Remove the combustion measurement device and switch the main power off to the boiler by placing the toggle switch in the 'OFF' position.
- 8) Replace the flue temperature sensor back to its proper location.

## 10.2 GAS VALVE ADJUSTMENT PROCEDURE

If adjustment of the gas valve is required use the following procedure.

In order to perform adjustments to the gas valve the DynaMax must be firing before proceeding.

**DM 080 – 250, 260**

**Figure 56: Venturi & Gas Valve Assembly**

Low-fire adjustment screw  
(use Torx 40 for adjustment,  
clockwise increases CO<sub>2</sub>)

High-fire adjustment screw  
(use slotted screwdriver for  
adjustment, counter-  
clockwise increases CO<sub>2</sub>)



### To adjust the high-fire setting

Use the DynaMax Control Panel

Press the **[MENU]** button > select Appliance Settings and press **[ENTER]** > select Boiler Control and press **[ENTER]** > Enter the correct Installer passcode.

Select 'Maximum power' for high power. The DynaMax should respond immediately and fire at maximum fan speed.

Locate the input adjustment screw on the side of the venturi. Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

	Increase CO <sub>2</sub>	Decrease CO <sub>2</sub>
<b>High Fire Adjustment</b>	 Counter-Clock Wise	 Clockwise

On the DynaMax Control Panel select 'off' to return to normal operation.

### To adjust the low fire setting

Use the DynaMax Control Panel

Press the **[MENU]** button > select Appliance Settings and press **[ENTER]** > select Boiler Control and press **[ENTER]** > Enter the correct Installer passcode.

Select 'Minimum power' for low power.


The DynaMax should respond immediately and fire at minimum fan speed. When this is achieved locate the low fire adjustment screw as illustrated in Figure 56. This screw is covered with a cap, which can be removed using a Torx 40 screwdriver. When the correct combustion values are achieved replace the screw cap back on to the gas valve.

	Increase CO <sub>2</sub>	Decrease CO <sub>2</sub>
<b>Low Fire Adjustment</b>	 Clockwise	 Counter-Clock Wise

On the DynaMax Control Panel select 'off' to return to normal operation.

## DM 299 – 399

**Figure 57: DM 299 – 399 Gas Valve**



High fire adjustment, increases CO<sub>2</sub>

Low fire adjustment (Use for adjustment, increases CO<sub>2</sub>)

### To adjust the high-fire setting

Use the DynaMax Control Panel

Press the **[MENU]** button > select Appliance Settings and press **[ENTER]** > select Boiler Control and press **[ENTER]** > Enter the correct Installer passcode.

Select 'Maximum power' for high power. The DynaMax should respond immediately and fire at maximum fan speed.

Locate the high-fire adjustment screw on the top side of the gas valve. The screw can be identified by a red cylinder casing around the screw. Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

	Increase CO <sub>2</sub>	Decrease CO <sub>2</sub>
<b>High Fire Adjustment</b>	 Counter-Clock Wise	 Clockwise

On the DynaMax Control Panel select 'off' to return to normal operation.

### To adjust the low fire setting

Use the DynaMax Control Panel

Press the **[MENU]** button > select Appliance Settings and press **[ENTER]** > select Boiler Control and press **[ENTER]** > Enter the correct Installer passcode.

Select 'Minimum power' for low power.


The DynaMax should respond immediately and fire at 1500 RPM. When this is achieved locate the low fire adjustment screw as illustrated in Figure 57. When the correct combustion values are achieved replace the screw cap back on to the gas valve.

	Increase CO <sub>2</sub>	Decrease CO <sub>2</sub>
<b>Low Fire Adjustment</b>	 Clockwise	 Counter-Clock Wise

On the DynaMax Control Panel select 'off' to return to normal operation.

## DM 500 – 800

**Figure 58: DM 500 - 800 Gas Valve**



Lift top cover to access high fire air/gas ratio adjustment (use 3mm allen key for adjustment, counter-clockwise increases CO<sub>2</sub>)

Low-fire air/gas ratio adjustment, use slotted screwdriver for adjustment, clockwise increases CO<sub>2</sub>

Gas Inlet

### To adjust the high-fire setting

Use the DynaMax Control Panel

Press the **[MENU]** button > select Appliance Settings and press **[ENTER]** > select Boiler Control and press **[ENTER]** > Enter the correct Installer passcode.

Select 'Maximum power' for high power. The DynaMax should respond immediately and fire at maximum fan speed.

Locate the input adjustment screw on the top side of the gas valve. Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

	Increase CO <sub>2</sub>	Decrease CO <sub>2</sub>
<b>High Fire Adjustment</b>	 Counter-Clock Wise	 Clockwise

On the DynaMax Control Panel select 'off' to return to normal operation.

### To adjust the low fire setting

Use the DynaMax Control Panel

Press the **[MENU]** button > select Appliance Settings and press **[ENTER]** > select Boiler Control and press **[ENTER]** > Enter the correct Installer passcode.

Select 'Minimum power' for low power.

The DynaMax should respond immediately and fire at 1500 RPM. When this is achieved locate the low fire adjustment screw as illustrated in Figure 58. When the correct combustion values are achieved replace the screw cap back on to the gas valve.

	Increase CO <sub>2</sub>	Decrease CO <sub>2</sub>
<b>Low Fire Adjustment</b>	 Clockwise	 Counter-Clock Wise

On the DynaMax Control Panel select 'off' to return to normal operation.

## PART 11 MAINTENANCE

### CAUTION

It is important that all gas appliances be serviced by a qualified technician trained by Camus Hydronics. It is in your own interest and that of safety to ensure that all local codes, and all the "NOTES" and "WARNINGS" in this manual are complied with. To service or adjust this appliance, it is imperative that the serviceman utilize a combustion analyzer to read CO<sub>2</sub> and CO according to Camus Hydronics recommendations.

Listed below are items that must be checked to ensure safe reliable operations. Verify proper operation after servicing.

### 11.1 EXAMINE THE VENTING SYSTEM

Examine the venting system at least once a year. Check more often in the first year to determine inspection interval. Check all joints and pipe connections for tightness, corrosion or deterioration. Flush the condensate drain hose with water to clean. Clean screens in the venting air inlet system as required. Have the entire system, including the venting system, periodically inspected by a qualified service agency.


### 11.2 VISUALLY CHECK MAIN BURNER FLAMES

At each start up after long shutdown periods or at least every six months. A burner view port is located on the combustion chamber front door.

### CAUTION

The area around the burner view port is hot and direct contact could result in burns

**Figure 59: Normal Burner Flame Profile (short dense and blue)**




- **Normal Flame:** A normal flame at 100% of burner input is blue, with a well defined flame and no flame lifting.
- **Yellow Tip:** Yellow tipping can be caused by blockage or partial obstruction of air flow to the burner.
- **Yellow Flames:** Yellow flames can be caused by blockage of primary air flow to the burner or excessive gas input. This condition **MUST** be corrected immediately.

If improper flame is observed, examine the venting system; ensure proper gas supply and adequate supply of combustion and ventilation air.

### 11.3 CLEANING BOILER HEAT EXCHANGER

**Figure 60: Heat Exchanger & Burner Assembly**



- 1) Shut down boiler:
  - a) Turn the main power off to the boiler
  - b) Shut off gas supply at the main manual valve in the gas piping of the main appliance
  - c) **DO NOT** drain the boiler unless it will be exposed to freezing temperatures. If using antifreeze prevention fluid in the heat exchanger, **DO NOT** drain.
- 2) Allow time for the boiler to cool to room temperature if it has been firing.
- 3) **Wall Hung:** Remove both the stainless steel upper jacket and the lower sheetmetal jacket.  
**Floor Mount:** Remove front stainless steel panel.
- 4) Remove igniter and flame sensor electrodes. If necessary, clean with steel wool. **DO NOT** use sandpaper.
- 5) Remove the fan/ mixing tube assembly from the heat exchanger door.
- 6) Remove burner.
- 7) Examine burner and clean if required as per 11.7.1.
- 8) Examine heat exchanger surfaces to determine if cleaning is required. If cleaning is required remove the (6) nuts fastening the heat exchanger flange from the heat exchanger.
- 9) Use a vacuum cleaner to remove any debris that has collected on the heat exchanger surfaces. **DO NOT** use any type of solvent.
- 10) Finish cleaning by wiping down the boiler heating surfaces with a clean, damp cloth.
- 11) Re-install the heat exchanger door by evenly torquing down the (6) nuts to 3 ft-lbs, burner, igniter and flame sensor, and fan/ mixing tube assembly. Fasten the nuts back to the heat exchanger assembly.
- 12) Re-connect the fan assembly to the boiler mixing tube.



**NOTE**

All gaskets on disassembled components must be replaced with new gaskets/sealant on re-assembly, if required. Gasket kits are available from the factory

**CAUTION**

When the vent system is disconnected for any reason it must be reassembled and resealed according to vent manufacturer's instruction

**11.4 CONDENSATE TREATMENT**

Condensate occurs when the products of combustion are cooled below their dew point in the heat transfer process. The liquid condensate formed from this high efficiency heat transfer process is mildly acidic.

- The condensate will typically have a pH ranging from 4.0 to 5.0 as it is discharged from the condensate drain of the appliance.
- The condensate collection box inside each DynaMax where the condensate is collected is constructed of a non-corrosive plastic.
- All materials external to the appliance in contact with the condensate must be corrosion resistant.
- Condensate must be able to flow freely from the appliance. All condensate flow is accomplished by gravity requiring a minimum downward slope of 1/4" per foot (21mm/m) to ensure proper flow to a suitable drain.
- All condensate piping and connections must be easily accessible for routine maintenance and inspection.
- Use solid piping when running condensate line across the floor.
- Check neutralized pH level regularly or as required by local jurisdiction. Replace neutralizer medium as required.

There are several factors affecting amount of condensation created by the appliance, however for rough approximation use.

Condensation Volume, US Gallon/Hr = Input, MBH/1000 x 5.0

Many jurisdictions will require the acidic condensate to be neutralized before it can be placed in a drain system.

- A neutralizer, calcium carbonate, to control the pH of the liquid discharged to a drain system is provided with every DynaMax boiler.
- Neutralizer consists of an industrial grade, non-corrosive plastic reservoir for collection of the condensate.
- As the reservoir fills, it provides an extended residence time to neutralize the condensate.
- Residency time in the neutralizer reservoir allows time for the pH to be raised.
- Prime the neutralizer reservoir with 1 litre of water.

As the condensate migrates through the reservoir in typical applications the pH is controlled to a range of 5.5 to 6.0 before exiting the system. Always check with local codes for specific requirements.

**11.5 IGNITER AND FLAME SENSOR ELECTRODES**

The direct spark igniter is to be checked at every service interval. Clean the direct spark igniter as required to maintain peak ignition efficiency.

- 1) Turn off main electrical power to the appliance.
- 2) Turn off main manual gas shutoff to the appliance.
- 3) Locate the direct spark igniter and flame sensor.
- 4) Disconnect the power lead to the direct spark igniter and flame sensor
- 5) Loosen and remove the two (2) torx screws that hold the igniter and flame sensor to the heat exchanger flange.
- 6) Pull the igniter horizontally out of the heat exchanger flange. Use care, do not hit or break the igniter leads.
- 7) Remove any debris that has accumulated on the electrodes using steel wool. If the electrodes cannot be cleaned to their original appearance, replacements are needed. Do not use sand-paper since this will contaminate the surface.
- 8) Check that the igniter and flame sensor gaskets are still in good condition (no tears or seams). If the gaskets are in good condition the electrodes can be re-installed back to the heat exchanger flange.
- 9) Check that the igniter gap is 9/64".

**11.6 CHECK IGNITER GROUND WIRING**

- 1) Inspect boiler ground wire from the heat exchanger flange to J12 of the electrical DynaMax Controller. Check boiler ground wire continuity.
- 2) Verify that all wiring is in good condition and is securely anchored.

**11.7 BURNER MAINTENANCE**

The burner should be removed for inspection and cleaning on an annual basis. An appliance installed in a dust or dirt contaminated environment will require inspection and cleaning on a more frequent schedule. The fan assisted combustion process may force airborne dust and dirt contaminants, contained in the combustion air, into the burner. With sustained operation, non-combustible contaminants may reduce burner port area, reduce burner input or cause non-warrantable damage to the burner. **Never operate this appliance during construction.**

Airborne contaminants such as dust, dirt, concrete dust or dry wall dust can be drawn into the burner with the combustion air and block the burner port area.

**11.7.1 Burner Removal and Cleaning**

Access to the burner will require the following steps:

- Turn off main electrical power to the appliance.
- Turn off main manual gas shutoff to the appliance
- Remove the front cover.
- Disconnect the gas supply connection to the fan inlet.
- Disconnect the fan motor power wires at the harness.

- Remove the direct spark igniter and the flame sensor.
- Remove the T-25 screws holding the front burner flange in place to gain access to the burner.
- The burner can now be pulled horizontally out of the heat exchanger cavity.
- Use care to prevent damage to the knitted metal fiber of the burner surface.
- Wash the burner with water, such as a garden hose. Never wipe or brush the surface of the burner.
- For optimal results immerse the burner port area in a solution of dishwashing detergent and hot water. **DO NOT** use chlorine based solvents or cleaning agents on the burner. Allow the burner to remain in the solution for a short period of time to remove, dust, dirt and oil or grease laden contaminants.
- Rinse the burner thoroughly with clean water to remove any residue from the detergent cleaner
- The burner should be air dried after removal from the cleaning solution and rinsing.
- Check all gaskets and replace as necessary. Gaskets affected by heat will not reseal properly and must be replaced.
- Replace the burner in the reverse order that it was removed.

#### NOTE

When the combustion air fan is removed for any reason, the inlet to the burner must be covered to prevent further foreign objects from falling into the burner. Always look inside the burner to check for dents. Do not place a burner back into operation if the inner distribution screen has been dented during the service operation, call the factory for recommendations. Use care when removing and handling the burner, Sharp objects or impact may damage or tear the metal fiber surface rendering the burner unfit for service.

### 11.8 COMBUSTION AND VENTILATION AIR

Check frequently to be sure that the flow of combustion air to the appliance is not obstructed. Unless air is piped directly to the heater combustion air must be provided to the mechanical room with openings sized per the requirements of the current B149 or National Fuel Gas Code. The DynaMax is setup to allow outdoor combustion air to be connected directly to the appliance. It is highly recommended that combustion air be connected directly to the appliance. For installations in a common boiler room with atmospheric appliances or if there is the possibility of negative pressure in the boiler room, the air inlet must be piped directly to the DynaMax.

### 11.9 GAS VALVE VOLTAGE

This appliance uses a transformer to supply a 24 volt signal to the gas valve. The voltage on the secondary side should be 24 to 28VAC when measured with a voltmeter. A secondary voltage of 21VAC or less supplied to 24VAC components may cause operational problems.

### 11.10 COMBUSTIBLE MATERIALS

#### CAUTION

Keep appliance clear from combustible materials; do not store **GASOLINE** and other flammable vapors and liquids in the proximity of the appliance.

### 11.11 FREEZE PROTECTION FOR INDOOR & OUTDOOR INSTALLATIONS

Installations are not recommended in areas where the danger of freezing exists. Proper freeze protection must be provided for appliances installed outdoors, in unheated mechanical rooms or where temperatures may drop to the freezing point or lower. If freeze protection is not provided for the system, a low ambient temperature alarm is recommended for the mechanical room. Damage to the appliance by freezing is non-warrantable.

- **Location** - Heating boilers, hot water supply boilers or water heaters must be located in a room having a temperature of at least 40°F (5°C).
- **Caution** - A mechanical room operating under a negative pressure may experience a downdraft in the flue of an appliance that is not firing. The cold outside air may be pulled down the flue and causing a frozen heat exchanger. This condition must be corrected to provide adequate freeze protection.
- Freeze protection for the appliance using an indirect coil can be provided by using hydronic system antifreeze. Follow the manufacturer's instructions. **DO NOT** use undiluted or automotive type antifreeze.
- **Shut-down and draining** - If for any reason, the unit is to be shut off in a space where danger of freezing exists, the following precautionary measures must be taken:
  - Shut off gas supply.
  - Shut off water supply.
  - Shut off electrical supply.
  - Drain the main exchanger and the brazed plate heat exchanger, if supplied, completely.
  - Ensure that the pump and connecting piping are fully drained.

### 11.12 FREEZE PROTECTION FOR A HEATING BOILER SYSTEM (Optional)

- Use only properly diluted inhibited glycol antifreeze designed for hydronic systems. Camus recommends using a 30/70 mixture of glycol antifreeze to water. **DO NOT** exceed a mixture of 50/50.
- Follow the instructions from the antifreeze manufacturer. Quantity of antifreeze required is based on total system volume including expansion tank volume.
- **Antifreeze is denser than water and changes the viscosity of the system. The addition of antifreeze will decrease heat transfer and increase frictional loss in the boiler and related piping. Where antifreeze has been used, to maintain the temperature rise across the appliance confirm that the recommended GPM for pure water has been increased by 15% and the head loss by 20%.**
- Local codes require a back flow preventer or actual disconnect from city water supply when antifreeze is added to the system.
- When filling or topping-up the system with water mixed with the antifreeze always used distilled or RO (reverse osmosis) water. This will prevent the reaction of the water with antifreeze which can create sludge.



## PART 12 INSTALLATIONS

### WARNING

Before starting the boiler, smell near the floor and around the boiler for any gas odours or any unusual odour. Remove the stainless steel jacket and smell the interior of the boiler. If there is any sign of a gas leak, do not proceed with startup. Repair all the leaks before attempting to start the boiler.

### WARNING

Propane boilers ONLY – Your local propane supplier adds an odorant to the propane gas to allow for propane gas leak detection. In some cases, the added odorant can fade and the gas may not give off any noticeable odour. Before startup have the local propane supplier check for the correct odorant level in the gas.

### 12.1 CHECKING THE INSTALLATION

- Inspect the connections for water, gas and electricity.
- Inlet gas pressure must be a minimum of 3" W.C. for natural gas and 11" W.C. for propane.
- With the boiler off, open the main gas supply valve and vent the trapped air from the piping leading to the boiler. Confirm that all gas connections to the heater are tight and that there are no missing test plugs.

Refer to Section 10.1 Setting the Correct Combustion of the manual for recommendations on setting combustion characteristics

### 12.2 CHECKING THE CONSTRUCTION

- Check the boiler wiring to see that it agrees with the wiring diagram supplied.
- Confirm that all terminal strips and field connections are identified.
- Confirm that the DynaMax Controller control is set in the proper mode. In remote mode an external controller determines the set point and the stage contacts on the DynaMax Controller are always closed. Auto reset limits are fixed in all Modes.
- With the boiler running, check for flue gas leaks along the inner cabinet joints and around the flue outlet.
- Repair any leaks prior to proceeding to the next step.
- At the factory, adjustments were made to achieve proper input and acceptable burner performance at full input and at minimum input.

### 12.3 HEATING BOILER INSTALLATIONS

Before beginning the installation, consult local codes for specific plumbing requirements. The installation should have unions and valves at the inlet and outlet of the appliance so it can be isolated for service. An air separation device must be supplied in the installation piping to eliminate trapped air in the system. Locate a system air vent at the highest point in the system. The system must also have a properly sized expansion tank installed. Typically, an air charged diaphragm-type expansion tank is used. The expansion tank must be installed close to the boiler and on the suction side of the system pump (appliance Inlet) to ensure proper operation. Caution: This appliance should not be operated at less than 12 PSIG cold. Pressure will rise when hot. Expansion tank sizing will determine the pressure when the system is hot. Do not operate the system at less than 18-20 PSIG when hot. Water piping must be supported by suitable hangers or floor stands, NOT by the appliance. Pipe systems will be subject to considerable expansion and contraction.

Pipe supports could allow the pipe to slide resulting in noise transmitted into the system. Padding is recommended. The boiler pressure relief valve must be piped to a suitable floor drain. See Section 4.11.

### 12.4 INSPECT & RECHARGE CONDENSATE COLLECTION/NEUTRALIZING RESERVOIR

- 1) Before starting the unit inspect the condensate reservoir in the DynaMax making sure the collection box is intact.
- 2) Remove screw holding lid on to condensate collection box. Remove lid from the condensate collection box
- 3) Examine neutralizer medium and refill as necessary with fresh medium
- 4) Fill with fresh water until the water begins to flow out of drain
- 5) Re-install the lid and hold-down screw on the condensate collection box.

### WARNING

The condensate collection box must be filled with water to prevent flue gas emissions from escaping during boiler operation.

### CAUTION

A leak in a boiler "System" will cause the fill system to introduce fresh water constantly, which may cause the tubes to accumulate a line/scale build up. Lime/scale buildup leading to heat exchanger failure is **NOT** covered by warranty.

### 12.5 WATER CONNECTIONS

System pipe size must be in accordance with Table 10 (depending on model) and, between supply and return lines, must not exceed 50 feet of equivalent length. Connection sizes at the heater are given in Tables 3 & 5. Any reduction in recommended pipe size may decrease flow resulting in high temperature rise across the heat exchanger, boiler noise, flashing to steam and non-warrantable heat exchanger damage.

### 12.6 PIPING LENGTHS

The appliance circulator provides the water flow from the primary boiler piping, through the boiler and back to the primary system. Pipe diameter and length are critical to ensure proper flow through the boiler. The secondary loop piping to and from the appliance must have a fully ported ball valve installed in both the supply and return side piping and will be used for isolation only. The ball valves must be the same diameter as the installed piping. If flow control is required, other means of flow control such as globe valve or flow setter should be used.

### 12.7 SUMMARY

#### a) Typical Boiler Installations

##### General Plumbing Rules

- 1) Check all local codes.
- 2) For serviceability, always install unions.
- 3) Always pipe pressure relief valve to an open drain.
- 4) Locate system air vents at highest point of system.
- 5) Expansion tank must be installed near the boiler and on the suction side of the system pump.
- 6) Support all water piping.
- 7) Place drip pan underneath boiler. (if required)

## b) Placing the Boiler in Operation

### **Pre-Start Check List**

- 1) Review the location of the boiler, clearances from combustible surfaces and available service clearances.
- 2) Review Part 2 Venting. Ensure that all vent components are fabricated from the correct category of materials with adequate clearance from combustibles. Review the vent termination point for proper location and clearances.
- 3) If a separate combustion air pipe is used, ensure that it is properly sized, sealed and terminated.
- 4) Review the water piping from the boiler to the system. The boiler must be installed in a primary/ secondary piping system. Review the diameter and equivalent length of the installed piping to and from the boiler to ensure proper flow.
- 5) Ensure that a properly sized system pump is installed with an expansion tank.
- 6) Check system pressure. Ensure a minimum of 18-20 PSIG with the system hot and not more than 90% of the rated pressure of the relief valve.
- 7) Review the installed gas piping from the meter to the boiler. Ensure that the gas pipe, meter and any regulators are adequately sized.
- 8) Review the field wiring and electrical service for the boiler controls. Ensure that the electrical service(s) is adequately sized.
- 9) Fill the condensate collector with fresh water until water begins to pour out the drain.
- 10) Ensure that the boiler condensate drain and all vent system condensate drains are properly routed to an acceptable floor drain.

### **Boiler Set-Up**

- 1) Ensure that the boiler and piping system are full of water. Bleed all air from the pump housing and secondary loop.
- 2) Check system for any water leaks.
- 3) Check system for installation of glycol or water treatment where required. Where glycol has been used to maintain the temperature rise across the appliance confirm that the recommended flow for pure water has been increased by 15% and the head loss by 20% while maintaining a 30-35°F rise across the heat exchanger.

### **Boiler Operational Checks**

- 1) Turn the boiler main power switch to the "ON" position.
- 2) Verify operation of the text display on the front panel.
- 3) Program the adjustable points.
- 4) Push the reset button if a manual reset error is displayed.
- 5) Install a manometer on the gas supply to the boiler and verify minimum gas supply pressure as the burner fires at 100% of rated input.
- 6) Verify operation of safeties as necessary (low water cut-off, high limit, gas pressure, etc.).

## **Boiler Operation**

- 1) Appliance should begin the start-up process for the sequence of operation.
- 2) The boiler will fire at approximately 50% of rated input on initial start-up and adjust input as required to meet system demand.
- 3) Based on system demand, the appliance will modulate accordingly.
- 4) As system demand is satisfied, the burner will fire at minimum fire for the given demand and the boiler will cycle off when the demand ceases or is interrupted. When this occurs the combustion air fan will decelerate at a pre-programmed rate before the appliance shuts down.

## **12.8 DOMESTIC HOT WATER WITH STORAGE TANK**

Hot water heaters are designed for installation with a storage tank. The piping between the tank and heater and the control of water velocity, as explained below, are important for correct operation of your hot water heater.

## **12.9 DOMESTIC HOT WATER WITH PLATE HEAT EXCHANGER**

The piping between the plate heat exchanger in the DynaMax boiler and to an outlet tap is important for correct operation of the plate heat exchanger. The following procedure should be followed for setting the domestic hot water tuning valve:

- 1) There is a temperature tuning valve inside the Dynamax jacket on the domestic hot water outlet from plate exchanger. This valve can be set for field conditions.
- 2) First identify the highest domestic hot water load. For example in some cases it may be the bath tub and in some cases it may be the clothes washer.
- 3) Allow the Dynamax to fire up and reach full fire under maximum hot water load demand conditions.
- 4) Observe the outlet water temperature and close the tuning valve gradually as outlet temperature starts to drop. Allow the system to reach equilibrium between adjustments to the tuning valve.
- 5) Once the tuning valve is properly set, outlet temperatures will never drop below desired minimum temperature.
- 6) Seal stem of tuning valve with silicone to prevent unauthorized tampering.



## 12.10 TEMPERATURE RISE AT FULL FIRING RATE

- 1) The pump must run continuously when the burner is firing.
- 2) With the pump running and the burner in the off cycle, the inlet temperature and outlet temperature readings on the DynaMax Control Panel should read approximately the same temperatures.
- 3) Turn the appliance on and allow time for the temperature to stabilize. Check the temperature rise when the burner is firing at 100% of rated input.
- 4) Compare the temperature rise on the Control Panel with the required temperature rise at the required flow rate on Tables 31 and 32.
- 5) Should adjustment be needed, proceed as follows:

**If the temperature rise is too high, the water velocity is too low. Adjust as follows:**

- 1) Check for flow restrictions. Check for debris in strainers
- 2) Check diameter and equivalent length of the piping between the storage tank and hot water heater.
- 3) Be sure the pipes between the hot water heater and storage tank are not more than a total of 50 equivalent feet between supply and return lines. If maximum equivalent length for the specified pipe diameter is exceeded, larger diameter pipe may have to be installed to achieve correct flow and temperature rise.
- 4) Be sure all valves are open between the hot water heater and the storage tank. Ensure that all ball valves are fully ported.
- 5) Check the pump to be sure it is running properly and that the pump motor is running in the proper direction.
- 6) Common manifold piping for multiple unit installations will require larger minimum pipe sizes and tank circulating tapping to ensure proper flow.

The required temperature rise and the recommended pump size are based on the heating of potable water with a hardness of 7.5 to 17.0 grains per gallon and a total dissolved solids not exceeding 300 PPM. Consult the factory when heating potable water exceeding these specifications. Water with a hardness of less than 5 grains per gallon will usually have a low pH which can be aggressive and corrosive causing non-warrantable damage to the heater, pump and associated piping. Refer to Tables 31 and 32 for reference.

**Table 31: Temperature Rise across Heat Exchanger (Hydronic Heating)**

MODEL [BTU/hr]	TEMPERATURE RISE ACROSS HEAT EXCHANGER			
	30°F (16.7°C)		35°F (19.4°F)	
	USGPM	ΔP-Ft.	USGPM	ΔP-Ft.
80,000	5.0	8.2	4.3	6.2
100,000	6.3	12.3	5.4	9.4
150,000	9.5	10.4	8.1	7.8
199,000	12.6	7.2	10.8	5.8
250,000	15.8	11.5	13.5	8.7
299,000	18.9	9.3	16.2	7.0
399,000	25.2	8.4	21.6	6.3
500,000	31.5	9.2	27.0	6.9
600,000	38.8	17.5	32.0	11.8
700,000	45.3	18.2	40.0	14.4
800,000	51.8	23.5	43.0	16.0

**Table 32: Temperature Rise across Heat Exchanger (DHW)**

MODEL [BTU/hr]	TEMPERATURE RISE ACROSS HEAT EXCHANGER	
	20°F (11.1°C)	
	USGPM	ΔP-Ft.
80,000	7.5	11.5
100,000	9.4	26.9
150,000	14.0	27.8
199,000	19.2	25.9
250,000	23.5	28.3
299,000	28.8	25.8
399,000	38.4	23.9
500,000	48.6	29.4
600,000	57.6	34.2
700,000	70.4	40.0
800,000	77.6	43.2

### CAUTION

Temperature rise cannot be adjusted when the burner is firing at less than 100% of input rate.

### CAUTION

Adequate care **MUST** be taken to prevent potential scald injury when storing water at 140°F (60°C) and hotter.

### WARNING

Should overheating occur or the gas supply fail to shut off, do not turn off or disconnect the electrical supply to the pump, instead, shut off the gas supply at a location external to the appliance



## 12.11 SETTING THE CORRECT COMBUSTION

Refer to Section 10.1 Setting the Correct Combustion.

## 12.12 CASCADE SETUP

The following components are needed for a Cascade setup

- 1) DynaMax Ignition Control Board (848-MN)
- 2) DynaMax Text Display (848-RC)
- 3) LabVision Software (recommended)
- 4) 10k $\Omega$  System Sensor

Turn off all the boilers before beginning the setup process.

To setup the DynaMax Cascade system follow the instructions:

### System Sensor

Insert the supplied 10k $\Omega$  system sensor into the return header to the boilers. The wires coming out of the system sensor should be connected to pin#5 and #6 of the green DynaMax terminal board.

### DynaMax Ignition Control Board (848-MN)

The S4 connector as shown in the figure below is to be pushed towards connector J5 on the Master and Slave boiler(s). This step is done by Camus unless the configuration was altered in the field.

**Figure 61: DynaMax Ignition Control Board**




### DynaMax Text Display (848-RC)

The display has 3 Molex Minifit Jr connections at the backside. The single one is to be connected to the DynaMax Ignition Control Board (848-MN). The two other Molex Minifit Jr connectors which are located closer to the switch are used for the Cascade setup.

### Switch Setup

There is a switch located on the backside of the text display. Only the Master Text Display is required to provide power to the Slave boilers, therefore the switch on the backside of the Master display should be in the ON position, and the switch at the Slave displays should be in the OFF position. Figure 59 refers to how the switch is to be placed.

**Figure 62: Text Display Switch Setup**



### Wiring Setup

Refer to Figure 63 for a pictorial description of how to connect the Cascade system together.

### Master Boiler

The following needs to be done to the Master Text Display:

- 1) Connect the "To 848MN control" connector to the DynaMax Ignition Control Board (848-MN). This step was done by Camus unless the display was disconnected in the field.
- 2) Place Switch to the "ON" position
- 3) Connect the "To next display" connector. This connector serves as the communication point to the next boiler. The "To previous display" connector is to be left empty (no connection required)

### Hydronic Heating

- a. Wire system sensor into system sensor input
- b. Attach call for heat/ enable signal to Room Stat connection

### DHW with Tank Sensor

- a. Wire tank sensor into system sensor input

### DHW with Aquastat


- a. Wire aquastat into DHW sensor input
- b. Wire system sensor into system sensor input

### Slave Boiler

The following needs to be done to the Slave Text Display:

- 4) Connect the "To 848MN control" connector to the DynaMax Ignition Control Board (848-MN). This step is done by Camus unless the display was disconnected in the field.
- 5) Place Switch to the "OFF" position
- 6) Connect the "To previous display" connector using the connector from step 3.  
If there are more than 2 boilers (up to 8) continue with step 7.  
If not, Wiring Setup is complete.
- 7) Connect the "To next display" connector. This connector serves as the communication point to the next boiler. When this is done all 3 connectors are used on the back of the text display.

**Figure 63: Text Display Detail**



### **Programming the Cascade Setup**

#### **Master Boiler**

Turn on the DynaMax Master Boiler and wait until the Date and Time to appear.

- 1) Press **[MENU]**
- 2) Select "Appliance Settings" using the **[NEXT]** button and press **[ENTER]**.
- 3) Select "Cascade Control" using the **[NEXT]** button and press **[ENTER]**.
- 4) Enter the PIN Number to gain access. The numbers can be moved up and down using the **[UP]/[DOWN]** keys and press **[ENTER]** to move to the next digit.
- 5) Select "Master Boiler 1" using the **[UP]/[DOWN]** keys and press **[ENTER]** to confirm.
- 6) If a system sensor is used, select Enable System Sensor
- 7) Select the proper Cascade Mode

System	Cascade Mode
Hydronic & DHW	CH&DHW
DHW using a temperature sensor	DHW/SENS
DHW using an aquastat	DHW/STAT

NOTE: When operating in DHW/SENS or DHW/STAT set the CH Mode = 0, and DHW Mode = 0

- 8) Press **[MENU]** until the Date and Time appear on the home screen.
- 9) The home screen should read "System: M1". If not, go through steps 1-5 again.
- 10) The Master boiler is now setup. **DO NOT** turn off the Master Boiler.

#### **Slave Boiler**

Turn on the DynaMax Slave Boiler and wait until the Date and Time to appear.

- 11) Press **[MENU]**
- 12) Select "Appliance Settings" using the **[NEXT]** button and press **[ENTER]**.
- 13) Select "Cascade Control" using the **[NEXT]** button and press **[ENTER]**.
- 14) Enter the PIN Number to gain access. The numbers can be moved up and down using the **[UP]/[DOWN]** keys and press **[ENTER]** to move to the next digit.
- 15) Select "Slave Boiler 2" using the **[UP]/[DOWN]** keys and press **[ENTER]** to confirm. If there are more than 2 boilers (up to 8) continue with step 16. If not, go to step 18.
- 16) Repeat steps 7-10 for the following slave boiler(s)
- 17) Select the next "Slave Boiler" in the sequence. The boilers must be addressed in sequential order. That is, the Master Boiler is addressed as 1 the first Slave Boiler is addressed as 2, the next Slave Boiler is addressed as 3 etc.
- 18) Press **[MENU]** until the Date and Time appear on the home screen.
- 19) The home screen should read "System: S2". The third boiler in this series will be S3 and so on. If not, go through steps 11-15 again.
- 20) Programming is complete. **DO NOT** turn off the Slave Boiler.

### **12.13 INTERFACE MODULE (if equipped)**


The DynaMax Interface Module comes complete with:

- 0-10Vdc External Input
- Alarm Output
- Modbus Communication
- External Reset

#### **Wiring Setup**

Refer to Figure 66 and 67 for a pictorial description of how to connect the Interface module.


**Figure 64: Text Display Detail**




#### **Switch Setup**

There is a switch located on the backside of the text display. Only the Master Text Display is required to provide power to the Slave boilers, therefore the switch on the backside of the Master display should be in the ON position, and the switch at the Slave displays should be in the OFF position. Figure 65 refers to how the switch is to be placed.


**Figure 65: Text Display Switch Setup**



**Figure 66: Standalone boiler with Modbus Interface**



**Figure 67: Cascade boilers with Modbus Interface**



Modbus communicates using words (the contents of 16-bit holding registers). The data that is offered by the 848IF is organized as a list of bytes. Table 33 shows the parameters available for reading and their addresses.

**NOTE:** The toggle switch located on the 848IF must be pushed towards the red/white stripped wires.

**Table 33: Modbus Read Only Registers**

Read Only Registers							
Item Index		Parameter Name	DM Link device and holding registers				
Word	Byte		MN (100)	RC Standalone (200)	RC Cascade Master 1 (201)	...	RC Cascade Slave 8 (208)
0 High Byte	0	STATE	0x0000	0x0010	0x0020	...	0x0090
0 Low Byte	1	STATUS	0x0000	0x0010	0x0020	...	0x0090
2 High Byte	2	ERROR_NUMBER	0x0002	0x0012	0x0022	...	0x0092
2 Low Byte	3	SYSTEM_TEST	0x0002	0x0012	0x0022	...	0x0092
4 High Byte	4	Supply Temp	0x0004	0x0014	0x0024	...	0x0094
4 Low Byte	5	RETURN_TEMP	0x0004	0x0014	0x0024	...	0x0094
6 High Byte	6	DHW_TEMP	0x0006	0x0016	0x0026	...	0x0096
6 Low Byte	7	FLUE_TEMP	0x0006	0x0016	0x0026	...	0x0096
8 High Byte	8	FLAGS (RT and SWL)	0x0008				
8 Low Byte	9	RAM_CH_SETP_OINT	0x0008				
10 High Byte	10	APPLIANCE_TYPE	0x000A				
10 Low Byte	11	CONTROL_CONFIG_BYTE	0x000A				
12 High Byte	12	CH_MODE	0x000C				
12 Low Byte	13	DHW_MODE	0x000C				
14 High Byte	14	CH_SETPOINT	0x000E				
14 Low Byte	15	DHW_SETPOINT	0x000E				

The low byte of the word contains possible values of the Status parameter.

**Table 34: Ignition Module Status**

MN STATUS			
STATUS		State Name	Description
Dec.	Hex		
0	0x00	STANDBY	Standby (Waiting for demand)
14	0x0E	BLOCK	Error Handling
10	0x0A	ALARM	Error Handling
15	0x0F	FROST_PROTECT	Frost Protection Handling
16	0x10	CH	Central Heating Demand
17	0x11	RESET_STATE	Initializing
18	0x12	STORAGE	Storage Tank Demand
19	0x13	TAP	DHW Demand (Combination Models)
20	0x14	PRE_HEAT	Pre-Heat Demand (Combination Models)
21	0x15	STORE_WARM_HOLD	Pre-Heat Demand (Storage Tank)

The high byte of that word contains possible values of the State parameter.

**Table 35: Ignition Module State**

Ignition Module States			
STATE		State Name	Description
Dec.	Hex		
0	0x00	RESET_0	Initializing
1	0x01	RESET_1	Initializing
2	0x02	STANDBY_0	Standby (Waiting for demand)
3	0x03	SAFETY_ON	Initiating boiler demand
4	0x04	SAFETY_OFF	Initiating boiler demand
5	0x05	PRE_PURGE	Initiating boiler demand
6	0x06	PRE_PURGE_1	Initiating boiler demand
7	0x07	IGNIT_0	Initiating boiler demand
8	0x08	IGNIT_1	Initiating boiler demand
9	0x09	BURN_0	Handle boiler demand
10	0x0A	POST_PURGE_0	Ending boiler demand
11	0x0B	POST_PURGE_1	Ending boiler demand
12	0x0C	PUMP_CH_0	Handling CH demand without boiler demand
13	0x0D	PUMP_CH_1	Post Pump after CH demand
14	0x0E	PUMP_HW_0	Handling DHW demand without boiler demand
15	0x0F	PUMP_HW_1	Post Pump after DHW demand
16	0x10	ALARM_1	Error Handling
17	0x11	ERROR_CHECK	Error Handling
18	0x12	BURNER_BOOT	Controller Restart
19	0x13	CLEAR_E2PROM_ERROR	Error Handling
20	0x14	STORE_BLOCK_ERROR	Error Handling
21	0x15	WAIT_A_SECOND	Error Handling

**Table 36: Manual Reset Error**

Manual Reset Errors	Decimal	Hex	Description
E2PROM_READ_ERROR	0	0	No communication with E2Prom
IGNIT_ERROR	1	1	Three unsuccessful ignition attempts in a row
GV_RELAY_ERROR	5	5	Problems with Gas Valve Relay = Internal Hardware Error
SAFETY_RELAY_ERROR	6	6	Problems with Safety Relay = Internal Hardware Error
SPARE_LOCK_ERROR_1A	7	7	
FAN_ERROR	8	8	Minimum fan speed < 1500 RPM, Modulation signal not recognized
RAM_ERROR	9	9	Internal software error
WRONG_EEPROM_SIGNATURE	10	A	Contents of E2Prom are not up to date
E2PROM_ERROR	12	C	No communication with E2Prom
STATE_ERROR	13	D	Internal software error
ROM_ERROR	14	E	Internal software error
15MS_XRL_ERROR	16	10	Internal software error
SPARE_LOCK_ERROR_1D	17	11	
T_MAX_LOCK_ERROR	18	12	High Limit tripped
STACK_ERROR	19	13	Stack Limit tripped
FLAME_OUT_TOO_LATE_ERROR	20	14	Flame still present 10 sec. after closing the gas valve
FLAME_ERROR_1	21	15	Flame detected just before gas valve opened
20MS_XRL_ERROR	22	16	Internal software error
41MS_ERROR	23	17	Internal software error
TOO_MANY_FLAME_FAILURES	24	18	Three times flame lost during one demand
FLAG_BYTE_INTEGRITY_ERROR	27	1B	Internal software error
AD_HI_CPL_ERROR	28	1C	Internal software error
AD_LO_CPL_ERROR	29	1D	Internal software error

**Table 37: Automatic Reset Errors**

Automatic Reset Errors	Decimal	Hex	Description
REFHI_TOO_LO_ERROR	31	1F	Internal hardware error
REFHI_TOO_HI_ERROR	32	20	Internal hardware error
REFLO_TOO_LO_ERROR	33	21	Internal hardware error
REFLO_TOO_HI_ERROR	34	22	Internal hardware error
FLAME_ERROR_2	36	24	False Flame detected
RETURN_TEMP_ERROR	40	28	Return temperature exceeded 185oF
WD_50HZ_ERROR	43	2B	No ground connection, or internal hardware error
PHASE_ERROR	44	2C	Line and Neutral wires are interchanged
NET_FREQ_ERROR	45	2D	Line frequency differs by more than 2% for 60Hz
FAULTY_EARTH_ERROR	46	2E	Ground connection fault
WD_COMMUNICATION_ERROR	47	2F	Internal hardware error
APPLIANCE_SELECTION_ERROR	48	30	Appliance selection code and resistor do not match upon startup
T_SUPPLY_OPEN	51	33	Supply sensor not connected
T_RETURN_OPEN	52	34	Return sensor not connected
T_DHW_OUT_OPEN	55	37	DHW sensor not connected
T_SYSTEM_OPEN	56	38	System sensor not connected
T_FLUE_OPEN	57	39	Flue sensor not connected
T_SUPPLY_SHORTED	59	3B	Supply sensor shorted
T_RETURN_SHORTED	60	3C	Return sensor shorted
T_DHW_OUT_SHORTED	63	3F	DHW sensor shorted
T_SYSTEM_SHORTED	54	40	System sensor shorted
T_FLUE_SHORTED	65	41	Flue sensor shorted
BLOCKED_FLUE_ERROR	66	42	Blocked Flue condition
FLOW_SWITCH_NOT_OPEN_ERROR	67	43	Flow switch not open
FLOW_SWITCH_NOT_CLOSED_ERROR	68	44	Flow switch not closed

## 12.14 Write Functionality

The DynaMax Ignition module may be only reset when it is in error. Only manual reset errors can be reset by writing 0x4000 to the *Reset & R/W control* holding register (0x001A) of the Modbus interface (this sets the MN reset bit of the *Reset & R/W control* holding register) The 848IF then sends a reset command to the DynaMax Ignition Module over the established link.

The *Reset & R/W control* register of the MN (0x001A) also controls the reading and writing of the DynaMax Ignition Module holding registers. Each bit of the *Reset & R/W control* register corresponds with one parameter of the Read/Write holding registers table. When a bit in the *Reset & R/W control* is clear the data in the corresponding holding register byte is fetched from the DynaMax Ignition Module into the 848IF. When a bit in the *Reset & R/W control* register is set the data in the corresponding holding register byte is sent from the IF to the MN. To set an RC parameter through Modbus first set its bit in the *Reset & R/W control* register. This stops the parameter being fetched from the MN. Then write the desired value into the parameters holding register. The following table lists the *Reset & R/W control* bits and corresponding parameters.

**Table 38: Modbus Read/Write Registers**

Read/Write Holding Registers			
Item Index		Parameter Name	Holding Registers
Word	Byte		
10 High Byte	10	Reset & R/W Control	0x001A
10 Low Byte	11	Reset & R/W Control	0x001A
14 High Byte	14	CH_Setpoint	0x001E
14 Low Byte	15	DHW_Setpoint	0x001E

Reset & R/W control bits				
R/W control register	bit	MN_Parameter Name	Byte	Holding Register
0x001A Low byte	0	DHW_Setpoint	15	0x001E Low byte
0x001A Low byte	1	CH_Setpoint	14	0x001E High byte
0x001A High byte	14	MN Reset bit		

### 12.14.1 Write CH Setpoint

- 1) Issue a Modbus write single holding register command writing 0x0002 to the *Reset & R/W control* register located at 0x001A to switch from CH set point reading to writing
- 2) Calculate the scaled set point =  $((x - 32) / 1.8) + 10$  \* 2 \* 256
- 3) Issue a Modbus write single holding register command writing the scaled calculated set point to the 0x001E holding register



### 12.14.2 Write DHW Setpoint

- 1) Issue a Modbus write single holding register command writing 0x001 to the *Reset & R/W Control* register located at 0x001A to switch from DHW set point reading to writing
- 2) Calculate the scaled set point =  $((x-32)/1.8)+10$ \*2
- 3) Issue a Modbus write single holding register command writing the scaled and calculated set point to the 0x001E holding register

#### NOTE

- Be advised that whenever the MN control is reset, it will revert back to the setpoints stored in the E2Prom. After every MN reset (automatic, through Modbus, via the IF External Reset Input or via the RC reset button) the Modbus controller must make sure that the error condition has been resolved (ERROR\_NUMBER = 0xFF) and then re-write the desired setpoints through Modbus
- If the *Reset & R/W control* register bit of a setpoint is set, the setpoint in the IF is communicated with the MN as long as it differs from the setpoint in the DynaMax Ignition Module. If the setpoint is then changed by means of the Display or LabVision it will again be different from the setpoint in the IF and thus, again be overwritten by the setpoint in the IF. As long as the *Reset & R/W control* register bit of the setpoint is set the IF overrules all other setpoint settings. Clear the bit in the *Reset & R/W Control* register to re-enable setting of the setpoint by RC or LabVision
- When no Modbus communication (reading or writing) is sensed for more than 4.25 seconds the *R/W control* register bits will be reset. The *R/W control* register bits will be reset. The *R/W control* register bits will also be reset when undefined bits (ie. other than bits 0 and 1) are set.
- In a cascade system only the setpoints of the MN board connected directly to the IF board can be controlled.

### 12.15 Alarm Output (if equipped)

This is a feature that is offered on the 848IF. An alarm output is available to signal was sensed in the connected heating system. Once an alarm is signalled by the alarm output it can be reset by means of the External Reset Input.

The alarm output is a normally open, dry contact/ potential free output. If an error is sensed in one of the attached boilers the Alarm output contact closes. The output can be used to drive an external device such as a lamp, a buzzer, a PLC or a building management system. Refer to 15.3 848IF Interface Module Wiring Schematic for complete wiring details.

The IF code scans its Modbus holding registers (0x0000, 0x0010...0x0090) for a STATE that is not equal to zero. If a state not equal to 0 (zero) is found the IF subsequently checks for an ERROR\_NUMBER not equal to 0xFF to see if this device is in error. If so, the alarm relay is energized and the alarm output contact closes.

The alarm output functionality can be used even if Modbus communication is non-existent.

Due to communication latency it can take several minutes for the Alarm output to reflect the state of any of the connected boilers. Especially in a cascade system and/or when LabVision is connected.

### 12.16 External Reset (if equipped)

The external reset can be controlled by a relay or pushbutton.

If the input is open the resetting of an error is an enabled. Once an error is signalled by the alarm output it can be reset by shorting the external reset input to 0V. A reset command is then sent over to the DynaMax Ignition Module and the external reset is disabled until the input is open again. Refer to 15.3 848IF Interface Module Wiring Schematic for complete wiring details.

### 12.17 0-10Vdc External Input (if equipped)

An analog input can be used to control the CH or the DHW set point. The input can handle input voltages of up to 10Vdc. A resistor of 500Ω may be added to obtain a 0-10Vdc input from a 4-20mA signal. Refer to 15.3 848IF Interface Module Wiring Schematic for complete wiring details.

The analog input setting screen is shown below in LabVision:

Figure 68: Analog Input Parameters




Table 39: Analog Input Selection

ANLG_IN_MODE Configuration		
Mode	Name	Description
0	Off	Analog Input not Enabled
1	CH Setpoint Setting	Analog input controls the CH set point
2	DHW Setpoint Setting	Analog input controls the DHW set point

Table 40: Analog Input Setpoints

ANLG_IN_MODE Configuration		
Input Voltage [Vdc]	Input Current [mA]	CH Setpoint/ DHW Setpoint
0	0	Analog Input not enabled
2	4	41°F
.	.	.
10	20	194°F



The ANLG\_IN\_ENABLE parameter determines whether the analog input is enabled or disabled. The ANLG\_IN\_ENABLE parameter is set to 'False', analog input is disabled, under the following circumstances

- When the ANLG\_IN\_MODE is set to 0 (off)
- When the input voltage is less than 2V
- From the moment a Modbus write command is detected until 4.25 minutes after the last Modbus write command was ended. Modbus set point setting has priority over the Analog input set point setting

**NOTE**

- During commissioning (and when altering the ANLG\_IN\_MODE setting) the setpoint that is not controlled by the analog (or Modbus) must be checked/ set manually after setting the mode
- If the Analog input is not connected (open) the default input voltage is 2.5V. If the analog input is not to be used it must be disabled by setting ANLG\_IN\_MODE to 0.
- The analog input and Modbus connection can be used simultaneously but when the Modbus connection is used to set the setpoint the analog input is disabled.
- In a cascade system only the setpoints of the MN board connected directly to the IF board can be controlled.

## 12.18 APPLIANCE

- \* Remove manometers and tighten test port screws.
- \* Fill out start up report for each heater. Be sure to record all settings and readings. Retain a copy of report for future reference.
- \* Start up is now complete and heater may be placed into service.

## 12.19 IGNITION CYCLE

The ignition cycle is shown in the table below. The values are the default factory settings.

**Table 41: DynaMax Ignition Cycle**

State →	Standby	Pre Purge	Safety ON	Safety OFF <sup>6</sup>	Ignit_0	Ignit_1	Burn	Post Purge_0
Time	0s	5s after fan speed is within 600 rpm			2 sec	6 sec	Limited to 24 hours continuously <sup>3</sup>	Min. 30 sec
Demand	0	No influence	No influence	No influence	No influence	No influence	> 0	No influence
Fan	Off	Ignition speed	Ignition speed	Ignition speed	Ignition speed	Ignition speed	Requested power	Ignition speed
Gasvalve	Closed	Closed	Closed	Closed	Closed	Open	Open	Closed
Spark	Off	Off	Off	Off	On	On <sup>4</sup>	Off	Off
Ionisation	0	0	0	0	0 <sup>1</sup>	Flame must be detected <sup>2</sup>	Flame must be detected	No flame must be detected <sup>5</sup>

Note:

1. If a flame signal is detected at the end of the pre-spark period (Ignit\_0) then a lockout will occur.
  2. If at the end of the safety period (6 sec) no flame is detected the control will go to post-purge to remove the unburned gas. After this a re-ignition attempt is started following the same cycle. The number of re-ignition attempts is limited to 2 after which a lockout occurs.
  3. The burner can only be on continuously for a period of 24 hours. After this the burner is switched off and a restart sequence follows.
  4. Sparking stops 2 seconds before the end of the Ignit\_1 period to allow for ionisation detection when measuring ionisation through the spark plug.
  5. If after post\_purge\_0 time (max. 10 sec.) still flame is detected lockout follows
  6. Safety ON/OFF in this state the correct working of the safety relay is proved.
- If the ignition cycle is started it will continue until completion, even if the demand is removed.

## PART 13 PIPING DIAGRAMS


**Figure 69: Single Boiler Hydronic Heating Zoned Piping Arrangement**

This piping arrangement is designed for:

Central Heating Mode: 0, 1, 2, or 3

DHW Mode: 0

Boiler Address: 100




**Figure 70: Single Combination Boiler Zoned Piping Arrangement**

Central Heating Mode: 0, 1, 2, or 3

DHW Mode: 4

Boiler Address: Boiler Address = 100



Note:


- 1) Size main header to minimize induced flow through zones
- 2) Separate boiler loop as shown is recommended for system piping greater than 50 equivalent feet.

**Figure 71: Single Boiler Hydronic Heating & Indirect Storage Tank Zoned Piping Arrangement**

Central Heating Mode: 0, 1, 2, or 3

DHW Mode: 1, or 2

Boiler Address: Boiler Address = 100



**Note:**


- 1) Size main header to minimize induced flow through zones
- 2) Separate boiler loop as shown is recommended for system piping greater than 50 equivalent feet.

**Figure 73: Single Boiler Hydronic Heating & Direct Storage Tank Zoned Piping Arrangement**

Central Heating Mode: 0

DHW Mode: 1 or 2

Boiler Address: Boiler Address = 100






**Figure 74: Multiple Boiler Hydronic Heating Zoned Piping Arrangement**

Central Heating Mode: 0, 1, 2, 3


DHW Mode: 0

Boiler Address: Master Boiler Address = Master Boiler 1 (M1)  
Slave Boiler Address = Slave Boiler 2 (S2)




## PART 14 EXPLODED VIEW & PARTS LIST

### DYNAMAX WALL HUNG



**DYNAMAX FLOOR MOUNT**



Ref #	Name of Part	Part ID	DynaMax Models													
			ALL	80	100	150	200	210	250	260	299	399	500	600	700	800
1	Heat Exchanger	4 + 1 Wall		X	X											
		5 + 2 Wall				X										
		8 + 4 Wall					X		X							
		8 + 4 Floor						X		X						
		10 + 6 Floor									X					
		15 + 8 Floor										X				
		18 + 10 Floor											X			
		21 + 11 Floor												X		
		24 + 12 Floor													X	
2	Burner	80,000 BTU		X												X
		100,000 BTU			X											
		150,000 BTU				X										
		199,000 BTU					X	X								
		250,000 BTU							X	X						
		299,000 BTU									X					
		399,000 BTU										X				
		500,000 BTU											X			
		600,000 BTU												X		
		750,000 BTU													X	
		800,000 BTU														X
3	Heat Exchanger Flange	GM20-65-028-01		X	X	X										
		GM20-65-033-01					X	X	X	X	X	X	X			
4	Heat Exchanger Flange Nuts	GM10-05-012	X													
5	<b>Igniter</b>	GM10-35-108-01		X	X	X	X	X	X	X	X	X	X			
		GM10-35-161-01												X	X	X
6	<b>Flame Sensor</b>	GM10-35-109-01		X	X	X	X	X	X	X	X	X	X			
		GM10-25-104												X	X	X
7	Igniter/Flame Sensor Screws	GM10-05-020	X													
8	<b>DynaMax Controller</b>	848MN	X													
9	<b>DynaMax Display</b>	848RC	X													
10	Condensate Neutralizer Box	15-6010	X													
11	Combustion Fan	55667.11221		X	X											
		55667.21120				X										
		55667.21080					X	X	X	X						
		55667.21200									X	X				
		55667.14002											X			
		G1G 170												X	X	X
12	Venturi	459000-444-003		X	X											
		459000-444-001				X										
		459000-446-051					X	X	X	X						
		45900450-010									X					
		45900450-020										X				
		VMU300A1046											X	X	X	X
13	Gas Valve	VK8115V1341		X	X	X	X	X	X	X						
		VR8615VB1044									X	X				
		V8730V1015											X			
		V8730C1023												X	X	X

Ref #	Name of Part	Part ID	DynaMax Models													
			ALL	80	100	150	200	210	250	260	299	399	500	600	700	800
14	Hydronic Heating/Combination Pump	Astro 30		X	X											
		Astro 50				X	X	X								
		PL30							X	X	X					
		PL36										X	X	X		
		E30													X	X
		Star 16		X	X											
		Star 21				X										
		Star 30F					X	X	X	X	X					
		Star 17										X				
		TOP S 1.25x25											X			
		TOP S 1.25x35												X		
		TOP S 1.5x20													X	
		TOP S 1.5x30														X
	DHW Pump	E7B		X	X											
		E9B				X	X	X	X	X						
		E12B									X	X				
		E33B											X			
		4360-1.25B												X	X	X
		Star 16 BFX		X												
		Star 30 BU			X											
		TOP S 1.5x20B				X										
		TOP S 1.5x30B					X	X			X	X				
		TOP S 1.5x40B							X	X			X			
		TOP S 2x50B												X	X	X
15	Mixing Chamber	GM20-70-011		X	X	X										
		GM20-70-020-01					X	X	X	X	X	X				
		14-5540												X	X	X
16	Air Pressure Switch	8021205256	X													
17	3-Way Valve Actuator	VC4011ZZ02/E		X	X	X	X	X	X	X	X					
		ML8115B1004										X	X	X	X	X
	3-Way Valve Body	VCZMR6100/E		X	X	X	X	X	X	X						
		VCZND6100/U									X					
		VBN3EM3POX										X	X			
		VBN3FP3POX												X	X	X
18	High Limit	TCL 110A (CPVC, AL29-4C, SS)	X													
		TCL 085A (PVC)	X													
19	¼ Turn Lock	Wall Hung	X													
		Floor Mount	X													
20	Wall Mount Back Panel	14-5402		X	X	X										
		14-5402-250					X		X							
21	Wall Mount Front Bottom Wrap	14-5403		X	X	X										
		14-5403-250					X		X							
22	Front Upper Wrap	14-5404		X	X	X										
		14-5404-250					X		X							



Ref #	Name of Part	Part ID	DynaMax Models													
			ALL	80	100	150	200	210	250	260	299	399	500	600	700	800
23	Restrain	14-5405		X	X	X	X		X							
24	Mounting Bracket	14-5406		X	X	X	X		X							
25	Lower Bracket	14-5407		X	X	X	X		X							
26	Wall Top Bracket	14-5408		X	X	X	X		X							
27	Support Frame Assembly	14-5409		X	X	X										
		14-5409-250					X		X							
28	Bracket Front	14-5410		X	X	X	X		X							
29	Rear Bracket	14-5411		X	X	X	X		X							
30	Bezel Stiffener Plate	14-5412		X	X	X	X		X							
31	Controller Plate	14-5413		X	X	X	X		X							
32	Electrical Conduit Plate	14-5415		X	X	X										
		14-5415-250					X		X							
33	Electrical Strip Plate	14-5416		X	X	X	X		X							
34	Plastic Bezel	15-6001-A		X	X	X	X		X							
35	Bracket for Neutralizer Box	14-5419		X	X	X	X		X							
36	Air Inlet/ Vent Adapter	FSA-HEX03		X	X	X	X	X	X	X	X	X				
37	Plate Heat Exchanger (Combination Models ONLY)	LB31-20X		X	X	X										
		LB31-40X					X	X	X	X	X	X	X			
38	DynaMax Floor Front Panel	14-5501-20-25						X		X						
		14-5501									X	X	X	X	X	X
39	DynaMax Floor Base Panel	14-5502						X		X	X	X	X			
		14-5502-60-75												X	X	X
41	Floor Back Panel	14-5504-20-25						X		X						
		14-5504									X	X	X			
		14-5504-60-75												X	X	X
42	Top Cover Back	14-5505						X		X	X	X	X			
		14-5505-60-75												X	X	X
43	Side Panel Right	14-5506-20-25						X		X						
		14-5506									X	X	X			
		14-5506-60-75												X	X	X
44	Side Panel Left	14-5507-20-25						X		X						
		14-5507									X	X	X			
		14-5507-60-75												X	X	X
45	Front Panel Bottom	14-5508						X		X	X	X	X	X	X	X
46	Side Panel Left Front	14-5509-20-25						X		X						
		14-5509									X	X	X	X	X	X
47	Control Panel Plate	14-5510						X		X	X	X	X	X	X	X
48	HX Support Frame	14-5511									X	X	X			
		14-5511-60-75												X	X	X



Ref #	Name of Part	Part ID	DynaMax Models													
			ALL	80	100	150	200	210	250	260	299	399	500	600	700	800
49	Support Plate	14-5512						X		X	X	X	X	X	X	X
50	Bracket Right	14-5513-20-25						X		X						
		14-5513						X		X	X	X	X	X	X	X
51	Stand Off Left	14-5514						X		X	X	X	X	X	X	X
52	Stand Off Right	14-5515						X		X	X	X	X	X	X	X
53	Support Leg	14-5516						X		X	X	X	X			
		14-5516-60-75												X	X	X
54	Stiffener under Leg	14-5517						X		X	X	X	X	X	X	X
		14-5517-60-75												X	X	X
55	Floor Bracket Left	14-5518-20-25						X		X						
		14-5518									X	X	X	X	X	X
56	Floor Rear Bracket	14-5520-20-25						X		X						
		14-5520						X		X	X	X	X	X	X	X
57	Top Cover Assembly	14-5521						X		X	X	X	X	X	X	X
58	Dashboard	15-6002-A						X		X	X	X	X	X	X	X
59	Bracket for Neutralizer Box	14-5525						X		X	X	X	X	X	X	X
60	Rubber Bushing	33-0101		X	X	X	X	X	X	X						
62	Condensate Pan Brace	14-5417		X	X	X	X		X							
63	Cover Plate	14-5421		X	X	X										
		14-5421-250					X		X							
64	Standoff	14-5423	X													
66	Electrical Strip Plate Protector	14-5420	X													
67	Air Intake Adapter with Pressure Port	44-0008		X	X	X	X		X							
68	Plastic Flange with 3" Street Elbow	44-0009											X			
	4" Air Intake Box	14-5551												X	X	
	5" Air Intake Box	14-5546														X
69	3" Air Intake Adapter	44-0010											X			
	4" Air Intake Adapter	14-5559												X	X	
	5" Air Intake Adapter	14-5556														X
70	Condensate Pan	14-5418		X	X											
		14-5414				X										
		14-5414-250					X		X							
71	Condensate Pan Brace	14-5417		X	X	X										
		14-5417-250					X		X							
72	Plate Heat Exchanger Bracket	14-5424		X	X	X										
		14-5424-200					X		X							



Ref #	Name of Part	Part ID	DynaMax Models													
			ALL	80	100	150	200	210	250	260	299	399	500	600	700	800
73	Transformer Mounting Plate	14-5541		X	X	X	X		X							
70	<b>Igniter Gasket</b>	GM10-25-018	X													
71	<b>Flame Sensor Gasket</b>	GM10-25-004	X													
72	Burner Refractory	GM10-25-098-01		X	X	X										
		GM10-25-107					X	X	X	X	X	X	X	X	X	X
73	Automatic Air Vent	FV-4M1	X													
74	Terminal Board	TB-001.001	X													
75	On/Off Switch	C6000ALBBXCHLI	X													
76	40VA Transformer	HCT-01E0BB06	X													
77	<b>Supply/Return Sensor</b>	NTC-SENSOR-002	X													
78	<b>Flue Sensor</b>	NTC-SENSOR-003	X													
79	<b>Outdoor Sensor</b>	NTC-SENSOR-004	X													
79	<b>Sensor Wire</b>	CABLE HARNESS	X													
80	<b>DHW Sensor</b>	NTC-SENSOR-001	X													
82	Gas Valve Elbow	45900400-132/B		X	X	X	X	X	X	X						
		45900400-144/B									X	X				
83	Gas Valve Wire Harness	45900441-015B		X	X	X										
		45900429-007B					X	X	X	X	X	X				
84	Relief Valve	10-407-05		X	X	X	X	X	X	X						
		10-604-10									X	X	X			
85	Wiring Harness	77-0004		X	X	X	X		X							
		77-0006						X		X	X	X	X	X	X	X
87	1/2" Firing Valve	USA0509101T		X	X	X	X		X							
88	DynaMax Fan Discharge Orifice	14-0377-80		X	X											
		14-0377-100				X										
89	Expandable Air Inlet Adapter w/o Pressure Test Point	14-0378		X	X	X	X		X							
90	Expandable Air Inlet Adapter	14-0379		X	X	X	X		X							
91	Flex Pipe	2" Diameter		X	X	X	X	X	X	X	X	X				
		3" Diameter											X			
		4" Diameter												X	X	
		5" Diameter														X
92	Flexible Stainless Steel Pipe 1" X 11"	66-0075	X													
93	Flexible Stainless Steel Pipe 1/2" X 11"	66-0073	X													
94	Manual Shutoff Valve Kit	50002653-001	X													

Ref #	Name of Part	Part ID	DynaMax Models													
			ALL	80	100	150	200	210	250	260	299	399	500	600	700	800
95	Rear Vent Adapter	GM10-15-991-01						X		X						
		GM10-15-992-01									X	X	X			
96	Metal Latch	6521-00-0551-YT						X		X	X	X	X	X	X	X
97	Strike	7800-02						X		X	X	X	X	X	X	X
98	Interface Module	848IF	X													
99	Plastic to Stainless Steel Vent Adapter	300566		X	X	X	X	X	X	X						
		300611									X	X	X			
	Stainless to Plastic Vent Adapter	303504												X		
		300537													X	X
100	Rubber Air Sleeve	1056-22		X	X	X	X	X	X	X	X	X				
		1056-33											X			
		1056-44												X	X	
		1056-55														X
101	<b>Burner Gasket</b>	GM10-25-074-09		X	X	X	X	X	X	X	X	X	X			
102	Fan Gasket	33-0037		X	X	X	X	X	X	X	X	X				
		33-0038											X			
		33-0043												X	X	X




Not shown in Exploded View  
Recommended spare parts

**Part**


# PART 15 ELECTRICAL DIAGRAMS

## 15.1 DM 80- 250 INTERNAL WIRING DIAGRAM (WALL HUNG MODELS)





## 15.3 848IF Interface Module Wiring Schematic





## 15.4 FIELD WIRING

### 15.4.1 System Sensor

The temperature of the primary return can be controlled by installing a system sensor. The system sensor must be used in all Cascade modes, and must be enabled through the DynaMax controller or through LabVision.


### 15.4.2 Cascade Setup

To setup a cascade system a Master boiler must be chosen, and the other boilers connected to it in this system are designated as Slaves.

Connect the system sensor and outdoor sensor (if equipped) to the Master boiler. The Master boiler will use the water temperature in the primary loop to control the operation of the cascade setup. The location of the system sensor should be installed downstream of all the zones in the primary loop. The system sensor is wired into the DynaMax Terminal board as shown in the diagram below.

If outdoor reset is desired, the outdoor sensor needs to be connected to the Outdoor Sensor location on the DynaMax Terminal Board. When the outdoor sensor is connected to the Master boiler, the DynaMax Controller will recognize this automatically and the Master will calculate the water temperature set point based on the Ch\_Setpoint Curve. If the outdoor sensor is not connected to the Master boiler the DynaMax Controller will maintain a fixed water temperature that is programmed into the control.

If a Zone Thermostat is available, it needs to be connected to the Room Thermostat terminals on the DynaMax Terminal Board. If the boiler is required to run continuously a jumper cable can be placed between the '5' and '6' contacts, this will then force a call for heat on the cascade setup.



## 15.5 DETAILED CONNECTOR DESCRIPTION

Connector	Pin #	Connector Description
<b>J2</b>		Provides 120VAC to the DynaMax Controller
	1	Earth/ Ground
	2	120VAC Neutral
	3	120VAC Live
<b>J6</b>		3-Way Diverter Valve
	1	DHW 120VAC Live
	2	CH 120VAC Live
	3	120VAC Neutral
<b>J7</b>		On-Board Pump
	1	Not Used
	2	Pump 120VAC Neutral
	3	Not Used
	4	Not Used
	5	Pump 120VAC Live
<b>J13</b>		High-Limit, Gas Valve, Flame Sensor
	1	120VAC Ground
	2	Flame Sensor
	3	Gas Valve 120VAC Neutral
	4	Gas Valve 120VAC Live
	5	High-Limit Safety
	6	
<b>J9</b>		Fan Power, Fan Modulation
	1	Fan 120VAC Earth/ Ground
	2	Fan 120VAC Live
	3	Fan 120VAC Neutral
	4	Fan Signal +
	5	Fan Hall Effect Signal
	6	Fan Pulse Width Modulation (PWM) Signal
	7	Fan Signal -
<b>J16</b>		Various Sensors
	1	Flow Switch
	2	Air Switch
	3	Flow Switch
	4	Air Switch
	5	Not Used
	6	Not Used
	7	Not Used
	8	Not Used

Connector	Pin #	Connector Description
<b>J5</b>		Various Sensors
	1	Room Thermostat, 24VAC
	2	Control Panel, +
	3	Supply/Outlet Sensor
	4	Return/Inlet Sensor
	5	DHW Sensor/ Tank Stat
	6	Flue/Stack Sensor
	7	System Sensor
	8	Outdoor Sensor
	9	Room Thermostat, 24VAC
	10	Control Panel, -
	11	Supply/Outlet Sensor
	12	Return/Inlet Sensor
	13	DHW Sensor/ Tank Stat
	14	Flue/Stack Sensor
	15	System Sensor
	16	Outdoor Sensor
<b>J12</b>		Spark Return Signal
<b>T2</b>		Spark Igniter
<b>F1</b>		3.15A Fuse



## **CONDENSING BOILER LIMITED WARRANTY**

Camus Hydronics Limited ("Camus") extends the following LIMITED WARRANTY to the owner of this appliance, provided that the product has been installed and operated in accordance with the Installation Manual provided with the equipment. Camus will furnish a replacement for, or at Camus option repair, any part that within the period specified below, shall fail in normal use and service at its original installation location due to any defect in workmanship, material or design. The repaired or replacement part will be warranted for only the unexpired portion of the original warranty.

### **THIS LIMITED WARRANTY DOES NOT COVER**

1. Failure to properly install, operate or maintain the equipment in accordance with Camus' manual
2. Abuse, alteration, accident, fire, flood, foundation problems and the like
3. Sediment or lime build-up, freezing, or other conditions causing inadequate water circulation
4. Pitting and erosion caused by high water velocity;
5. Failure of connected systems devices, such as pump or controller
6. Use of non-factory authorized accessories or other components in conjunction with the system;
7. Failing to eliminate air from, or replenish water in, the connected water system
8. Chemical contamination of combustion air or use of chemical additives to water
9. Production of noise, odours, discolouration or rusty water
10. Damage to surroundings or property caused by leakage or malfunction
11. All labour costs associated with the replacement and/or repair of the unit
12. Any failed component of the hydronic system not manufactured as part of the boiler.

### **HEAT EXCHANGER**

If within TWELVE years after initial installation of the appliance, a heat exchanger shall prove upon examination by Camus to be defective in material, thermal shock, leakage or workmanship, Camus will exchange or repair such part or portion on the following pro rated limited warranty

Years into Warranty	% of List Price
8	30
9	40
10	50
11	60
12	70

This term is reduced to SIX years if the appliance is used for other than hydronic space heating. Heat Exchanger shall be warranted for (20) years from date of installation against "Thermal Shock" (excluded, however, if caused by appliance operation at large changes exceeding 150°F between the water temperature at inlet and appliance temperature.

### **BURNER**

If within FIVE years after initial installation of the appliance a burner shall prove upon examination by Camus to be defective in material or workmanship, Camus will exchange or repair such part or portion.

### **ANY OTHER PART**

If any other part fails within one (1) year after installation, or eighteen (18) months from date of factory shipment based on

replacement or repair that part. Replacement parts will be shipped f.o.b. our factory.

### **DURATION OF LIMITED WARRANTY**

Any limited warranty, including the warranty of merchantability imposed on the sale of the boiler under the laws of the state or province of sale are limited in duration to one year from date of original installation.

### **STATE LAW & LIMITED WARRANTY**

*Some states or provinces do not allow:*

- a) Limitations on how long an implied warranty lasts
  - b) Limitations on incidental or consequential damages.
- The listed limitations may or may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state and province to province.

### **CONDITIONS**

*We will not:*

- a) Repair or replace any boiler, or part, subject to conditions outlined in 'This Limited Warranty Does Not Cover'
- b) Reimburse any costs associated with repair and/or replacement
- c) Replace and/or repair any boiler without complete model number/serial number
- d) Replace any boiler without prior receipt of actual rating plate from the appliance.

### **HOW TO MAKE A CLAIM**

Any claim under this warranty shall be made directly to Camus Hydronics Limited Canadian Head Office

### **SERVICE LABOR RESPONSIBILITY**

Camus shall not be responsible for any labour expenses to service, repair or replace the components supplied. Such costs are the responsibility of the owner.

### **DISCLAIMERS**

Camus shall not be responsible for any water damage. Provisions should be made that in the event of a water/appliance or fitting leak, the resulting flow of water will not cause damage to its surroundings.

+ + + + +

Name of Owner			
Name of Dealer			
Address			
Model No.			
Serial #:			
Date of Installation:		Date of Initial Operation:	

6226 Netherhart Road, Mississauga, Ontario, L5T 1B7, CANADA

Camus' records, whichever comes first. Camus will furnish a



**CAMUS Hydronics is a manufacturer of replacement parts for most copper finned**

**water heaters and heating boilers as well as a**

**supplier of specialty HVAC products. Our service line is open 24 hours, 7 days a week!**

**The CAMUS CERTIFIED! Seal assures you that Reliability, Efficiency & serviceability are built**

**into every single unit! For more information**



**on our innovative products from CAMUS Hydronics Limited, call 905-696-7800 today.**



**CAMUS HYDRONICS LTD.**

**6226 Netherhart Road, Mississauga, Ontario L5T 1B7**

**TEL: 905-696-7800 FAX: 905-696-8801**