








INSTALLATION OPERATION AND SERVICE MANUAL

TH SERIES

   	<p>GAS FIRED RESIDENTIAL AND COMMERCIAL STAINLESS STEEL TANK HEATERS</p>  <p>HOT WATER SUPPLY</p> <p><i>Models; TH082 ,102, 152, 202, 252, 292, 392, 502</i></p>	 
---	--	---

WARNING:

If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death

Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance,
- Do not touch any electrical switch; do not use any phone in your building,
- Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions,
- If you cannot reach your gas supplier, call the fire department.

Qualified installer, service agency or the gas supplier must perform installation and service.

To the Installer: After installation, these instructions must be given to the end user or left on or near the appliance.

To the End User: This booklet contains important information about this appliance. Retain for future reference.



CAMUS® HYDRONICS LTD.

6226 Netherhart Road, Mississauga, Ontario, L5T 1B7

99-0079
Rev. 0.4

TABLE OF CONTENTS

PART 1	GENERAL INFORMATION	1
1.1	INTRODUCTION	1
1.2	SPECIAL INSTRUCTIONS TO OWNER	1
1.3	CHECKING EQUIPMENT	1
1.4	DISPLAY UNIT	1
1.5	SEQUENCE OF OPERATION	1
1.5.2	Heat Transfer Process.....	2
1.5.3	End of Sequence	2
1.6	INSTALLATION CODES	2
1.7	WARRANTY.....	2
1.8	REMOVAL OF EXISTING APPLIANCE	3
1.9	BOILER/FURNACE ROOM OPERATING CONDITION	3
1.10	LOCATION OF UNIT	3
1.11	CLEARANCE FROM COMBUSTIBLE MATERIAL	4
PART 2	AIR INLET AND VENTING.....	7
2.1	GENERAL VENTING GUIDE	7
2.2	CATEGORY IV VENTING (TH 082 – 502).....	8
2.2.1	Approved Venting Materials Category IV	8
2.3	CATEGORY II VENTING (TH 202 - 502).....	8
2.3.1	Approved Venting Materials Category II	9
2.4	COMBINED COMBUSTION AIR INLET	9
2.5	VENT TERMINATION AND AIR INLET CLEARANCES	9
2.5.1	Sidewall Venting	9
2.5.2	Sidewall Air Inlet.....	10
2.5.3	Sidewall Concentric Vent/ Air.....	10
2.6	Vertical Direct Venting.....	11
PART 3	GAS CONNECTION	12
3.1	GAS CONNECTION	12
3.2	GAS PIPING.....	12
3.3	INSTALL PIPING.....	12
3.4	CHECKING GAS SUPPLY PRESSURE.....	13
3.5	HIGH and LOW GAS PRESSURE SWITCHES (Optional)	13
3.6	AIR/GAS RATIO VALVE.....	13
3.7	BURNER	14
PART 4	WATER CONNECTION	15
4.1	INLET AND OUTLET CONNECTIONS.....	15
4.2	MINIMUM PIPE SIZE REQUIREMENTS.....	15
4.3	HEAT EXCHANGER.....	15
4.4	LOW WATER TEMPERATURE SYSTEMS.....	15
4.5	PIPING ARRANGEMENTS.....	15
4.5.1	Field Supplied Components.....	15
4.6	FLOW PROVING DEVICE	16
4.7	T&P RELIEF VALVE	16
4.8	STAINLESS STEEL STORAGE TANK.....	16
PART 5	ELECTRICAL & CONTROLS	16
5.1	ELECTRICAL CONECTIONS	16
5.2	HIGH LIMIT	16
5.3	TH CONTROLLER.....	16
5.3.1	Service Parts	17

5.3.2	Ignition Module Lockout Functions.....	17
5.4	ERROR TABLE.....	17
5.4.1	Lockout Codes	17
5.4.2	Alert Codes	17
PART 6	CONTROL PANEL.....	18
6.1	TH CONTROLLER.....	18
6.2	SETTING THE TH CONTROLLER.....	18
6.3	DOMESTIC HOT WATER OPERATION	18
PART 7	COMPONENTS	19
7.1	DIRECT SPARK IGNITER.....	19
7.2	FLAME SENSOR.....	19
7.3	COMBUSTION AIR FAN.....	19
7.4	GAS VALVE.....	19
7.5	OUTER JACKET.....	19
PART 8	TH CONTROL PANEL	20
8.1	SETTING THE TANK HEATER CONTROLLER.....	20
PART 9	TROUBLESHOOTING	25
9.1	SETTING THE CORRECT COMBUSTION.....	33
9.2	GAS VALVE ADJUSTMENT PROCEDURE	33
PART 10	MAINTENANCE	35
10.1	EXAMINE THE VENTING SYSTEM.....	35
10.2	VISUALLY CHECK MAIN BURNER FLAMES	35
10.3	CLEANING BOILER HEAT EXCHANGER.....	35
10.4	CONDENSATE TREATMENT	36
10.4.1	Condensate Volume	36
10.5	IGNITER AND FLAME SENSOR ELECTRODES.....	36
10.6	CHECK IGNITER GROUND WIRING	36
10.7	BURNER MAINTENANCE	36
10.7.1	Burner Removal and Cleaning	37
10.8	REMOVAL OF COMBUSTION CHAMBER LINING	37
10.9	COMBUSTION AND VENTILATION AIR	37
10.10	CONTROL CIRCUIT VOLTAGE.....	37
10.11	COMBUSTIBLE MATERIALS.....	37
10.12	FREEZE PROTECTION FOR INDOOR & OUTDOOR INSTALLATIONS	38
PART 11	INSTALLATIONS.....	38
11.1	CHECKING THE INSTALLATION	38
11.2	CHECKING THE CONSTRUCTION	38
11.3	INSPECT & RECHARGE CONDENSATE COLLECTION/NEUTRALIZING RESERVOIR.....	38
11.4	WATER CONNECTIONS.....	39
11.5	SUMMARY	39
11.6	TEMPERATURE RISE AT FULL FIRING RATE	39
11.7	SETTING THE CORRECT COMBUSTION.....	40
11.8	APPLIANCE.....	40
11.9	IGNITION CYCLE.....	41
PART 12	SUGGESTED PIPING DIAGRAMS	42
PART 13	EXPLODED VIEW & PARTS LIST.....	43
PART 14	ELECTRICAL DIAGRAMS	47
14.1	TH 82- 502 INTERNAL WIRING DIAGRAM	47
14.2	DETAILED CONNECTOR DESCRIPTION.....	48

PART 1 GENERAL INFORMATION

1.1 INTRODUCTION

The TH Series is a forced draft appliance utilizing a premix power burner based on a push through design which offers several venting options. Heat output is controlled by a one to one air/gas ratio control gas valve which provides seamless modulation. The heater provides domestic hot water at working pressures up to 160 PSI. It is designed for use with a fully pumped and pressurized water system. The water heater will automatically modulate to provide heat outputs from 100% down to approximately 20% of rated input.

The TH utilizes a negative pressure gas valve. The operation of the fan will generate a negative pressure in the venturi, which draws in a matching amount of gas through the valve.

During operation the TH maintains a steady state efficiency across the entire range of modulation. Air and gas are metered in precise proportion (1:1 Ratio) allowing combustion characteristics which determine efficiency to remain the same over the entire operating range.

The TH is designed so that all of the sensible heating value and most of the latent heat is being transferred to the water.

1.2 SPECIAL INSTRUCTIONS TO OWNER

This manual supplies information for the installation, operation and servicing of the appliance. It is strongly recommended that this manual be reviewed completely before proceeding with an installation

CAUTION

It is important that all gas appliances are installed by a qualified installer/technician that is trained by Camus® Hydronics. It is in your own interest and that of safety to ensure that all local codes, and all the following "NOTES" and "WARNINGS" are complied with. Installing, servicing or adjusting this appliance should be performed only by a qualified installer/technician that is trained by Camus® Hydronics. The serviceman must utilize a combustion analyzer with CO₂, CO to set the appliance according to Camus® Hydronics' recommendations, prior to commissioning.

NOTE

RETAIN THIS MANUAL FOR FUTURE REFERENCE

1.3 CHECKING EQUIPMENT

Check for signs of shipping damage upon receiving equipment. Pay particular attention to parts accompanying the boiler, which may show signs of being hit or otherwise being mishandled. Verify total number of pieces shown on packing slip with those actually received. In case there is damage or a shortage, immediately notify carrier.

1.4 DISPLAY UNIT

The display unit will indicate status and will display selected temperature. Refer to Part 8 TH Control Panel, which provides details to modes and error codes displayed on the appliance.

1.5 SEQUENCE OF OPERATION

- 1) The power switch is placed in the "ON" position.
- 2) Minimum 120 VAC 60Hz single phase (15A circuit) is supplied to the Terminal Strip.
- 3) 24 VAC power is supplied to the TH Controller which provides all setup and ignition control functions.
- 4) A heat request is detected by the DHW Sensor.
- 5) After the appliance water pump starts, flow is proven by the flow proving device.
- 6) The TH Controller initiates a start-up sequence once it receives a heat demand.
- 7) Voltage is sent to the electrically commutated DC motor of the combustion fan after the internal safety checks are satisfied.
- 8) The fan will run at Pre-Purge speed until the Pre-Purge timer is satisfied. Once this is complete the TH Controller provides a signal to modulate down to ignition fan speed.
- 9) The TH Controller supplies voltage to the air/gas ratio control valve. The air/gas ratio control valve senses the pressure across the venturi and supplies gas to pre-mix with air.
- 10) The igniter will continue to spark for 6 seconds, with the gas valve opened 2 seconds after the initial spark is generated with the fan running at ignition speed.
- 11) Spark igniter lights the air/gas mixture. The TH Controller looks for a minimum flame rectification signal of 0.8 Vdc from the flame sensor during the Main Flame Establishing Period. If the signal is present the TH Controller will allow the gas valve to remain open. The burner is now firing at starting input rate.
- 12) The fan is kept at ignition speed until the stabilization timer is satisfied.
- 13) The boiler will modulate to the correct fan speed to meet the heat demand. The modulation rate is controlled via Pulse Width Modulation (PWM) signals provided by the TH Controller.
- 14) The fan speed will slowly decrease as the heat request nears the heat demand. If the heat demand is sustained for a long duration of time the boiler will get to a point of steady-state and the fan will rotate at a constant speed.
- 15) When the heat demand is satisfied or is removed the burner will shut off and the fan speed will ramp up to the preset Post-Purge speed until the Post-Purge Timer is satisfied.
- 16) The pump continues to circulate until the post-pump time is satisfied.
- 17) The boiler will then go into Standby as it waits for the next heat demand.

Note:

1. If a flame signal is detected at the end of the pre-purge period a lockout will occur.
2. If at the end of the safety period (6 sec) no flame is detected the control will go to post-purge to remove the unburned gas. After this, a re-ignition attempt is started following the same cycle. The number of re-ignition attempts is limited to 2 after which a lockout occurs.
3. The burner can only be on continuously for a period of 24 hours. After this the burner is switched off and a restart sequence follows.
4. Sparking stops 2 seconds before the end of the ignition period to allow for ionisation detection.

1.5.2 Heat Transfer Process

- 1) Burner input continues to increase until DHW water temperature reaches the setpoint temperature.
- 2) Burner input may stabilize at a fixed rate where demand equals input.
- 3) Burner input will decrease when DHW water temperature approaches temperature setpoint.

1.5.3 End of Sequence

- 1) Setpoint temperature is satisfied.
- 2) Power to the gas valve is turned off.
- 3) Combustion air fan ramps to a stop over the factory preprogrammed time period.

WARNING
To minimize the possibility of serious personal injury, fire or damage to your appliance, never violate the following safety rules.

DO NOT
Do not use this appliance if any part of it has been under water . The possible damage to a flooded appliance can be extensive and present numerous safety hazards. Any appliance that has been under water must be replaced

WHAT TO DO IF YOU SMELL GAS
Do not try to light any appliance. • Do not touch any electric switch: do not use any phone in your building. • Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. • If you cannot reach your gas supplier, call the fire department.

IMPORTANT
Consult and follow local Building and Fire Regulations and other Safety Codes that apply to this installation. Contact the local gas utility company to inspect and authorize all gas and flue connections.
Installation and service must be performed by a qualified technician/installer, and trained by Camus® Hydronics.

WARNING
Should overheating occur or the gas supply fails to shut off, DO NOT turn off or disconnect the electrical supply to the pump. Shut off the gas supply at a location external to the appliance.

- Boilers and water heaters are heat producing appliances. To avoid damage or injury, do not store materials against the appliance or the vent-air inlet system. Use proper care to avoid unnecessary contact (especially children) with the appliance and vent-air inlet components.
- Never cover appliance, lean anything against it, store trash or debris near it, stand on it or in any way block the flow of fresh air to appliance.
- **UNDER NO CIRCUMSTANCES** may flammable materials such as gasoline or paint thinner be used or stored in the vicinity of this appliance, vent-air inlet system or any location from which fumes could reach the appliance or vent-air inlet system.
- A gas appliance that draws combustion air from the equipment room where it is installed must have a supply of fresh air circulating around it during burner operation for proper gas combustion and proper

venting.

1.6 INSTALLATION CODES

The equipment shall be installed in accordance with those installation regulations enforced in the local area where the installation is to be made. These shall be carefully followed in all cases. Authorities having jurisdiction shall be consulted before installations are made. In the absence of such requirements, the installation shall conform to the latest edition or current as amended of the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA-B149 Installation Code. All electrical wiring must be done in accordance with the requirements of the authority having jurisdiction or, in the absence of such requirements, with national electrical code, ANSI/NFPA70 and/or the Canadian electrical code part 1 CSA C22.1. Where required by the authority having jurisdiction, the installation must conform to American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers, ASME CSD-1. All boilers must conform to the latest edition of the ASME Boiler and Pressure Vessel Code, Section II. Where required by the authority having jurisdiction, the installation must comply with the CSA International, CAN/CGA-B149 and/or local codes. This appliance meets the safe lighting performance criteria with the gas manifold and control assembly provided, as specified in the ANSI standards for gas-fired units, ANSI Z21.10.3b.

1.7 WARRANTY

- Factory warranty (shipped with unit) does not apply to units improperly installed or improperly operated.
- Factory warranty shall apply only when the appliance is installed in accordance with local plumbing and building codes, ordinances and regulations, the printed instructions provided with it and good industry practices.
- Excessive **water hardness** causing a lime build-up in the stainless steel coils or tubes is not a fault of the appliance and is not covered by warranty. Consult the factory for recommendations for use in hard water areas. (See Water Treatment and Water Chemistry)
- Using or storing **corrosive chemicals** in the vicinity of this appliance will attack the stainless steel jacket, the stainless steel venting, heat exchanger coils, wiring and brass fittings and voids warranty.
- Damage caused by **freezing or dry firing** voids warranty.
- This appliance is not to be used for **temporary heating** of buildings under construction.
- The manufacturer shall **NOT** be held liable for any personal injury or property damage due to ice formation or the dislodging of ice from the vent system or the vent termination

1.8 REMOVAL OF EXISTING APPLIANCE

When an existing appliance is removed from a common venting system, the common venting system is likely to be too large for proper venting of the appliances remaining connected to it. At the time of removal of an existing appliance, the following steps must be followed with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation.

- Seal any unused openings in the common venting system.
- Visually inspect the venting system for proper size and horizontal pitch and determine that there is no blockage, restriction, leakage, corrosion or other deficiency, which could cause an unsafe condition.
- Insofar as is practical, close all building doors and windows and all doors between the spaces in which the appliances remaining connected to the common venting system are located and other spaces of the building. If applicable turn on the clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
- Place in operation the appliance being inspected. Follow the lighting instructions. Adjust thermostat so that appliance operates continuously.
- Test for spillage at the draft control device relief opening after 5 minutes of main burner operation.
- After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous condition of use.
- Any improper operation of the common venting system should be corrected so that the installation conforms to the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA B149, Installation Codes. When resizing any portion of the common venting system, the common venting system should be resized to approach the minimum size as determined using the appropriate tables in Part 11 of the National Fuel Gas Code, ANSI Z223.1 and /or CAN/CGA B149, Installation Codes.

Heat exchanger surfaces and vent piping should be checked every six months for deterioration and carbon deposits. Remove all soot or other obstructions from the chimney and flue, which might impede draft action. Replace any damaged or deteriorated parts of the venting system.

A qualified service technician should follow this procedure when inspecting and cleaning the heat exchanger and vent pipe.

- 1) Turn off electrical power and main manual gas shut-off and allow appliance to cool down.
- 2) Remove the vent pipe at connection to heat exchanger and check heat exchanger and vent for obstruction and clean as necessary.
- 3) Remove burner from appliance and carefully clean as required. Never brush or wipe the knitted metal fiber surface. Use a garden hose or gently wash under the

tap. Vacuum out any deposits found in the heat exchanger.

CAUTION

Never use a pressure washer or compressed air to clean the burner.

- 4) Reinstall parts removed in steps 2 and 3. Be sure that vent pipe has proper pitch and is properly sealed. Replace any damaged gasket or refractory. Tighten fan flange mounting nuts to 3 ft-lb.
- 5) Restore electrical power and gas supply to appliance.
- 6) Place appliance in operation using lighting instructions provided.
- 7) Confirm proper operation of all safety devices
- 8) Check for gas leaks and proper vent operation.

NOTE

Experience has shown that improper installation or system design, rather than faulty equipment, is the cause of most operating problems

1.9 BOILER/FURNACE ROOM OPERATING CONDITION

- Due to low jacket losses from the appliance, temperatures in the vicinity of the boiler room may drop significantly; supplemental heat is required to maintain ambient temperature at minimum of 40°F.

1.10 LOCATION OF UNIT

Install this appliance in a clean, dry location with adequate service clearance.

- Do not locate this appliance in an area where it will be subject to freezing unless precautions are taken. Radiant losses from the TH are minimal and should not be relied on to keep the appliance room warm.
- Do not locate this appliance where it may be exposed to a corrosive atmosphere.
- The appliance should be located close to a floor drain in an area where leakage from the appliance or connections will not result in damage to the adjacent area or to lower floors in the structure, it is recommended that a suitable drain pan, adequately drained, be installed under the unit. Under no circumstances is the manufacturer to be held responsible for water damage in connection with this unit, or any of its components.
- If the appliance is installed above the level of the building's radiation system, a low water cut-off device must be installed in the appliance outlet at a minimum of 3 ft (1M) above the heat exchanger inlet/outlet connections. Some local codes require the installation of a low water cut-off on all systems
- When placing the appliance beware that a minimum clearance of 24" must be provided at the front to allow easy access to the heat exchanger.
- The appliance must be installed so that the ignition system components are protected from water (dripping, spraying, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)
- Appliances located in a residential garage and in adjacent spaces that open to the garage and are not part of the living space of a dwelling unit must be installed so that all burners and burner ignition devices have a minimum clearance of not less than 18" (46cm)

above the floor. The appliance must be located or protected so that it is not subject to physical damage by a moving vehicle.

- **DO NOT** install this appliance in any location where gasoline or flammable vapors are likely to be present.
- Appliance must be installed on a level floor. Maintain required clearances from combustible surfaces.
- The appliance designed for indoor installation (Indoor Models) must be installed indoors where it is protected from exposure to wind, rain and weather.
- The appliance designed for outdoor installation (Outdoor Models) must be installed outdoors. For outdoor installations, always consider the use of a shelter such as a garden shed in lieu of direct exposure of the appliance to the elements. The additional protection afforded by the shelter will help to minimize nuisance problems with electrical connections and will allow easier servicing of the appliance under severe weather conditions.


1.11 CLEARANCE FROM COMBUSTIBLE MATERIAL

This appliance is suitable for alcove (a closet without a door) installation with minimum clearances to combustibles as follows:

Table 1: Clearance from Combustibles

Clearances from Combustibles	
TOP:	0"
SIDES:	0"
REAR:	12"
VENT (Vent Adapter/ Stainless Steel):	1"
VENT (PVC/CPVC):	0"
FRONT:	6"

Figure 1: TH Clearance from Combustibles



NOTE
Clearances from combustible construction are noted on the appliance rating plate

Table 2: TH Service Clearances

Input [BTU/hr]	Service Clearance, Inches (cm)				
	Front	Top	Right Side	Left Side	Rear
80,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61cm)	12" (31 cm)
100,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61cm)	12" (31 cm)
150,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61 cm)	12" (31cm)
199,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61 cm)	12" (31 cm)
250,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61 cm)	12" (31 cm)
299,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61 cm)	12" (31cm)
399,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61 cm)	12" (31 cm)
500,000	24" (61cm)	18" (46cm)	0" (0cm)	24" (61 cm)	12" (31 cm)

Figure 2: TH Model Dimensions





Table 3: Appliance Dimensions and Specifications

Input [BTU/hr]	Dim. "A" [in.]	Dim. "B" [in.]	Dim. "C" [in.]	Dim. "D" [in.]	Dim. "E" [in.]	Dim. "F" [in.]	Dim. "G" [in.]	Dim. "H" [in.]	Equivalent Length of Vent & Air Intake Pipes at Recommended Diameter, [in.]			Water Conn. at Boiler [in.] NPT	Gas Conn. at Boiler [in.] NPT	
									Category IV					
									Over 25' and up to 100'	Over 15' and up to 25'	Up to 15'			
80,000	53	22 1/4	46 1/4	46 3/8	47 1/2	8 3/4	9 7/8	7 3/8	3	3	2	-	1	1/2
100,000	53	22 1/4	46 1/4	46 3/8	47 1/2	8 3/4	9 7/8	7 3/8	3	3	2	-	1	1/2
150,000	53	22 1/4	46 1/4	46 3/8	47 1/2	8 3/4	9 7/8	7 3/8	3	3	2	-	1	1/2
199,000	53	31 1/4	37 3/4	46 3/8	47 1/2	12 1/8	9 7/8	7 3/8	3	3	2	4	1	1/2
250,000	53	31 1/4	37 3/4	46 3/8	47 1/2	12 1/8	9 7/8	7 3/8	3	3	2	4	1 1/4	1/2
299,000	65 1/2	31 1/4	37 1/2	58 3/8	53 7/8	12 1/8	11 3/8	8 7/8	4	3	3	5	1 1/4	3/4
399,000	65 1/2	31 1/4	37 1/2	58 3/8	53 7/8	12 1/8	11 3/8	8 7/8	4	3	3	5	1 1/2	1
500,000	65 1/2	31 1/4	37 1/2	58 3/8	53 7/8	12 1/8	11 3/8	8 7/8	4	3	3	6	1 1/2	1

Maintain minimum specified clearances for adequate operation. All installations must allow sufficient space for servicing the vent connections, water pipe connections, circulating pump, bypass piping and other auxiliary equipment, as well as the appliance

Figure 3: TH Service Clearances



PART 2 AIR INLET AND VENTING


▲ DANGER

It is extremely important to follow these venting instructions carefully. Failure to do so can cause severe personal injury, death or substantial property damage.

2.1 GENERAL VENTING GUIDE

- Single pipe vent with common air from room.

Figure 4: Venting Configuration



IN GENERAL

- The operation of exhaust fans, compressors, air handling units etc. can rob air from the room, creating a negative pressure condition leading to reversal of the natural draft action of the venting system. Under these circumstances an engineered air supply is necessary.
- If the appliance is to be installed near a corrosive or potentially corrosive air supply, the appliance must be isolated from it and outside air should be supplied as per code.
- Potentially corrosive atmospheres will result from exposure to permanent wave solution, chlorinated waxes and cleaners, chlorine, water softening chemicals, carbon tetrachloride, halogen based refrigerants, Freon cleaning solvents, hydrochloric acid, cements and glues, masonry washing materials, antistatic fabric softeners, dry cleaning solvents, degreasing liquids, printing inks, paint removers, etc.
- The equipment room MUST be provided with properly sized openings to assure adequate combustion air and proper ventilation when the unit is installed with a proper venting system.

The TH is a category II/IV condensing appliance, 97% efficient unit.

The TH may be vented with manufactured prefabricated UL/ULC listed vents of AL29-4C or 316L stainless steel or with plastic vent certified to UL/ULC S636, such as, IPEX System 636 CVPC or IPEX System 636 PVC or as permitted by local jurisdictions.

- The TH must be vented and supplied with combustion and ventilation air as described in this section. Ensure that the venting and combustion air supply complies with these instructions regarding

the vent system, air system, and combustion air quality.

- Provisions for combustion and ventilation air are to be in accordance with the section "Air for Combustion and Ventilation", Of the National Fuel Gas Code, ANSI Z223.1/NFPA 54, or clause 8.2,8.3, or 8.4 of" Natural Gas and Propane Installation Code", CAN/CSA B149.1,2 or applicable provisions of the local building codes.
- The distance of the vent terminal from adjacent buildings, windows that open and building openings MUST comply with the latest edition of the National Fuel Gas Code, ANSI Z223.1 for U.S. installations or CAN/CGA Standard B149 Installation Code for Canadian Installations.
- Vent connection is made directly to the flue outlet opening on the rear of the unit. The connection from the appliance vent to the stack must be made as direct as possible. The first 3 feet of vent from the appliance flue outlet must be readily accessible for visual inspection.
- Vent connectors serving appliances vented by natural draft shall not be connected into any portion of a mechanical draft system operating under positive pressure.
- A UL listed concentric vent/air intake kit may be used with the TH.
- Horizontal runs of vent pipe shall be securely supported (approximately every 4 feet) to prevent sagging and maintain a minimum upward slope of 1/4" per foot from the appliance to the vent terminal.
- The weight of the venting system must not rest on the unit. Adequate support of the venting system must be provided in compliance with local codes and other applicable codes.
- All connections should be secured and sealed per the vent manufacturer's specifications. When a positive vent system is disconnected for any reason, the flue must be reassembled and resealed according to the vent manufacturer's instructions.
- Do not use an existing chimney as a raceway if another appliance or fireplace is vented through the chimney.
- Inspect completed vent and air supply piping thoroughly to ensure all connections are sealed and are in compliance with the instructions provided and satisfy requirements of all applicable codes.

NOTE

All vent pipes must be properly assembled and supported, and the exhaust must be pitched a minimum of 1/4 inch per foot back to the boiler. All components used to fabricate and assemble the vent system are to originate from the same supplier.

When determining equivalent inlet air and vent lengths of 3" diameter add 3 to 5 feet for each 90° elbow and 2 to 3 feet for each 45° elbow, depending on centerline radius of the elbow.

Example: 30 feet of CPVC pipe + (3 x 5 feet) 90° elbows + (1 x 3 feet) 45° elbow = 48 equivalent feet of piping for centerline radius of 1.5D, where D is the pipe diameter.

2.2 CATEGORY IV VENTING (TH 082 – 502)

A category IV appliance is individually vented through a dedicated vent.

The TH shall be vented as a Category II/ IV condensing appliance as per table 4.

For site conditions exceeding 100 equivalent feet an engineered vent system approved by the local authority will be required.

The appliance shall be vented using sealed positive vent suitable for a condensing appliance with the following venting options:

- 1) Sidewall or rooftop termination where both the vent and combustion air inlet air are in the same zone. The inlet and vent terminals are to be installed with a minimum 12" separation distance between centerline of inlet and centerline of exhaust. Refer to Fig. 5, 6, and 7 for sidewall termination and Fig. 8 for rooftop termination.
- 2) Sidewall termination with vent and combustion air inlet from separate zones.
- 3) Single pipe thru wall or rooftop venting with combustion air inlet from the boiler room.

NOTE
Vent Option 3 not recommended for R-2000 homes or equivalent air tight construction.

2.2.1 Approved Venting Materials Category IV

- 1) PVC and CPVC (Chlorinated Polyvinyl Chloride) Schedule 40 or 80 approved to ULC S636.
- 2) Manufactured prefabricated UL/ULC listed vent of AL29-4C or 316L stainless steel. Use of 316L is limited to use in applications where there is no possibility of contaminants in the air such as refrigerants, chlorine etc.
- 3) PVC-DWV approved to comply with ANSI/ASTM D2665 (US Jurisdictions ONLY when permitted)
- 4) PVC Schedule 40 approved to comply with ANSI/ASTM D1785. (US Jurisdictions ONLY when permitted)
- 5) CPVC Schedule 40 approved to comply with ANSI/ASTM F441. (US Jurisdictions ONLY when permitted)
- 6) Polypropylene approved to comply with ULC S636

NOTE
1) Use of cellular core PVC (ASTM F891), cellular core CPVC or Radel® (polyphenosulfone) in venting systems shall be prohibited.
2) Covering non-metallic vent pipe and fittings with thermal insulation shall be prohibited.

Table 4: Maximum Flue Temperature for Various Vent Materials¹⁾

Vent Material	Maximum Flue Temperature [°F]
PVC	149
CPVC	194
PPE	230
AL29-4C	300+, limited only by rating of seals
316L Stainless Steel	300+, limited only by rating of seals

Stack temperature is typically between 15-30°F above inlet water temperature depending on model size and firing rate.

Air Inlet (Supply Air or Fresh Air) Piping

- PVC, Non Foam Core Pipe.
- CPVC, Non Foam Core Pipe
- ABS (Acrylonitrile-Butadiene-Styrene)
- PPE (Polypropylene)
- Single wall, Galvanized
- Single wall, Stainless steel
- Single wall, Aluminum

Single wall air inlet pipes are to be insulated 5 feet from the wall toward the interior of the building to minimize external sweating.

Air intake material must be of a type listed by a nationally recognized testing agency.

The following air intake options shall be utilized:

- Outside air sealed direct (vertical or horizontal)
- Outside air ducted to jacket flange
- Indoor Air

Table 5: Required Vent and Air Inlet Diameters

Input [BTU/hr]	Equivalent Length of Vent & Air Intake Pipes at Recommended Diameter*			
	Category IV			Category II
	Over 25' and up to 100'	Over 15' and up to 25'	Up to 15'	
80,000	3"	2"	2"	-
100,000	3"	2"	2"	-
150,000	3"	2"	2"	-
199,000	3"	3"	2"	4"
250,000	3"	3"	2"	4"
299,000	4"	3"	3"	5"
399,000	4"	3"	3"	5"
500,000	4"	3"	3"	6"

* Consult factory for recommendations applicable to venting combinations not shown above.

2.3 CATEGORY II VENTING (TH 202 - 502)

A category II appliance may be combined into a common negative pressure venting system designed to ASHRAE requirements using a proven vent sizing program. Vent designs are to be certified by a qualified professional designer acceptable to the authority having jurisdiction.

The TH may be vented as a Category II appliance using sealed vent suitable for a condensing appliance.

2.3.1 Approved Venting Materials Category II

- 1) PVC and CPVC (Chlorinated Polyvinyl Chloride) Schedule 40 or 80 approved to ULC S636.
- 2) Manufactured prefabricated UL/ULC listed vent of AL29-4C or 316L stainless steel. Use of 316L is limited to use in where there is no possibility of contaminants in the air such as refrigerants, chlorine etc.
- 3) PVC-DWV approved to comply with ANSI/ASTM D2665 (US Jurisdictions ONLY when permitted).
- 4) PVC Schedule 40 approved to comply with ANSI/ASTM D1785. (US Jurisdictions ONLY when permitted)
- 5) CPVC Schedule 40 approved to comply with ANSI/ASTM F441. (US Jurisdictions ONLY when permitted).
- 6) Polypropylene approved to comply with ULC S636

Air Inlet (Supply Air or Fresh Air) Piping

- PVC
- CPVC (Chlorinated Polyvinyl Chloride)
- ABS (Acrylonitrile-Butadiene-Styrene)
- PPE (Polypropylene)
- Single wall, Galvanized
- Single wall, Stainless steel
- Single wall, Aluminum

Single wall air inlet pipes are to be insulated 5 feet from the wall toward the interior of the building to minimize external sweating.

The following air intake options shall be utilized:

- Outside air sealed direct (vertical or horizontal)
- Outside air ducted to jacket flange
- Indoor Air

NOTE

Sealed combustion is required when the TH is placed in a space with other fan-assisted appliances.

Sealed combustion is required when TH Series is placed in a space with other fan-assisted appliances.

If air is taken directly from outside the building with no duct, provide two permanent openings:

- a) Ventilation of the space occupied by fuel burning appliance(s) or equipment shall be supplied by a ventilation opening at the highest practicable point communicating with the outdoors. The total cross sectional area of the ventilation opening must be either 10% of the net free area required for combustion air or 10 sq. in. (6500 mm²), whichever is greater.
- b) Net free area for combustion air opening shall be in accordance with all applicable codes. In the absence of such codes provide combustion air opening with a minimum free area of one square inch per 7000 Btuh input (5.5 cm per kW) up to 1,000,000 Btuh and one square inch per 14,000 Btuh in excess of 1,000,000 Btuh. This opening must be ducted no higher than 18" nor less than 6" above the floor.
- c) In extremely cold climates when air supply is provided by natural air flow from outdoors we recommend sizing the combustion air-supply opening with a minimum free area of not less than one square inch per 30,000 Btu/hr, of the total rated input of the burner, provided that this does not conflict with local codes. This opening is in addition to the ventilation opening defined in paragraph a) above.

NOTE

Outside air openings shall directly communicate with the outdoors.

CAUTION

Under no circumstances should the mechanical room ever be under a negative pressure. Particular care should be taken where exhaust fan, attic fans, clothes dryers, compressors, air handling units, etc., may take away air from the unit.

2.4 COMBINED COMBUSTION AIR INLET

The TH may be installed with a combined combustion air inlet.

The combined combustion air inlet pipe sizing can be calculated using the method shown below:

Equivalent pipe diameter = Sq Root [(d₁)² + (d₂)² + (d₃)² + ... + (d_n)²], where d_n = individual pipe diameter

- Example: Find the equivalent pipe diameter of three air inlet pipes, 3" (7.6cm), 3" (7.6cm) and 4" (10.2cm)

Equivalent pipe diameter = Sq Root[(3)² + (3)² + (4)²] = Sq Root(34) = 5.8", select 6" (15.3cm) equivalent diameter pipe.


The air inlet point for multiple air inlets must be provided with an exterior opening which has a free area equal to or greater than the total area of all air inlet pipes connected to the common air inlet. This exterior opening for combustion air must connect directly to the outdoors. The total length of the combined air inlet pipe must not exceed a maximum of 100 equivalent feet (30.5m). Deduct the restriction in an area provided by any screens, grills or louvers installed in the common air inlet point. Screens, grills or louvers installed in the common air inlet can reduce the free area of the opening from 25 to 75% based on the materials used. Calculate and compensate accordingly.

2.5 VENT TERMINATION AND AIR INLET CLEARANCES

2.5.1 Sidewall Venting


- The first 3 feet (1m) of vent from the appliance flue outlet must be readily accessible for inspection.

Figure 5: Sidewall Vertical Configuration



* Always check local codes for minimum distance above ground or snow levels

Figure 6: Sidewall Horizontal Configuration




* Always check local codes for minimum distance above ground or snow levels

Location of Vent Termination

- 1) The total length of vent piping must not exceed the limits stated in Table 6.
- 2) The bottom of the vent terminal shall be located at least 3 feet (1m) above grade or above normal snow levels. In all cases the appliance shall be installed in accordance with local codes
- 3) The TH can vent up to 100 equivalent feet. Elbows can range from 3 to 5 feet in equivalent length depending on the centerline radius. Vent sizes are 3" for Models 82 to 252 and 4" for Models 292 to 502 for equivalent vent lengths of up to 100'.
- 4) The vent outlet shall terminate at least 12" (0.30m) away from any forced air inlet. The vent must be at least 7 feet (2.15m) above grade when located adjacent to public walkways due to normal formation of water vapour in the combustion process.
- 5) The vent outlet MUST NOT terminate below a forced air inlet at any distance
- 6) The vent cannot terminate below grade. Position the vent termination where vapours will not damage walls or plants or may be otherwise objectionable.
- 7) The vent terminal shall not be installed closer than 3 feet (1m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.
- 8) DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 9) Position terminations so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- 10) The vent piping must terminate in an elbow pointed outward or away from the air inlet.
- 11) Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Keep the vent cap/terminal clear of snow, ice, leaves, debris etc. Some discolouration to exterior building surfaces is to be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.
- 12) Perform regularly scheduled inspections to ensure that the vent terminal is unobstructed.

2.5.2 Sidewall Air Inlet

Figure 7: Sidewall Vent and Air Inlet Configuration



* Please check local codes for minimum distance above ground or snow levels

Location of a Sidewall Air Inlet Cap

- 1) The total length of piping for air inlet must not exceed the limits stated in Table 6.
- 2) The point of termination for the sidewall air inlet cap must be located a minimum of 12 inches (0.30m) away from the flue gas termination, but never above.
- 3) The air piping must terminate in a down-turned elbow to avoid recirculation of flue products into the inlet air stream.
- 4) DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 5) DO NOT terminate the air inlet in a window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect performance or cause recirculation.
- 6) The air inlet cannot terminate below grade.
- 7) Locate terminations so they are not likely to be damaged by foreign objects, or exposed to build-up of debris.
- 8) Perform regularly scheduled inspections to ensure that the air inlet terminal is unobstructed.

Termination and Fittings

- 1) The air inlet opening must be at least 12 inches (0.30m) away from (never above) the vent termination and at least 3 feet (1m) above grade or above normal maximum snow levels.

2.5.3 Sidewall Concentric Vent/ Air

A listed concentric vent kit can be used with the TH appliance. Both combustion air and vent pipes must terminate outside the structure.

- 1) The total length of piping for venting or air must not exceed the limits stated in Table 8.
- 2) The bottom of the termination shall be located at least 3 feet (1m) above grade or above normal snow levels. In all cases the appliance shall be installed in accordance with local codes
- 3) The termination MUST NOT terminate below a forced air inlet at any distance
- 4) The termination cannot terminate below grade. Position the termination where vapours will not damage walls or plants or may be otherwise objectionable.

- 5) The termination shall not be installed closer than 3 feet (1m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.
- 6) DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 7) Position termination so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- 8) Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Keep the vent cap/terminal clear of snow, ice, leaves, debris etc. Some discoloration to exterior building surfaces is to be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.
- 9) Perform regularly scheduled inspections to ensure that the termination is unobstructed.
- 10) Operate the appliance for one heat cycle to ensure combustion air and vent pipes are properly connected to the concentric vent termination connections.

CAUTION

Do not operate appliance with the rain cap removed as this may result in the recirculation of flue products. Water may also flow into the combustion air pipe and into the burner enclosure.

Figure 8: Concentric Sidewall Termination





Figure 9: Concentric Vent Sidewall



2.6 Vertical Direct Venting

Location of Vent Termination


- 1) The total length of piping for venting must not exceed the limits stated in Table 6.
- 2) The vent piping must terminate in a 90° elbow if plastic piping is used or in an approved vent cap if using metal venting. The vent outlet must be at least 1 foot away and 1 foot above from the air inlet opening which must terminate in a double elbow facing downwards.

- 3) The vertical termination must be a minimum of 3 feet (1m) above the point of exit.
- 4) A vertical termination less than 10 feet (3.05m) from a parapet wall must be a minimum of 2 feet (0.61m) higher than the parapet wall.
- 5) DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence.
- 6) Position the air inlet and vent terminations so they are not likely to be damaged by foreign objects, or exposed to build-up of debris.
- 7) Perform regularly scheduled inspections to ensure that the vent terminal is unobstructed.

Location of a Vertical Air Inlet Opening

- 1) The total length of piping for inlet air must not exceed the limits given in Table 6.
- 2) The air inlet consists of two 90° elbows installed at the point of termination for the vertical air inlet pipe. A 90° elbow and a 90° street elbow may be used to make this assembly. If a straight piece of pipe is used between the two elbows, it should not exceed 6" (0.15m) in length. The air inlet opening must be at least 1 foot below the vent opening. The air piping must be no further than 2 feet (0.6m) from the center of the vent pipe. This arrangement avoids exhaust gases from re-circulating into the inlet air stream. Refer to Figure 8.
- 3) Air inlet must terminate at least 3 feet (1.0m) above the roof or normal snow levels and at least 1 foot (0.3m) below the vent termination.
- 4) Locate terminations so they are not likely to be damaged by foreign objects or exposed to build-up of debris.
- 5) Perform regularly scheduled inspections to ensure that the air inlet terminal is unobstructed.

Figure 10: Vertical Direct Venting Configuration



Vertical Concentric Vent/ Air

A concentric vent kit can be used with the TH appliance. Both combustion air and vent pipes must terminate outside the structure.


- 1) The total length of piping for venting or air must not exceed the limits stated in Table 8.
- 2) The bottom of the termination shall be located at least 3 feet (1m) above grade or above normal snow levels. In all cases the appliance shall be installed in accordance with local codes
- 3) The termination MUST NOT terminate below a forced air inlet at any distance

- 4) The termination cannot terminate below grade. Position the termination where vapours will not damage walls or plants or may be otherwise objectionable.
- 5) The termination shall not be installed closer than 3 feet (1m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.
- 6) DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- 7) Position termination so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- 8) Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Keep the vent cap/terminal clear of snow, ice, leaves, debris etc. Some discolouration to exterior building surfaces is to be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.
- 9) Perform regularly scheduled inspections to ensure that the termination is unobstructed.
- 10) Operate the appliance for one heat cycle to ensure combustion air and vent pipes are properly connected to the concentric vent termination connections.

CAUTION

Do not operate appliance with the rain cap removed as this may result in the recirculation of flue products. Water may also flow into the combustion air pipe and into the burner enclosure.

Figure 11: Concentric Vent Vertical Venting



Length of Air Inlet Pipe

The maximum total length of the sidewall or vertical roof top combustion air inlet pipe as installed from the appliance to the air inlet cap must not exceed 100 equivalent feet (30.5m) in length. Subtract 3 to 5 feet (1 to 1.5m) of equivalent length depending on centerline radius for each 90° elbow installed in the air inlet pipe system. Pressure drop in each 45° elbow will be half as much, 2 to 3 feet (0.6 to 1.0m).

PART 3 GAS CONNECTION

Verify that the appliance is supplied with the type of gas specified on the rating plate. Consult factory for installations at high altitude.

3.1 GAS CONNECTION

- Safe operation of unit requires properly sized gas supply piping. See gas line sizing data.
- Gas pipe size may be larger than appliance connection.
- Installation of a union at the appliance gas line connection is required for ease of service and removal of the gas train.
- Install a manual main gas shutoff valve, outside of the appliance gas connection as require by local codes.
- A trap (drip leg) **MUST** be provided in the inlet gas connection to the appliance.
- Optional gas controls may require routing of bleeds and vents to the atmosphere, outside the building when required by local codes.

Table 6: Recommended Gas Pipe Size

Single Appliance Installation

(For distance from natural gas meter or propane second stage regulator)

Input Btu/Hr, x1000	0-100 FT		101-200 FT		201-300 FT	
	NAT.	L.P.	NAT.	L.P.	NAT.	L.P.
80	3/4"	1/2"	3/4"	1/2"	1"	3/4"
100	3/4"	1/2"	1"	3/4"	1"	3/4"
150	1"	3/4"	1 1/4"	1"	1 1/4"	1"
199	1"	3/4"	1 1/4"	1"	1 1/4"	1"
250	1 1/4"	1"	1 1/4"	1"	1 1/2"	1 1/4"
299	1 1/4"	1"	1 1/2"	1 1/4"	1 1/2"	1 1/4"
399	1 1/4"	1"	1 1/2"	1 1/4"	2"	1 1/2"
500	1 1/2"	1 1/4"	2"	1 1/2"	2"	1 1/2"
600	1 1/2"	1 1/4"	2"	1 1/2"	2"	1 1/2"
700	2"	1 1/2"	3"	2 1/2"	3"	2 1/2"
800	2"	1 1/2"	3"	2 1/2"	3"	2 1/2"

3.2 GAS PIPING

All gas connections must be made with pipe joint compound resistant to the action of liquefied petroleum and natural gas. All piping must comply with local codes and ordinances.

3.3 INSTALL PIPING

- The gas line should be sufficient to handle the total installed capacity. Verify pipe size with your gas supplier.
- Use approved piping as per code free from burrs.
- Install a manual main gas shutoff valve at the appliance gas inlet, outside of the appliance and before the gas valve.
- Run pipe to the Appliance gas inlet.
- Install a sediment trap in the supply line to the Appliance gas inlet.
- Apply a moderate amount of good quality pipe compound.
- For LP gas, consult your LP gas supplier for expert installation.

The appliance and its individual gas shut-off valve must be disconnected from the supply piping when pressure testing the gas supply piping at pressures above ½ PSI

Table 7: Gas Pressures at Inlet to Appliance

	PROPANE	NATURAL GAS
Minimum (inches W.C.)	11	3
Maximum (inches W.C.)	11	14

*Recommended regulator settings is 7.0" w.c.

The gas supply line must be of adequate size to prevent undue pressure drop and must never be smaller than the size of the connection on the appliance. Sizing based on Table 8 is recommended, depending on model.

Before operating the appliance, the complete gas train and all connections must be tested using soap solution.

Verify that the appliance is supplied with the type of gas specified on the rating plate. Heating values of local natural gas are to be between 950 and 1010 Btu/ft³. Consult factory if heating values are outside this range or if a gas with a mixture of constituents is being used.

3.4 CHECKING GAS SUPPLY PRESSURE

- Turn the main power switch to "OFF" position.
- Shut off gas supply at the manual gas cock in the gas piping to the appliance. If fuel supply is LP gas, shut off gas supply at the tank.
- Remove the 1/8" hex plug from the gas pressure test port located on the inlet gas supply connection at the rear of the appliance. Install a fitting in the inlet pressure tapping suitable to connect to a manometer or magnahelic gauge. Range of scale should be 0 to 14 inch W.C. or greater to check inlet pressure
- Turn on gas supply at the field installed manual gas cock; turn on LP gas at tank if required.
- Turn the power switch to "ON" position.
- Adjust the thermostat set point to call for heat.
- Observe the gas supply pressure as the burner fires at 100% of rated input. Supply pressure is to remain stable.
- Ensure inlet pressure is within specified range. Minimum and maximum gas supply pressures are specified in Table 8.
- If gas pressure is out of range, contact the gas utility, gas supplier, qualified installer or service agency to determine necessary steps to provide proper gas pressure to the control.
- If gas supply pressure is within normal range, proceed to remove gas manometer and replace pressure tap fittings in the gas piping to the appliance. Turn the power switch to "OFF" position.
- Turn on gas supply at the manual valve; turn on LP gas at tank if required.
- Turn the power switch to "ON" position.
- Adjust the thermostat temperature set point to the desired water temperature so the appliance will call for heat.
- Check appliance performance by cycling the system while you observe burner response. The burner should ignite promptly. Flame profile should be stable, see section 10.2, Visually Check Main Burner Flames. Turn system off and allow burner to cool, then cycle burner again to ensure proper ignition and flame characteristics.

IMPORTANT

Upon completion of initial installation or following any repair work on the gas system, leak test all gas connections with a soap solution while the main burner is firing. Immediately repair any leak found in the gas train or related components. DO NOT operate an appliance with a leak in the gas train, valves or related gas piping.

3.5 HIGH and LOW GAS PRESSURE SWITCHES (Optional)

High and low gas pressure switches are available as an option and are wired in series with the blocked flue switch. The high gas pressure switch is used to monitor the differential gas pressure between the outlet of the control valve and the fan inlet. If differential gas pressure exceeds the maximum setting of the pressure switch, the appliance will shut down and a low air condition will be indicated on the display panel. The low gas pressure switch is to monitor the minimum incoming gas supply pressure supplied to the gas train. If gas pressure falls below the minimum setting of the pressure switch, the appliance will shut down and a low air condition will be displayed on the display panel.

3.6 AIR/GAS RATIO VALVE

The main gas valve supplying gas to the burner on this appliance utilizes a servo pressure regulator providing a slow opening, fast closing safety shut off and air/gas ratio control for the gas combustion process. The valve is a 1:1 negative pressure gas valve. The valve performs the functions of a pressure regulator, safety shutoff, and air/gas ratio control. Full closing of the valve seat occurs in less than 0.8 seconds when the valve is de-energized. Operation of the gas valve in combination with the combustion air fan allows the burner input rate to vary from 20% to 100% based on temperature demand. The inlet gas supply pressure must be maintained within the specified minimum and maximum pressures.

The air/gas ratio is preset at the factory and adjustment is not usually required if gas supply pressure is maintained within the specified range.

There are no serviceable parts on the air/gas ratio valve control.

Figure 12: TH 82 – 252 1:1 Air/Gas Ratio Control Valve




Figure 13: TH 292 – 392 1:1 Air/Gas Ratio Control Valve





Figure 14: TH 502 1:1 Air/Gas Ratio Control Valve



3.7 BURNER

Figure 15: TH Burner



This appliance uses a single cylindrical burner installed horizontally into the cavity located in the center of the heat exchanger. There is a unique burner for each one of the TH models.

Burners may NOT be interchanged between different Btu/hr input models. The burner consists of a round mounting flange welded to a ported stainless steel mixing tube. This stainless steel tube is covered with a close fitting, knitted stainless steel metal fiber alloy material that forms the burner outer surface. The burner is setup to operate in blue mode and infrared operating condition should be avoided. Infrared operation will occur only if air to gas adjustments is incorrect. If infrared operation is noted the cause must be corrected.

The burner should be removed for inspection and cleaning on an annual basis. An appliance installed in a dust or dirt contaminated environment will require inspection and cleaning on a more frequent schedule. The fan assisted combustion process may force airborne dust and dirt contaminants, contained in the combustion air, into the burner. With sustained operation, non-combustible contaminants may reduce burner surface area, reduce burner input or cause non-warrantable damage to the burner.

Airborne contaminants such as dust, dirt, concrete dust or dry wall dust can be drawn into the burner with the combustion air and block the burner surface area. **DO NOT** operate this appliance during construction.

The spark igniter and flame sensor are removable from the combustion chamber mounting door without removing the burner assembly.

Never use an open flame (match, lighter, etc.) to check gas connections.

Regulated Gas Supply Pressures for Tank Heater

A stable gas supply pressure is important to avoid rough starts with machines like the Tank Heater which use a 1 to 1 ratio control valve for internal gas pressure regulation. Camus® requires that all Tank Heater models be supplied with no more than 14" w.c. supply pressure. This means that lockup pressure must not exceed 14" w.c.

A suitable lockup regulator with internal or external relief will not exceed running pressure by more than 20%.

When required a final stage gas regulator is to be located as close as possible but no more than 10 feet from the appliance.

It is paramount that maximum lockup pressure be confirmed before any attempt is made to start up the appliance.

Operating the Tank Heater at lockup pressures exceeding 14" w.c. could lead to delayed ignitions and damage to the appliance.

PART 4 WATER CONNECTION

- Check all applicable local heating, plumbing and building safety codes before proceeding.
- If the appliance is installed above radiation level it must be provided with a low water cut-off device at the time of appliance installation (available from Camus®). Some local codes require the installation of a low water cut-off on all systems.
- A temperature and pressure relief valve is supplied with each TH. The relief valve must be mounted in a vertical position and piped to the floor in a manner acceptable to the enforcing authority.
- Be sure to provide unions and gate valves at inlet and outlet to the appliance so that it can be easily isolated for service.
- This appliance is a low mass stainless steel tube design which provides for instant heat transfer. All appliances are supplied with an internal suitable specific pump mounted in place. When replacing the pump, replace with one of equal or better-performance.
- An air vent is supplied on the heat exchanger header to eliminate trapped air. Install venting devices at high points in the system as well to eliminate trapped air in the piping.
- Use suitable pipe hangers or floor stands to support the weight of all water and gas piping.
- The TH must be installed so that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)
- Pipe cold water supply below hot water connection to prevent heat migration during times of low heat demand

4.1 INLET AND OUTLET CONNECTIONS

- All water connections must meet American National Standard Pipe Threads (NPT).
- For ease of service, install unions on inlet and outlet of the appliance. The connection to the appliance marked "Inlet" on the header should be used for return from the system. The connection on the header marked "Outlet" is to be connected to the supply side of the system.

4.2 MINIMUM PIPE SIZE REQUIREMENTS

Minimum water pipe connections are as follows for TH single unit installations. The equivalent number of straight feet of pipe for each valve and fitting in the connecting piping must be considered to properly arrive at the total equivalent feet of straight pipe in the field installed piping to the appliance. Consult factory if longer piping distances are required for a specific application. It is recommended to use copper piping for all system piping to reduce the possibility of the formation of deposits, which may result in heat exchanger starvation.

System pipe size must be in accordance with Table 9 (depending on model). Connection sizes at the heater are given in Table 4.

Table 8: Minimal System Pipe Size

Input, Btu/Hr	Water Size, NPT [in.]
80,000	1
100,000	1
150,000	1
199,000	1
250,000	1 1/4
299,000	1 1/4
399,000	1 1/2
500,000	1 1/2

4.3 HEAT EXCHANGER

This appliance uses precision formed stainless steel tubing to maximize the heat transfer process and achieve 97% steady-state efficiency. This heat exchanger is designed to withstand 160 PSIG working pressure.

A factory installed circulating pump ensures proper water flow during burner operation and creates enough velocity inside the stainless steel tubes and headers that prevents scaling.

4.4 LOW WATER TEMPERATURE SYSTEMS

In combination applications where the heating system requires supply water temperatures below 110°F, connections may be made directly to the TH (Refer to Part 12 Suggested Piping Diagrams). At incoming temperatures of 80°F or lower the TH achieves maximum efficiency. Inlet temperatures must not drop below 40°F to prevent freezing.

4.5 PIPING ARRANGEMENTS

4.5.1 Field Supplied Components

1) Heater system piping

Boiler system piping MUST be sized according to Table 9. Reducing the pipe size can restrict the flow rate through the tank and cause an excessive pressure drop.

2) Isolation Valves

Use only full port ball valves. Failure to supply full port ball valves may result in reduced flow rate through the tank.

3) Anti-Scald Mixing Valve

An anti-scaled mixing valve is recommended when DHW storage is above 120°F.

4) Unions

Recommended for ease of serviceability.

5) System Temperature Sensor

A system temperature sensor is to be installed in the main header at a point to detect controlled temperature and where it will not lead to short-cycling of the boiler.

Table 9: Flow and Pressure Drop at a Given Temperature Rise (DHW)

Input, Btu/Hr	20 °F (11.1 °C) Temp Rise	
	USGPM (min. flow)	ΔP Ft.
80,000	7.5	11.5
100,000	9.4	26.9
150,000	14.0	27.8
199,000	19.2	25.9
250,000	23.5	28.3
299,000	28.8	25.8
399,000	38.4	23.9
500,000	48.6	29.4

4.6 FLOW PROVING DEVICE

Figure 16: Flow Proving Device



The flow proving device is designed to detect when flow is present. This is done by detecting the amount of current (amperes) that exists in the live wire to the pump. When the current becomes too low a flow switch error is displayed indicating a lack of water flow inside the boiler.

Wall Mount	
LED Illuminated	Symptom
TRIP ON	Normal operation
TRIP OFF	Current under trip point

4.7 T&P RELIEF VALVE

This appliance is supplied with a T&P relief valve sized in accordance with ASME Boiler and Pressure Vessel Code, Section IV. To prevent water damage, the discharge from the relief valve shall be piped to a suitable floor drain for disposal when relief occurs. No reducing couplings or other restrictions shall be installed in the discharge line. The discharge line shall allow complete drainage of the valve and line. Relief valves should be manually operated at least once a year.

CAUTION
Avoid contact with hot discharge water

4.8 STAINLESS STEEL STORAGE TANK

The TH is equipped with a stainless steel storage tank. A 20 gallon tank is supplied with TH Models 082 – 152, and a 40 gallon tank is supplied with TH Models 202 – 502. The storage tanks are CSA certified and are rated to operate at a maximum working pressure of 160 psig.

PART 5 ELECTRICAL & CONTROLS

⚠ DANGER
IT IS EXTREMELY IMPORTANT THAT THIS UNIT BE PROPERLY GROUNDED!

5.1 ELECTRICAL CONNECTIONS

Minimum 120VAC 60Hz single phase (15A circuit) is required for the TH models TH-082 through TH-502. The appliance, when installed, must be electrically grounded in accordance with the requirements of the authority having jurisdiction or in the absence of such requirements, with the latest edition of the National Electrical Code ANSI/NFPA No. 70. When the unit is installed in Canada, it must conform to the Canadian Electrical Code, C22.1, Part 1 and/or local Electrical Codes.

- All wiring between the appliance and field installed devices shall be made with wire having minimum 220°F (105°C) rating.
- Line voltage wire exterior to the appliance must be enclosed in approved conduit or approved metal clad cable.
- The pump must run continuously when appliance is being fired.
- To avoid serious damage, DO NOT ENERGIZE the appliance until the system is full of water. Ensure that all air is removed from the pump housing and piping before beginning initial operation. Serious damage may result if the appliance is operated without proper flow.
- Provide the appliance with proper overload protection.

5.2 HIGH LIMIT

A manual reset fail-safe high limit aqua-stat control is internal to the TH controller and the control bulb is installed in a dry well in the heat exchanger outlet. The setting of this control limits maximum discharge water temperature to 210°F. The temperature of the outlet water in the heat exchanger must drop a minimum of 5°F (2.7°C) below the setting of the high limit control before the reset function can be activated.

5.3 TH CONTROLLER

This appliance uses a direct spark ignition control system. The operation of the TH Controller for the direct spark igniter proves the presence of main flame using a flame sensor proof current (0.8 Vdc). A status point alarm of Flame Fail will be displayed on the main panel if the boiler fails to light after three (3) ignition attempts.

Table 10: Connector Description

Connector	Connector Description
J1	Flame Sensor, Ground Rod
J2	Fan Modulation
J3	Display
J4	24VAC Power
J5	Gas Valve, Safety Interlock String
J6	Safety Annunciation, Remote Operator
J8	24VAC Power, Outlet Sensor
J9	Inlet/DHW, Stack Sensor

5.3.1 Service Parts

The TH Controller is not repairable. Any modification or repairs will invalidate the warranty and may create hazardous conditions that result in property damage, personal injury, fire, explosion and/or toxic gases. A faulty direct spark igniter **MUST** be replaced with a new factory part. **DO NOT** use general purpose field replacement parts. Each appliance has one TH Controller, one direct spark igniter and one flame sensor. A list of recommended spare parts is available.

5.3.2 Ignition Module Lockout Functions

The TH Controller may lockout in either a lockout condition requiring pushing the reset button to recycle the control for a CSD1 requirement or an alert condition. A typical lockout fault for the TH Controller occurs when the fan modulation signal is disconnected. Pushing the reset button on the control panel is the only way to reset the TH Controller that is in a lockout condition. Turning the main power “OFF” and then “ON” or cycling the thermostat will not reset a lockout condition. Wait five seconds after turning on the main power before pushing the RESET button when the TH Controller is in a lockout condition. Wait for the status LCD display to refresh indicating that the TH Controller is ready before releasing the reset button.

The TH Controller will go into an alert condition, for example, if the supply sensor is disconnected, flow switch, or air switch are not made. If the fault is not corrected, the boiler will stay in an alert condition. Once the fault is corrected, the boiler will automatically return to normal operating state

5.4 ERROR TABLE

The following tables provide a description of all the possible errors with the TH boiler. Errors can be divided into two groups. Alert errors (will disappear when error is gone) and lockout errors (can only be reset by the RESET button).

When the control is in error the pump will be running. This is done to prevent the freezing of the central heating circuit when the boiler is in error during the winter period. For some non-volatile lockouts the pump will not be running, see table below for more details.

5.4.1 Lockout Codes

Table 11: Lockout Codes

#	Description
0	None
1-31	Internal hardware error
47	Flame rod to ground leakage
49	24VAC low/high
64	Fan speed not proved, ignition failure
67	ILK Off
79	Heater Outlet high limit tripped
91	Inlet sensor fault
92	Outlet sensor fault
93	DHW sensor fault
95	Stack sensor fault
105	Flame detected out of sequence
106	Flame lost in Main Flame Establishing Period (MFEP)
107	Flame lost early in run
108	Flame lost in run
109	Ignition failed
112	Pilot test flame timeout
113	Flame circuit timeout
149	Flame detected

5.4.2 Alert Codes

Table 12: Alert Codes

#	Description
0	None
29	Burner switch turned OFF
30	Burner switch turned ON
47	Flame rod to ground leakage
49	Abnormal 24Vac voltage
50	Modulation Fault
61	Anti-short Cycle
62	Fan speed not proved
67	Interlock Off, safety circuit is open
69	Pilot test hold
79	Outlet high limit tripped (internal limit)
81	Delta-T limit exceeded (40°F)
91	Inlet sensor fault
92	Outlet sensor fault
93	DHW sensor fault
95	Stack sensor fault
97-99	Internal Fault
128	Fan speed failed during prepurge
129	Fan speed failed during preignition
130	Fan speed failed during ignition
131	Fan movement detected during standby
132	Fan speed failed during run
137	Interlock failed to close, safety circuit is open
110	Ignition failure occurred
111	Flame current below threshold (0.8 Vdc)
149	Flame detected
150, 291	Flame not detected
301 - 310	Interlock Off, safety circuit is open
353	Stack limit (PVC: 149°F, CPVC: 194°F, PPE: 230°F, SS, AL29-4C: 250°F)
460	LCI lost in run, safety circuit is open


PART 6 CONTROL PANEL

6.1 TH CONTROLLER

The appliance is provided with an operator interface panel at the front. The TH Controller can be accessed by removing the black-coloured top cover steel jacket which is held on by two (2) screws. The front upper jacket can simply be removed by pulling the panel towards you.

The boiler temperature controller for this appliance is a proprietary Camus® TH Controller. It initiates the local call for heat and sets the target temperature, inlet water temperature. This controller provides the following:

- Readings of inlet and outlet water temperatures stack temperatures, domestic hot water temperature, flame current, status of heater operation, etc.
- Operation as an auto reset high limit.
- Adjustable target temperature
- Molex and JST connectors for ease of service.
- Error message display.



6.2 SETTING THE TH CONTROLLER

Press the 'Next' button to view the desired setting. When the desired setting is satisfied press the **[UP]/[DOWN]** key and this will save the last setting. In normal operating mode the DHW/Inlet temperature and the status of the heater is shown.

6.3 DOMESTIC HOT WATER OPERATION

DHW Storage Tank with Temperature Sensor

The DHW temperature is measured with the heat exchanger inlet sensor and set with parameter DHW setpoint. When the DHW sensor drops below 'DHW setpoint – DHW on hysteresis' the control detects a demand for the storage tank and activates the pump. If the DHW temperature continues to drop the ignition sequence will begin. When the burner is lit the load is PID-modulated so the supply is regulated towards DHW setpoint. The burner will fire at steady-state or it shall shut off if the DHW temperature is greater than 'DHW setpoint + DHW off hysteresis'. The on-board pump will continue to circulate until the pump overrun timer is satisfied.


Frost Protection: To prevent freezing of the heat exchanger, the on-board pump is turned on if the DHW temperature is below 45°F. The on-board pump remains on until the DHW temperature exceeds 50°F. When this occurs the DHW pump continues to circulate until the post-pump timer is satisfied. If the DHW temperature continues to fall below 38°F the controller requests a minimum modulation fire rate. This operation continues until the DHW temperature exceeds 50°F.

PART 7 COMPONENTS

7.1 DIRECT SPARK IGNITER

The direct spark igniter is inserted directly through the combustion chamber front door and held in place by two torx-20 screws which must be torqued to 1 ft-lb (1.4 Nm). Care must be taken when removing and/or installing the igniter. Always remove the igniter prior to removing the fan assembly for inspection of the burner and heat exchanger.

Figure 17: Direct Spark Igniter




During a trial for ignition sequence a properly operating igniter will generate a continuous spark with a 9/64" (3.6mm) spark gap. It is recommended to clean the direct spark igniter using steel wool as required. **DO NOT** use sandpaper or grit-cloth since this will contaminate the metal surface.

7.2 FLAME SENSOR

The flame sensor is inserted directly through the combustion chamber front door and is screwed into the combustion chamber front door. Care must be taken, when installing the flame sensor, to align it perpendicular to the fan flange and parallel to the burner tube and not to over tighten.

Figure 18: Flame Sensor




The ignition module relies on the flame sensor to provide a flame rectification signal. Oxide deposits, improper placement or damaged ceramic insulator will result in insufficient signal leading to ignition module lock out. For proper operation minimum 0.8Vdc must be fed back to the module. Oxide deposit on the sensor rod must be removed with steel-wool. **DO NOT** use sand-paper since this will contaminate the metal surface.

7.3 COMBUSTION AIR FAN

TH uses a modulating air fan to provide combustible air/gas mix to the burner and push the products of combustion through the heat exchanger and venting system. The fan assembly consists of a sealed housing and fan wheel constructed from spark resistant cast aluminum. The fan is operated by a fully enclosed 120 VAC, Single-Phase EC/DC electric motor. The fan housing and motor assembly is fully sealed and **SHOULD NOT** be field serviced. The power draw of the motor is proportional to the modulated gas input rate of the appliance.

7.4 GAS VALVE

Figure 19: Venturi and Gas Valve Arrangement



The Gas Valve supplied with the TH is a combined valve/venturi assembly. A servo pressure regulator is incorporated into the gas valve to provide stable gas supply. Pressure taps are provided to check inlet and outlet gas pressures. An internal fine mesh screen is incorporated in the inlet of the gas valve to prevent debris from entering the combustion chamber. Gas valves are factory set at low and high fire and modulates to maintain combustion characteristics across the full operating range.

7.5 OUTER JACKET

The outer jacket assembly is constructed from mirror finish stainless steel. This ensures a long life for the jacket assembly, with full integrity

PART 8 TH CONTROL PANEL

8.1 SETTING THE TANK HEATER CONTROLLER



Button	Description
	Back button to return to previous menu
	Information button
	Home Button returns screen to home screen
	Navigation buttons
	Confirm selection

The 5-way control pad allows for easy access to various

functions on the Tank Heater HS controller. A button allows for immediate information concerning boiler operation including temperatures, boiler status and any errors that are occurring.

The Boiler Temperature Controller for this appliance is the Honeywell SOLA. It initiates the local call for heat and sets the target return (appliance inlet) water temperature. This controller offers a range of operation modes which provides set point as well as modulating control. It provides the following:

- Readings of inlet and outlet water temperatures as well as flame signal.
- Operation as an auto reset limit.
- Operation as a control for inlet water temperature, outlet temperature, system temperature.
- Available tank mounted sensor used in conjunction with inlet sensor.
- Adjustable; target temp, inter-stage differential, on delay between stages, minimum on time per stage, minimum off time per stage.
- Flame failure signal.
- Error message display in text
- Manual override of boiler input rate for combustion
- Pump exercising feature runs pump 10 seconds every three days in the event of no pump operation.

Levels of Access

Two levels of access to simplify the use of the boiler.

User – Access to general boiler and display settings and adjustments to the central heating and domestic hot water setpoint.

Installer – Access to all user parameters and allows for changes to additional boiler parameters to allow for ease of startup and serviceability.

The screenshot below displays the default homescreen.

Figure 20: Home Screen

```

System setpoint      182 °F
Operating temp       77 °F
Outlet temp          77 °F
Inlet temp           52 °F
Outdoor temp         20 °F

Boiler name          Boiler 1
State                 Standby
Demand               Burner switch off
Access status        User

Alert 29 Burner switch was turned OFF
    
```

Press OK to clear alert

The first five parameters can be user customizable to reflect the most vital information required on the boiler. The list of available parameters is outlined in the table below. This can be done by pressing:

- 1)
- 2) Scroll to *Display Setup*, press **OK**
- 3) Select the line item that is required to be altered, press **OK**
- 4) Select parameter, and press **OK**

PARAMETER	DESCRIPTION
Standard parameters	
System setpoint	Indicates active setpoint
Operating temp	Indicates temperature at modulation sensor (Default: inlet sensor)
Outlet	Outlet Water Temperature [°F]
Inlet	Inlet Water Temperature [°F]
Outdoor	Outdoor Temperature [°F], if equipped
Additional user configurable parameters	
Delta T	Outlet and Inlet water temperature differential [°F]
Fan speed	Actual fan speed [RPM]
Flame signal	Actual flame signal [Vdc]
Firing Rate	Target fan speed [RPM]
DHW	DHW Temperature [°F], if equipped
Stack	Stack Temperature [°F], if equipped
Boiler name	Tank Heater HS model
State	Indicates current boiler operation sequence
Demand	Indicates origin of call for heat (DHW)
Access Status	User, Installer
Outdoor	Outdoor Temperature [°F], if equipped
Error	Alert or Lockout. Section 5.4 provides additional details.

Pressing provides additional troubleshooting information on the diagnostic screen.

Figure 21: Diagnostic Screen

Boiler pump (C)	Off
CH pump (A)	Off
DHW pump (B)	Off
Blower/HSI	Off
External ignition	Off
Pilot valve	Off
Main valve	Off
Alarm	Off
Interlock (ILK)	On
Pre-ignit interlock (PII)	Off
Load Control Input (LCI)	On
STAT (Demand)	On
Time Of Day	Off
Safety relay	Off

Figure 22: Temperature screen

Outlet temp	77 °F
Inlet temp	52 °F
Delta T	25 °F
DHW temp	76 °F
Stack temp	102 °F
Outdoor temp	20 °F
Fan speed	LOW
Flame signal	0.00 uA
Firing rate	0 RPM
4-20mA input	OPEN
System sensor	Outlet

PARAMETER	DESCRIPTION
Boiler pump	Pump A

Sequence of Operation

- STAT
- Pump A
- Interlock
- Pilot Valve

Pump A is energized on DHW


Interlock: Flow switch, LWCO (if equipped), Blocked flue switch (N/C), Low gas switch (4.5" w.c., N/O), High gas switch (14" w.c., N/C)

Pressing  provides additional temperature information.

Intermittent Pump Electrical Connection

Terminals 7 and 8: 115Vac relay coil
Terminals 4 and 6: Normally open contacts

Pump Delay Relay




Constant Pump Operation Electrical Connection

Place black wire #5 on terminal 5. This will provide 115Vac to the TH series pump continuously.

Domestic Hot Water Programming Instructions

Modulation: Fixed Setpoint Operation (Standalone)

Description	Programming Instructions
<ul style="list-style-type: none"> Boiler operates at a fixed DHW setpoint Modulates on boiler inlet sensor (default) Heat demand is generated when Remote Operator is closed. 	<ol style="list-style-type: none"> Place both toggle switches in LOCAL Press ⓘ and select <i>Login</i> Select <i>Advanced Setup</i> <div style="text-align: center; margin: 10px 0;">  <p>The diagram shows a central menu with the following items: Quick Start, Login, Test, Advanced Setup (highlighted with a purple arrow pointing left), Diagnostics, and Display Setup.</p> </div> Select <i>DHW Config</i> <u>Inlet Sensor operation</u> Select <i>Demand switch = Sensor only</i>, and Press OK Select <i>Mod sensor = Inlet</i>, and Press OK, go to step 7 <p style="text-align: center;"><u>DHW Stat operation</u></p> <ol style="list-style-type: none"> Select <i>Demand switch = DHW switch</i>, and Press OK Select <i>Mod sensor = Inlet</i>, and Press OK, go to step 7 <p style="text-align: center;"><u>DHW Sensor operation</u></p> <ol style="list-style-type: none"> Select <i>Demand switch = Sensor only</i>, and Press OK Select <i>Mod sensor = DHW</i>, and Press OK Select <i>DHW Setpoint</i>, and enter desired setpoint using 5-way control Place right hand toggle switch setting to REMOTE for remote operation (if required)

Domestic Hot Water Setup Programming Instructions


Adjust lightoff rate

Description	Programming Instructions						
<ul style="list-style-type: none"> Adjust ignition speed on lightoff This may need to be adjusted to achieve smooth lightoffs cannot be achieved through combustion settings All Tank Heater's leave the factory with an ignition fan speed of 3000 RPM 	<ol style="list-style-type: none"> Place both toggle switches in LOCAL Press ⓘ and select <i>Login</i> Select <i>Advanced Setup</i> <div data-bbox="751 370 1163 678" style="text-align: center;"> <p>Advanced Setup</p> <table border="0"> <tr> <td>Quick Start</td> <td>Login</td> </tr> <tr> <td>Test</td> <td>Advanced Setup ←</td> </tr> <tr> <td>Diagnostics</td> <td>Display Setup</td> </tr> </table> </div> Select <i>Burner Control Ignition</i> Select <i>Adjustable lightoff rate</i>, and enter desired lightoff rate using 5-way control and press OK 	Quick Start	Login	Test	Advanced Setup ←	Diagnostics	Display Setup
Quick Start	Login						
Test	Advanced Setup ←						
Diagnostics	Display Setup						


Adjust stack limit

Description	Programming Instructions						
<ul style="list-style-type: none"> Adjust stack limit based on vent material used PVC: 149°F CPVC: 194°F PP, AL29-4C, Stainless steel: 230°F 	<ol style="list-style-type: none"> Place both toggle switches in LOCAL Press ⓘ and select <i>Login</i> Select <i>Quick Start</i> <div data-bbox="646 1036 982 1279" style="text-align: center;"> <p>Quick Start</p> <table border="0"> <tr> <td>← Quick Start</td> <td>Login</td> </tr> <tr> <td>Test</td> <td>Advanced Setup</td> </tr> <tr> <td>Diagnostics</td> <td>Display Setup</td> </tr> </table> </div> Select <i>Adjustable Stack limit</i>, and enter desired stack limit rate using 5-way control and press OK 	← Quick Start	Login	Test	Advanced Setup	Diagnostics	Display Setup
← Quick Start	Login						
Test	Advanced Setup						
Diagnostics	Display Setup						

Adjust outlet high limit

Description	Programming Instructions
<ul style="list-style-type: none"> Adjust outlet high limit. Maximum setting: 210°F. 	<ol style="list-style-type: none"> Place both toggle switches in LOCAL Press ⓘ and select <i>Login</i> Select <i>Quick Start</i> <div style="text-align: center;">  </div> Select <i>Adjustable high limit</i>, and enter desired stack limit rate using 5-way control and press OK

View burner run time, pump cycles

Description	Programming Instructions
<ul style="list-style-type: none"> To view burner run time, pump cycles for maintenance and service purposes 	<ol style="list-style-type: none"> Place both toggle switches in LOCAL Press ⓘ and select <i>Login</i> Select <i>Advanced Setup</i> <div style="text-align: center;">  </div> Select <i>System Config</i> Select <i>Statistics Config</i>

PART 9 TROUBLESHOOTING

COMPONENT	FAILURE MODE	ANALYSIS
Incoming Power	<ul style="list-style-type: none"> • Two wires interchanged 	<ul style="list-style-type: none"> • No effect on safety • Live and Neutral wires are interchanged.
Transformer Tripped	<ul style="list-style-type: none"> • The 24Volts and 120 Volts wired are interchanged 	<ul style="list-style-type: none"> • Transformer immediately burns out, replace transformer
Pump Fails to Circulate	<ul style="list-style-type: none"> • Wiring Issue 	<ul style="list-style-type: none"> • Check that wires are correctly wired from the TH Controller to the pump delay relay. • Check that 24VAC is delivered to pump coil.
	<ul style="list-style-type: none"> • Faulty Pump on a wet rotor pump 	<ul style="list-style-type: none"> • Pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually • Replace Pump
	<ul style="list-style-type: none"> • Air in the piping system 	<ul style="list-style-type: none"> • Purge all air from the piping system
	<ul style="list-style-type: none"> • Internal Fault on TH Controller 	<ul style="list-style-type: none"> • Replace TH Controller
Relief Valve	<ul style="list-style-type: none"> • System pressure exceeds relief valve setting 	<ul style="list-style-type: none"> • Replace the standard relief valve with a higher rated valve up to the maximum pressure of the heat exchanger. • Improperly sized expansion tank.
Flow Proving Device	<ul style="list-style-type: none"> • Flow Proving Device contacts are open 	<ul style="list-style-type: none"> • Verify LED's on current sensing transformer during a heat demand • Verify for closed valves or obstructions in boiler piping • Verify that all air has been purged from the system • Verify that wiring is correct
Flame Failure (Pressing the manual RESET on the TH Control Panel will be required to restart the ignition sequence)	<ul style="list-style-type: none"> • The boiler has failed to ignite the burner after 5 unsuccessful attempts 	<ul style="list-style-type: none"> • Verify that all air has been purged from gas line • Inspect spark electrode and related wiring for damage and connection errors • Verify that the ignition fan speed is set to 3000 RPM through fan diagnostics screen. • Verify that boiler is properly grounded • Verify incoming gas supply pressure and that it coincides with Table 8. • Verify that the vent/ air inlet piping (if equipped) are correctly installed and obstructions are not present. • Verify 24 VAC is being supplied to the gas valve transformer from the TH Controller during ignition. Check wiring from TH Controller, Gas Valve Transformer and Gas Valve Relay. If a signal cannot be detected, the TH Controller needs to be replaced • If 24 VAC is present, check the outlet of the valve to ensure that gas is flowing. With a manometer connected to the outlet pressure tap of the gas valve a negative pressure should be present during pre-purge. When the valve is energized a change in pressure should occur, if no change is detected the gas valve has failed to open or it is passing insufficient amount of gas. If this is an initial startup increase the low fire gas setting by ¼ turn clockwise. • Inspect flame sensor and associated wiring. Replace if necessary • Inspect the burner. Refer to Burner Maintenance in section 10.7 • Replace the TH Controller


SYMPTOM	FAILURE MODE	ANALYSIS
<p>Flame Disappears During a Run Cycle (Pressing the manual RESET on the TH Control Panel will be required to restart the ignition sequence)</p>	<ul style="list-style-type: none"> • The TH boiler was running and flame signal suddenly disappeared. This condition occurred 3 times. • Lockout: 106, 107, 108, 109 • Alert: 149, 150 	<ul style="list-style-type: none"> • Verify that minimum fan speed is greater than 2500 RPM • Verify that all air has been purged from gas line • Inspect spark electrode and related wiring for damage and connection errors. • Verify that boiler is properly grounded • Verify incoming gas supply pressure and that it coincides with Table 8. • Verify that the gas line connections to the boiler are adequate • Verify that the vent/ air inlet piping (if equipped) are correctly installed and obstructions are not present • Verify 120 VAC is being supplied to the transformer from the TH Controller during ignition. If a signal cannot be detected, the TH Controller needs to be replaced • Verify that 24 VAC is being supplied to the gas valve during ignition. If a signal cannot be detected, the transformer needs to be replaced • Inspect flame sensor and associated wiring. Replace if necessary • Inspect the burner. Refer to Burner Maintenance in section 10.7 • Replace the TH Controller if necessary
<p>Noisy Operation</p>	<ul style="list-style-type: none"> • Supply Gas Issue • Air/Gas Mixture Issue • Air Inlet and/or Vent configuration • Dirty/ Damaged Burner • Air in the piping system • Incorrect Igniter Gap 	<ul style="list-style-type: none"> • Refer to Part 3 Gas Connection in this manual. • Natural Gas Pressure should read between 3" w.c. and 14" w.c. • L.P. Gas Pressure should be at 11" w.c. • Refer to Gas Valve Adjustment Procedure in section 9.2 of this manual for the proper combustion setting. • Refer to Part 2 Air Inlet and Venting • Refer to Burner Maintenance in section 10.7 of this manual for the burner removal and inspection procedure. Clean or replace the burner, if required. • Purge all air from the piping system • Check that spark gap is 9/64"
<p>Auto Reset High Limit Trips</p>	<ul style="list-style-type: none"> • The supply/ outlet temperature has exceeded the setpoint temperature specified. • Alert: 63, 67, 79, 137, 276-281 • ILK OFF 	<ul style="list-style-type: none"> • Verify that the system is full of water and that all air has been properly purged from the system. • Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 12 of this manual. • Verify that 120VAC is being supplied to the boiler pump on a call for heat. If voltage cannot be detected check wiring. • Verify that the pump is circulating when 120VAC is detected. If not, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually • If 120VAC is present during a call for heat, but the pump still does not circulate, replace the pump. • Replace the main TH Controller if necessary

SYMPTOM	FAILURE MODE	ANALYSIS
Manual Reset High Limit Trips (Pressing the manual RESET on the TH Control Panel will be required to restart the ignition sequence)	<ul style="list-style-type: none"> Manual Reset Safety High Limit tripped, supply/outlet temperature in excess of 210°F Alert: 63, 67, 79, 137, 276-281 ILK OFF 	<ul style="list-style-type: none"> Verify that the capillary tube is broken. If this is the case, replace Manual Reset High Limit Verify that the system is full of water and that all air has been properly purged from the system. Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 12 of this manual. Verify that 120 VAC is being supplied to the boiler pump on a call for heat. If voltage cannot be detected check wiring. Verify that the pump is circulating when 120 VAC is supplied. If so, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually. If 120 VAC is present during a call for heat, but the pump still does not circulate, replace pump.
Temperature Overshoot	<ul style="list-style-type: none"> Stack temperature has exceeded the limit set on the boiler. Alert 125, 353 	<ul style="list-style-type: none"> The stack temperature has exceeded the maximum temperature allowed. Measure the resistance of the flue sensor at room temperature, it should be approximately 10kΩ.
	<ul style="list-style-type: none"> The supply/outlet temperature has exceeded the setpoint temperature specified. Alert: 63, 67, 137, 276-281 ILK OFF 	<ul style="list-style-type: none"> Verify that the system is full of water and that all air has been properly purged from the system Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 12 of this manual Verify that 120 VAC is being supplied to the heater pump on a call for heat. If voltage cannot be detected check wiring Verify that the pump is circulating when 120 VAC is supplied. If so, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually If 120 VAC is present during a call for heat, but the pump still does not circulate, replace the pump. Replace the TH Controller, if necessary.
Sensor Not Connected	<ul style="list-style-type: none"> Supply/ Outlet sensor, Alert: 92 Return/ Inlet sensor, Alert: 91 Flue sensor, Alert: 95 DHW sensor, Alert: 93 	<ul style="list-style-type: none"> Verify that the sensors are connected Verify that they are wired correctly. Measure the resistance of the sensors, 10kΩ sensors. Replace the sensor if necessary
Fan Not Turning	<ul style="list-style-type: none"> Fan refuses to rotate Alert 122, 123, 128, 129, 130, 131, 132 	<ul style="list-style-type: none"> Check fan power wires Fan signal wires are interchanged Minimum fan speed must be greater than 1500 RPM
Blocked Flue Switch	<ul style="list-style-type: none"> Blocked flue error Alert: 63, 67, 79, 137, 276-281 	<ul style="list-style-type: none"> Air Switch wire(s) is/are loose Air Switch is set too tight, reduce sensitivity by turning screw ¼ turn clockwise.
Flame Detection is out of Sync	<ul style="list-style-type: none"> Flame detection is present when no visible signs of a flame exist Lockout: 105, 158 	<ul style="list-style-type: none"> Verify supply voltage for proper polarity. Check external wiring for voltage feedback Check internal wiring for proper connections Check the flame sensor and verify that it is clean Replace TH Controller
Blank Display Screen	<ul style="list-style-type: none"> Blank display screen 	<ul style="list-style-type: none"> Check wire connections from TH Controller to DyanMax display

Ignition Failed displayed on screen


Hold 109: Ignition failed

An ignition error occurs when 3 consecutive attempts at lighting the burner have failed. This is a manual reset error where the technician must press OK to clear the error.




Hold 67: ILK OFF (Flow Switch, LWCO, Gas Pressure Switch, Blocked Flue Switch)
Alert 303: Abnormal Recycle: ILK off during drive to Purge
Alert 304: Abnormal Recycle: ILK off during Measured purge time
Alert 305: Abnormal Recycle: ILK off during Drive to Pre-ignition
Alert 306, 307: Abnormal Recycle: ILK off during Pre-ignition
Alert 308: Abnormal Recycle: ILK off during Main Flame
Alert 309: Abnormal Recycle: ILK off during Ignition Period

This error can indicate a blocked flue or blocked intake condition, low gas pressure switch tripped (optional) or high gas pressure switch tripped (optional). To identify the safety that is open set the multimeter to Vac and measure the voltage from one contact to ground. The contacts produce a 24Vac when the circuit is closed.



- Hold 63: LCI OFF (Flow Switch, LWCO, Blocked Flue Switch)**
- Hold 67: ILK OFF (Gas Pressure Switch, High Limit)**
- Alert 303: Abnormal Recycle: ILK off during drive to Purge**
- Alert 304: Abnormal Recycle: ILK off during Measured purge time**
- Alert 305: Abnormal Recycle: ILK off during Drive to Pre-ignition**
- Alert 306, 307: Abnormal Recycle: ILK off during Pre-ignition**
- Alert 308: Abnormal Recycle: ILK off during Main Flame**
- Alert 309: Abnormal Recycle: ILK off during Ignition Period**

The flow switch is not closed or the low water cutoff (LWCO, optional) was tripped. This is an automatic reset error and as soon as flow is proven this error resolves itself. To identify the safety that is open set the multimeter to Vac and measure the voltage from one contact to ground. The contacts produce a 24Vac when the circuit is closed.




Stack limit exceeded displayed on screen

Alert 125: Modulation was limited due to stack limit

Alert 353: Abnormal recycle: stack limit

A flue gas error occurs when the stack temperature has exceeded the maximum limit allowed by the vent material. This is an automatic reset error, when the stack temperature drops 20°F below the limit allowed the boiler is allowed to restart and an ignition attempt is made if the call for heat is not yet satisfied. In the event that a setpoint greater than 120°F is selected and PVC venting is used the setpoint must be reduced to below 150°F to avoid nuisance flame failures. If a setpoint greater than 120°F is required, venting with CPVC, AL29-4C, 316LL or PPE is strongly advised.


The stack temperature is between 15-30°F above the incoming (return) water temperature to the appliance.



Vent Material	Maximum Flue Temperature [°F]
PVC	149
CPVC	194
PPE	230
AL29-4C	300+, limited only by rating of seals
316L Stainless Steel	300+, limited only by rating of seals

Alert 291: Abnormal Recycle: Flame was not on at end of ignition
Alert 294: Abnormal Recycle: Flame was lost during Run
Alert 324: Abnormal Recycle: Hardware flame bias
Alert 377: Abnormal Recycle: Hardware flame bias delta

This type of failure indicates a flame rectification signal issue through the flame rod.



9.1 SETTING THE CORRECT COMBUSTION

- 1) Switch the main power off to the boiler by placing the toggle switch in the 'OFF' position
- 2) Switch the main power on to the boiler and adjust setpoint so that boiler begins ignition sequence.
- 3) Observe the boiler as it goes through its startup cycle and operates at high fire. This cycle is detailed on Figure 33 in section 11.9 Ignition Cycle.
- 4) Insert the combustion measurement probe into the stack when high fire operation is observed. Check to see that fan is running at maximum fan speed using the Control Panel.
- 5) The combustion values should reside in the range listed in Table 18. If combustion values are not within this range refer to Section 9.2 Gas Valve Adjustment Procedure to correct this issue.

Table 13: Combustion Values

	Natural Gas		Propane	
	CO ₂	CO	CO ₂	CO
Max. Fire	8.5% - 9.0%	<100 PPM	9.5% - 10.0%	<100 PPM
Min. Fire	8.0% - 8.5%	<100 PPM	9.0% - 9.5%	<100 PPM

- 6) When the combustion values are satisfied record these values as Camus® requires these for warranty purposes.
- 7) Remove the combustion measurement device and switch the main power off to the boiler by placing the toggle switch in the 'OFF' position.
- 8) Replace the flue temperature sensor back to its proper location.


9.2 GAS VALVE ADJUSTMENT PROCEDURE

If adjustment of the gas valve is required use the following procedure.

In order to perform adjustments to the gas valve the TH must be firing before proceeding.

TH 082 – 252



Figure 23: Venturi & Gas Valve Assembly



To adjust the low fire setting on display

- 1) Press the ⓘ button
- 2) Select *Test* and press **OK**
- 3) Select *Forced Rate* and press **OK**
- 4) Select *Set Low Fire*



The TH should respond immediately and fire at minimum fan speed. When this is achieved locate the low fire adjustment screw. This screw is covered with a cap, which can be removed using a Torx 40 screwdriver. When the correct combustion values are achieved replace the screw cap back on to the gas valve.

	Increase CO2	Decrease CO2
Low Fire Adjustment	 Clockwise	 Counter-Clock Wise

To adjust the high-fire setting on display

- 1) Press the ⓘ button
- 2) Select *Test* and press **OK**
- 3) Select *Forced Rate* and press **OK**
- 4) Select *Set High Fire*

Locate the input adjustment screw on the side of the venturi. Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

	Increase CO2	Decrease CO2
High Fire Adjustment	 Counter-Clock Wise	 Clockwise

TH 292 – 392

Figure 24: TH 292 – 392 Gas Valve



Low-fire air gas ratio adjustment (use Torx 40 for adjustment, clockwise increases CO₂)

High-fire air gas ratio adjustment (Use slotted screwdriver for adjustment, counter-clockwise increases CO₂)

To adjust the low fire setting on display

- 1) Press the **i** button
- 2) Select *Test* and press **OK**
- 3) Select *Forced Rate* and press **OK**
- 4) Select *Set Low Fire*

The TH should respond immediately and fire at 1500 RPM. When this is achieved locate the low fire adjustment screw. When the correct combustion values are achieved replace the screw cap back on to the gas valve.

	Increase CO ₂	Decrease CO ₂
Low Fire Adjustment	 Clockwise	 Counter-Clock Wise

To adjust the high-fire setting on display


- 1) Press the **i** button
- 2) Select *Test* and press **OK**
- 3) Select *Forced Rate* and press **OK**
- 4) Select *Set High Fire*

Locate the high-fire adjustment screw on the top side of the gas valve. The screw can be identified by a red cylinder casing around the screw. Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

	Increase CO ₂	Decrease CO ₂
High Fire Adjustment	 Counter-Clock Wise	 Clockwise

TH 502

Figure 25: TH 502 Gas Valve



Lift top cover to access high fire air/gas ratio adjustment (use 3mm allen key for adjustment, counter-clockwise increases CO₂)

Low-fire air/gas ratio adjustment, use slotted screwdriver for adjustment, clockwise increases CO₂

Gas Inlet

To adjust the low fire setting on display

- 1) Press the **i** button
- 2) Select *Test* and press **OK**
- 3) Select *Forced Rate* and press **OK**
- 4) Select *Set Low Fire*

The TH should respond immediately and fire at 1500 RPM. When this is achieved locate the low fire adjustment screw. When the correct combustion values are achieved replace the screw cap back on to the gas valve.

	Increase CO ₂	Decrease CO ₂
Low Fire Adjustment	 Clockwise	 Counter-Clock Wise

To adjust the high fire setting on display

- 1) Press the **i** button
- 2) Select *Test* and press **OK**
- 3) Select *Forced Rate* and press **OK**
- 4) Select *Set High Fire*

Locate the input adjustment screw on the top side of the gas valve. Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

	Increase CO ₂	Decrease CO ₂
High Fire Adjustment	 Counter-Clock Wise	 Clockwise

PART 10 MAINTENANCE

CAUTION

It is important that all gas appliances be serviced by a qualified technician trained by Camus® Hydronics. It is in your own interest and that of safety to ensure that all local codes, and all the "NOTES" and "WARNINGS" in this manual are complied with. To service or adjust this appliance, it is imperative that the serviceman utilize a combustion analyzer to read CO₂ and CO according to Camus® Hydronics recommendations.

Listed below are items that must be checked to ensure safe reliable operations. Verify proper operation after servicing.

10.1 EXAMINE THE VENTING SYSTEM

Examine the venting system at least once a year. Check more often in the first year to determine inspection interval. Check all joints and pipe connections for tightness, corrosion or deterioration. Flush the condensate drain hose with water to clean. Clean screens in the venting air inlet system as required. Have the entire system, including the venting system, periodically inspected by a qualified service agency.


10.2 VISUALLY CHECK MAIN BURNER FLAMES

At each start up after long shutdown periods or at least every six months. A burner view port is located on the combustion chamber front door.

CAUTION

The area around the burner view port is hot and direct contact could result in burns

Figure 26: Normal Burner Flame Profile (short dense and blue)




- **Normal Flame:** A normal flame at 100% of burner input is blue, with a well defined flame and no flame lifting.
- **Yellow Tip:** Yellow tipping can be caused by blockage or partial obstruction of air flow to the burner.
- **Yellow Flames:** Yellow flames can be caused by blockage of primary air flow to the burner or excessive gas input. This condition **MUST** be corrected immediately.

If improper flame is observed, examine the venting system; ensure proper gas supply and adequate supply of combustion and ventilation air.

10.3 CLEANING BOILER HEAT EXCHANGER

Figure 27: Heat Exchanger & Burner Assembly



- 1) Shut down boiler:
 - a) Turn the main power off to the boiler
 - b) Shut off gas supply at the main manual valve in the gas piping of the main appliance
 - c) DO NOT drain the boiler unless it will be exposed to freezing temperatures. If using antifreeze prevention fluid in the heat exchanger, **DO NOT** drain.
- 2) Allow time for the boiler to cool to room temperature if it has been firing.
- 3) Remove the upper sheetmetal jacket.
- 4) Remove igniter and flame sensor electrodes. If necessary, clean with steel wool. **DO NOT** use sandpaper.
- 5) Remove the fan/ mixing tube assembly from the heat exchanger door.
- 6) Remove burner.
- 7) Examine burner and clean if required as per 10.7.1.
- 8) Examine heat exchanger surfaces to determine if cleaning is required. If cleaning is required remove the (6) nuts fastening the heat exchanger flange from the heat exchanger.
- 9) Disconnect the condensate hose from the heat exchanger and connect a 5/8" diameter hose (field supplied) from the bottom of the heat exchanger to a drain
- 10) Use water proof material to carefully cover the refractory at the rear of the combustion chamber of the heat exchanger
- 11) Use a vacuum cleaner to remove any debris that has collected on the heat exchanger surfaces. **DO NOT** use any type of solvent.
- 12) Brush the heat exchanger with a nylon bristle brush. **DO NOT** use a metal brush. Re-vacuum the heat exchanger.
- 13) Finish cleaning by wiping down the boiler heating surfaces with a clean, damp cloth.
- 14) Rinse out any additional debris with a low pressure water supply. Start rinsing from the rear of the heat

exchanger and slowly working your way towards the front of the heat exchanger.

- 15) Remove the water proof material after cleaning is complete.
- 16) Re-install the heat exchanger door by evenly torquing down the (6) nuts to 3 ft-lbs, burner, igniter and flame sensor, and fan/ mixing tube assembly. Fasten the nuts back to the heat exchanger assembly.
- 17) Re-connect the fan assembly to the boiler mixing tube.
- 18) Re-connect the condensate hose to the heat exchanger.

NOTE

All gaskets on disassembled components must be replaced with new gaskets/sealant on re-assembly, if required. Gasket kits are available from the factory

CAUTION

When the vent system is disconnected for any reason it must be reassembled and resealed according to vent manufacturer's instruction

10.4 CONDENSATE TREATMENT

Condensate occurs when the products of combustion are cooled below their dew point in the heat transfer process. The liquid condensate formed from this high efficiency heat transfer process is mildly acidic. The condensate will typically have a pH ranging from 4.0 to 5.0 as it is discharged from the condensate drain of the appliance. The condensate collection box where the condensate is collected is constructed of a non-corrosive plastic. All materials external to the appliance in contact with the condensate must be corrosion resistant. Condensate must be able to flow freely from the appliance. All condensate flow is accomplished by gravity requiring a minimum downward slope of 1/4" per foot (21mm/m) to ensure proper flow to a suitable drain. A neutralizer box is mounted inside each TH. All condensate piping and connections must be easily accessible for routine maintenance and inspection. Use solid piping when running condensate line across the floor. Check neutralized pH level regularly or as required by local jurisdiction. Replace neutralizer medium as required.

10.4.1 Condensate Volume

There are several factors affecting amount of condensation created by the appliance, however for rough approximation use.

Condensation Volume, US Gallon/Hr = Input, MBH/1000 x 5.0

Many codes will require the acidic condensate to be neutralized before it can be placed in a drain system. A neutralizer to control the pH of the liquid discharged to a drain system is provided with every TH boiler. The neutralizer consists of an industrial grade, non-corrosive plastic reservoir for collection of the condensate. The condensate collects in the reservoir where it is in direct contact with calcium carbonate neutralizer medium. As the reservoir fills, it provides an extended residence time to neutralize the condensate. Residence time in the neutralizer reservoir allows time for the pH to be raised. Prime the neutralizer reservoir with 1 litre of water.

As the condensate migrates through the reservoir in typical applications the pH is controlled to a range of 5.5 to 6.0 before exiting the system. Always check with local codes for specific requirements.

10.5 IGNITER AND FLAME SENSOR ELECTRODES

The direct spark igniter is to be checked at every service interval. Clean the direct spark igniter as required to maintain peak ignition efficiency.

- 1) Turn off main electrical power to the appliance.
- 2) Turn off main manual gas shutoff to the appliance.
- 3) Locate the direct spark igniter and flame sensor.
- 4) Disconnect the power lead to the direct spark igniter and flame sensor
- 5) Loosen and remove the two (2) torx screws that hold the igniter and flame sensor to the heat exchanger flange.
- 6) Pull the igniter horizontally out of the heat exchanger flange. Use care, do not hit or break the igniter leads.
- 7) Remove any debris that has accumulated on the electrodes using steel wool. If the electrodes cannot be cleaned to their original appearance, replacements are needed. Do not use sand-paper since this will contaminate the surface.
- 8) Check that the igniter and flame sensor gaskets are still in good condition (no tears or seams). If the gaskets are in good condition the electrodes can be re-installed back to the heat exchanger flange.
- 9) Check that the igniter gap is 9/64".
- 10) When installing the igniter check that both torx screws are torqued to 1 ft-lb (1.4Nm).

10.6 CHECK IGNITER GROUND WIRING

- 1) Inspect boiler ground wire from the heat exchanger flange to J1-3 of the TH Controller. Check boiler ground wire continuity.
- 2) Verify that all wiring is in good condition and is securely anchored.

10.7 BURNER MAINTENANCE

The burner should be removed for inspection and cleaning on an annual basis. An appliance installed in a dust or dirt contaminated environment will require inspection and cleaning on a more frequent schedule. The fan assisted combustion process may force airborne dust and dirt contaminants, contained in the combustion air, into the burner. With sustained operation, non-combustible contaminants may reduce burner port area, reduce burner input or cause non-warrantable damage to the burner. Never operate this appliance during construction.

Airborne contaminants such as dust, dirt, concrete dust or dry wall dust can be drawn into the burner with the combustion air and block the burner port area.

10.7.1 Burner Removal and Cleaning

Access to the burner will require the following steps:

- Turn off main electrical power to the appliance.
- Turn off main manual gas shutoff to the appliance
- Remove the front cover.
- Disconnect the gas supply connection to the fan inlet.
- Disconnect the fan motor power wires at the harness.
- Remove the direct spark igniter and the flame sensor.
- Remove the three (3) T-25 screws holding the front burner flange in place to gain access to the burner.
- The burner can now be pulled horizontally out of the heat exchanger cavity.
- Use care to prevent damage to the knitted metal fiber of the burner surface.
- Wash the burner with water, such as a garden hose. Never wipe or brush the surface of the burner.
- For optimal results immerse the burner port area in a solution of dishwashing detergent and hot water. **DO NOT** use chlorine based solvents or cleaning agents on the burner. Allow the burner to remain in the solution for a short period of time to remove, dust, dirt and oil or grease laden contaminants.
- Rinse the burner thoroughly with clean water to remove any residue from the detergent cleaner
- The burner should be air dried after removal from the cleaning solution and rinsing.
- Check all gaskets and replace as necessary. Gaskets affected by heat will not reseal properly and must be replaced.
- Replace the burner in the reverse order that it was removed.

NOTE

When the combustion air fan is removed for any reason, the inlet to the burner must be covered to prevent further foreign objects from falling into the burner. Always look inside the burner to check for dents. Do not place a burner back into operation if the inner distribution screen has been dented during the service operation, call the factory for recommendations. Use care when removing and handling the burner, Sharp objects or impact may damage or tear the metal fiber surface rendering the burner unfit for service.

10.8 REMOVAL OF COMBUSTION CHAMBER LINING

The combustion chamber insulation in this appliance contains ceramic fiber material. Ceramic fibers can be converted to cristobalite in very high temperature applications. The International Agency for Research on Cancer (IARC) has concluded, "Crystalline silica in this form of quartz of cristobalite from occupational sources is carcinogenic to humans (Group 1)". Normal operating temperatures in this appliance are below the level to convert ceramic fibers to cristobalite. Abnormal operating conditions would have to be created to convert the ceramic fibers in this appliance to cristobalite.

The ceramic fiber material used in this appliance is an

irritant; when handling or replacing the ceramic materials it is advisable that the installer follow these safety guidelines.

- Avoid breathing dust and contact with skin and eyes.
 - Use NIOSH certified dust respirator (N95). This type of respirator is based on the OSHA requirements for cristobalite at the time this documentation was written. Other types of respirators may be needed depending on the job site conditions. Current NIOSH recommendations can be found on the NIOSH website at <http://www.cdc.gov/niosh/homepage.html>. NIOSH approved respirators, manufacturers, and phone numbers are also listed on this website.
 - Wear long-sleeved, loose fitting clothing, gloves, and eye protection
- Apply enough water to the combustion chamber lining to prevent airborne dust.
- Remove the combustion chamber lining from the water heater and place it in a plastic bag for disposal.
- Wash potentially contaminated clothes separately from other clothing. Rinse clothes washer thoroughly.
- **NIOSH stated First Aid**
 - Eye: Irrigate immediately
 - Breathing: Fresh air

10.9 COMBUSTION AND VENTILATION AIR

Check frequently to be sure that the flow of combustion air to the appliance is not obstructed unless air is piped directly to the heater. Combustion air must be provided to the mechanical room with openings sized per the requirements of the current B149 or National Fuel Gas Code. The TH is setup to allow outdoor combustion air to be connected directly to the appliance.

10.10 CONTROL CIRCUIT VOLTAGE

This appliance uses a transformer to supply a low voltage control circuit. The voltage on the secondary side should be 24 to 28VAC when measured with a voltmeter. A secondary voltage of 21VAC or less supplied to 24VAC components may cause operational problems.

10.11 COMBUSTIBLE MATERIALS

CAUTION

Keep appliance clear from combustible materials; do not store **GASOLINE** and other flammable vapors and liquids in the proximity of the appliance.

PART 11 INSTALLATIONS

10.12 FREEZE PROTECTION FOR INDOOR & OUTDOOR INSTALLATIONS

Installations are not recommended in areas where the danger of freezing exists. Proper freeze protection must be provided for appliances installed outdoors, in unheated mechanical rooms or where temperatures may drop to the freezing point or lower. If freeze protection is not provided for the system, a low ambient temperature alarm is recommended for the mechanical room. Damage to the appliance by freezing is non-warrantable.

- **Location** - Heating boilers, hot water supply boilers or water heaters must be located in a room having a temperature of at least 40°F (5°C).
- **Caution** - A mechanical room operating under a negative pressure may experience a downdraft in the flue of an appliance that is not firing. The cold outside air may be pulled down the flue and freeze a heat exchanger. This condition must be corrected to provide adequate freeze protection.
- **Shut-down and draining** - If for any reason, the unit is to be shut off in a space where danger of freezing exists, the following precautionary measures must be taken:
 - Shut off gas supply.
 - Shut off water supply.
 - Shut off electrical supply.
 - Drain the main exchanger and tank completely.
 - Ensure that the pump and connecting piping are fully drained.

WARNING

Before starting the boiler, smell near the floor and around the boiler for any gas odours or any unusual odour. Remove the stainless steel jacket and smell the interior of the boiler. If there is any sign of a gas leak, do not proceed with startup. Repair all the leaks before attempting to start the boiler.

WARNING

Propane boilers ONLY – Your local propane supplier adds an odorant to the propane gas to allow for propane gas leak detection. In some cases, the added odorant can fade and the gas may not give off any noticeable odour. Before startup have the local propane supplier check for the correct odorant level in the gas.

11.1 CHECKING THE INSTALLATION

- Inspect the connections for water, gas and electricity.
- Inlet gas pressure must be a minimum of 3" W.C. for natural gas and 11" W.C. for propane.
- With the heater off, open the main gas supply valve and vent the trapped air from the piping leading to the heater. Confirm that all gas connections to the heater are tight and that there are no missing test plugs.

Refer to Section 9.1 Setting the Correct Combustion of the manual for recommendations on setting combustion characteristics

11.2 CHECKING THE CONSTRUCTION

- Check the boiler wiring to see that it agrees with the wiring diagram supplied.
- Confirm that all terminal strips and field connections are identified.
- Confirm that the TH Controller control is set in the proper mode. In remote mode an external controller determines the set point and the stage contacts on the TH Controller are always closed. Auto reset limits are fixed in all Modes.
- With the heater running, check for flue gas leaks along the inner cabinet joints and around the flue outlet.
- Repair any leaks prior to proceeding to the next step.
- At the factory, adjustments were made to achieve proper input and acceptable burner performance at full input and at minimum input.

11.3 INSPECT & RECHARGE CONDENSATE COLLECTION/NEUTRALIZING RESERVOIR

- 1) Inspect the condensate reservoir in the TH, making sure the collection box is intact.
- 2) Remove screw holding lid on to condensate collection box. Remove lid from the condensate collection box
- 3) Examine neutralizer medium and refill as necessary with fresh medium
- 4) Fill with fresh water until the water begins to flow out of drain
- 5) Re-install the lid and hold-down screw on the condensate collection box.

WARNING

The condensate collection box must be filled with water to prevent flue gas emissions from escaping during boiler operation.

CAUTION

A leak in a boiler "System" will cause the fill system to introduce fresh water constantly, which may cause the tubes to accumulate a lime/scale build up. Lime/scale buildup leading to heat exchanger failure is **NOT** covered by warranty.

11.4 WATER CONNECTIONS

System pipe size must be in accordance with Table 9 (depending on model). Connection sizes at the heater are given in Tables 4. Any reduction in recommended pipe size may decrease flow resulting in high temperature rise across the heat exchanger, boiler noise, flashing to steam and non-warrantable heat exchanger damage.

11.5 SUMMARY

a) Typical Heater Installations

General Plumbing Rules

- 1) Check all local codes.
- 2) For serviceability, always install unions.
- 3) Always pipe pressure relief valve to an open drain.
- 4) Locate system air vents at highest point of system.
- 5) Expansion tank must be installed near the heater and on the suction side of the system pump.
- 6) Support all water piping.
- 7) Place drip pan underneath heater. (if required)

b) Placing the Heater in Operation

Pre-Start Check List

- 1) Review the location of the heater, clearances from combustible surfaces and available service clearances.
- 2) Review Part 2 Venting. Ensure that all vent components are fabricated from the correct category of materials with adequate clearance from combustibles.
- 3) Fill the condensate collector with fresh water until water begins to pour out the drain.
- 4) Ensure that the heater condensate drain and all vent system condensate drains are properly routed to an acceptable floor drain.
- 5) Review the vent termination point for proper location and clearances.
- 6) If a separate combustion air pipe is used, ensure that it is properly sized, sealed and terminated.
- 7) Review the water piping from the heater to the system. The heater must be installed in a primary/ secondary piping system. Review the diameter and equivalent length of the installed piping to and from the heater to ensure proper flow.
- 8) Ensure that a properly sized system pump is installed with an expansion tank.
- 9) Check system pressure. Ensure a minimum of 18-20 PSIG with the system hot and not more than 90% of the rated pressure of the relief valve.

- 10) Review the installed gas piping from the meter to the boiler. Ensure that the gas pipe, meter and any regulators are adequately sized.
- 11) Review the field wiring and electrical service for the heater controls. Ensure that the electrical service(s) is adequately sized.

Heater Set-Up

- 1) Ensure that the heater and piping system are full of water. Bleed all air from the pump housing and secondary loop.
- 2) Check system for any water leaks.
- 3) Check system for installation of glycol or water treatment where required. Where glycol has been used to maintain the temperature rise across the appliance confirm that the recommended flow for pure water has been increased by 15% and the head loss by 20%.

Boiler Operational Checks

- 1) Turn the heater main power switch to the "ON" position.
- 2) Verify operation of the display on the front panel.
- 3) Program the adjustable points.
- 4) Push the reset button if a lockout error is displayed.
- 5) Install a manometer on the gas supply to the heater and verify minimum gas supply pressure as the burner fires at 100% of rated input.
- 6) Verify operation of safeties as necessary (low water cut-off, high limit, gas pressure, etc.).

Heater Operation

- 1) Appliance should begin the start-up process for the sequence of operation.
- 2) The boiler will fire at 50% of rated input on initial start-up and adjust input as required to meet system demand.
- 3) Based on system demand, the appliance will modulate accordingly.
- 4) As system demand is satisfied, the burner will fire at minimum fire for the given demand and the heater will cycle off when the demand ceases or is interrupted. When this occurs the combustion air fan will decelerate at a pre-programmed rate before the appliance shuts down.

11.6 TEMPERATURE RISE AT FULL FIRING RATE

- 1) The pump must run continuously when the burner is firing.
- 2) With the pump running and the burner in the water heater in the off cycle, the Return/Inlet temperature and Supply/Outlet temperature readings on the TH Control Panel should read approximately the same temperatures.
- 3) Turn the hot water heater on and allow time for the temperature to stabilize. Check the temperature rise when the burner is firing at 100% of rated input.
- 4) Compare the temperature rise on the Control Panel with the required temperature rise at the required flow rate on Table 15.
- 5) Should adjustment be needed, proceed as follows:

- 6) The TH uses stainless steel heat exchanger tubes which are not sensitive to higher water velocity. If temperature rise is lower than anticipated it is not necessary to reduce flow.

If the temperature rise is too high, the water velocity is too low. Adjust as follows:

- 1) Check for flow restrictions. Check for debris in strainers
- 2) Check the pump to be sure it is running properly and that the pump motor is running in the proper direction.
- 3) Common manifold piping for multiple unit installations will require larger minimum pipe sizes.

The required temperature rise and the recommended pump size are based on the heating of potable water with normal hardness. For DHW applications other than normal water hardness choose a pump for the local water hardness conditions. Alternately, soften the water to normal hardness level. Damage to the heat exchanger as a result of scaling or corrosive water conditions in non-warrantable.

Table 14: Temperature Rise Across Heat Exchanger

TEMPERATURE RISE ACROSS HEAT EXCHANGER		
20°F (11.1°C)		
MODEL [BTU/hr]	USGPM	ΔP-Ft.
80,000	7.5	11.5
100,000	9.4	26.9
150,000	14.0	27.8
199,000	19.2	25.9
250,000	23.5	28.3
299,000	28.8	25.8
399,000	38.4	23.9
500,000	48.6	29.4

CAUTION

Temperature rise cannot be adjusted when the burner is firing at less than 100% of input rate.

CAUTION

Adequate care **MUST** be taken to prevent potential scald injury when storing water at 140°F (60°C) and hotter.

WARNING

Should overheating occur or the gas supply fail to shut off, do not turn off or disconnect the electrical supply to the pump, instead, shut off the gas supply at a location external to the appliance

11.7 SETTING THE CORRECT COMBUSTION

Refer to Section 9.1 Setting the Correct Combustion.


11.8 APPLIANCE

- Remove manometers and tighten test port screws.
- Fill out start up report for each heater. Be sure to record all settings and readings. Retain a copy of report for future reference.
- Start up is now complete and heater may be placed into service.

11.9 IGNITION CYCLE

The ignition cycle is shown in the table below. The values are the default factory settings.

Figure 28: TH Ignition Cycle



PART 12 SUGGESTED PIPING DIAGRAMS

Figure 29: Dedicated DHW Suggested Piping Arrangement






Figure 30: Combination Application Suggested Piping Arrangement



Note: Cold water piping should be below hot water connections to prevent heat migration during times of low heat demand

NOTE: HEATING ZONE PUMPS MUST BE EXERCISED ON A REGULAR BASIS DURING SUMMER MONTHS WHEN HEATING IS NOT REQUIRED.



Ref #	Name of Part	Part ID	ALL	82	102	152	202	252	292	392	502
1	Outer Jacket - Left	14-5625		X	X	X					
		14-5605					X	X			
2	Outer Jacket – Top Cover	14-5629		X	X	X					
		14-5609					X	X	X	X	X
3	Air Intake Adapter	44-0008		X	X	X	X	X			
		300704							X	X	
		44-0010									
4	Blocked Flue Switch	SMD8021205256	X								
5	Outer Jacket - Back	14-5604		X	X	X	X	X			
6	Pump (Armstrong)	E7B		X	X						
		E9B				X	X	X			
		E12B							X	X	
		E33B									
7	Gas Valve	VK8115V1341		X	X	X	X	X			
		VR8615B1044							X	X	
		V8730C1015									
8	Expandable Air Inlet Adapter	14-0379		X	X	X	X	X	X	X	
		44-0009									
9	Transition Arm	GM20-70-020-01		X	X	X	X	X	X	X	
		GM10-15-997-03									
10	Venturi	459000-444-003		X	X						
		459000-444-001				X					
		459000-446-051					X	X			
		45900450-010							X	X	
		VMU300A1046									
11	Combustion Fan	150503-00		X	X						
		150563-00				X	X	X			
		150563-05							X	X	
		55667.14002									
12	Rear Bracket	14-5411		X	X	X					
		14-5520-20-25					X	X			
13	Heat Exchanger	4 + 1 Wall		X	X						
		5 + 2 Wall				X					
		8 + 4 Floor					X	X			
		10 + 6 Floor							X		
		15 + 8 Floor								X	
		18 + 10 Floor									
14	75VA Transformer	HCT-01J2BB07	X								
15	Pump Relay	1649341-8	X								
16	Ignition Control	R7910B1009	X								
17	Control Panel	14-5614		X	X	X	X	X			
18	Outer Jacket – Front Top	14-5608		X	X	X	X	X			
		14-5648							X	X	X
19	¼ Turn Lock	Floor Mount	X								
20	Bezel	BezelHS	X								


Ref #	Name of Part	Part ID	ALL	82	102	152	202	252	292	392	502
21	Outer Jacket – Front Bottom	14-5607	X								
22	Bezel Support	14-5615	X								
23	Inner Jacket – Front	14-5610	X								
24	SS Tank	15-0021		X	X	X					
		15-0014					X	X	X	X	X
25	Bracket for Neutralizer Box	14-5525	X								
26	Condensate Neutralizer Box	90-15100		X	X	X					
		90-10030					X	X	X	X	X
27	HX Base Support	14-5631		X	X	X					
		14-5611					X	X	X	X	X
28	Support Leg	14-5621		X	X	X					
		14-5601					X	X	X	X	X
29	Stiffner under Support Leg	14-5622		X	X	X					
		14-5602					X	X	X	X	X
30	Base	14-5623		X	X	X					
		14-5603					X	X	X	X	X
31	Outer Jacket – Right	14-5626		X	X	X					
		14-5606					X	X	X	X	X
32	HX Support	14-5632		X	X	X					
		14-5612					X	X			
33	Flame Sensor	GM10-35-109-02	X								
34	Igniter	GM10-35-108-02	X								
35	Current Transformer	MCSS-A/U	X								
36	Right Bracket	14-5513-20-25	X								
37	Left Bracket	14-5410		X	X						
		14-5518-20-25				X	X	X	X	X	X
38	Heat Exchanger Flange	GM20-65-028-01		X	X	X					
		GM20-65-033-01					X	X	X	X	X
39	Heat Exchanger Flange Nuts	GM10-05-012	X								
40	Igniter/Flame Sensor Screws	GM10-05-020	X								
41	Igniter Gasket	GM10-25-018	X								
42	Flame Sensor Gasket	GM10-25-004	X								
43	Burner Refractory	GM10-25-098-01		X	X	X					
		GM10-25-107-02					X	X	X	X	X
44	Automatic Air Vent	FV-4M1	X								
45	Flue Sensor	NTC-SENSOR-003	X								
46	Sensor Wire	CABLE HARNESS	X								
47	TH Fan Discharge Orifice	14-0377		X	X	X	X	X			
48	Expandable Air Inlet Adapter w/o Pressure Test Point	1056-22		X	X	X	X	X	X	X	
		1056-33									X

Ref #	Name of Part	Part ID	ALL	82	102	152	202	252	292	392	502
49	Burner	221.042.001-A		X	X						
		221.039.001-A				X					
		221.041.001-A					X	X			
		221.037.001-A							X		
		221.038.001-A								X	
50	Burner Gasket	GM10-25-074-09	X								
51	Gas Valve Elbow	45900400-132/B		X	X	X	X	X			
		45900400-144/B							X	X	X
52	Gas Valve Wire Harness	45900441-015B		X	X	X	X	X			
		45900400-144/B							X	X	
53	½" Fire Valve	USA0509101T		X	X	X	X	X			
54	Flex Pipe	2" Diameter		X	X	X	X	X	X	X	
		3" Diameter									X
55	Metal Latch	6521-00-0551-YT	X								
56	Strike	7800-02									
57	On/Off Switch	C6000ALBBCHLI	X								
58	Display	DSP49G2094	X								
59	Gas Valve Relay	T9CP1A54-24	X								
60	TH Wire Harness	77-0037	X								
61	Inlet Sensor	NTC-SENSOR-002	X								
62	Outlet Sensor	NTC-SENSOR-002	X								
63	Tank Sensor	1987799Z/U	X								
64	Rear Vent Adapter	GM10-15-991-01					X	X			
		GM10-15-992-01							X	X	X
65	Gas Valve Relay	1649341-8	X								
66	Anode	Water Heater Anode	X								
67	High Limit	TCL085A (PVC)	X								
		TCL110A (CPVC, PPE, SS)	X								
68	Plastic to Stainless Steel Vent Adapter	300566		X	X	X	X	X			
		300611							X	X	X
69	Rear Thermal Fuse	GM10-35-263-00							X	X	X
70	Front Thermal Fuse	GM10-35-377-00							X	X	X
71	Mixing Chamber Screws	GM10-05-011	X								
72	Target Disk Washer for Target Disk Countersunk Head Screw M4x16 for Target Disk	GM10-25-189-00	X								
73		GM10-15-014-01	X								
74		GM10-05-021	X								
	Not shown in Exploded View										

Part Recommended Spare Part

PART 14 ELECTRICAL DIAGRAMS

14.1 TH 82- 502 INTERNAL WIRING DIAGRAM



14.2 DETAILED CONNECTOR DESCRIPTION

Connector	Pin #	Connector Description
J1		Flame Sensor and Ground
	1	Not Used
	2	Flame Sensor
	3	Ground
	4	Not Used
	5	
	6	
J2		Fan PWM Modulation
	1	Fan Tachometer Signal
	2	Fan Signal, +DC
	3	Fan Pulse Width Modulation (PWM) Signal
	4	Fan Signal, -DC
J3		On-Board Pump
	1	Display, Data Send
	2	Display, Data Receive
	3	Display, Common
J4		24VAC Power
	1-9	Not Used
	10	24VAC
	11	Not Used
	12	Ground
J5		Gas Valve, Safety String
	1	Safety String, Return
	2	Gas Valve, 24VAC
	3-7	Not Used
J6		Safety Annunciator
	1	Blocked Flue Switch
	2	Flow Switch
	3	Flow Switch
	4-8	Not Used

Connector	Pin #	Connector Description	
J8		24VAC Power, Outlet Sensor	
	1	24VAC	
	2	24 VAC Return	
	3	Remote Operator	
	4-7	Not Used	
	8	Outlet Sensor & High Limit	
	9		
	10		
		11-12	Not Used
	J9	1	Inlet (DHW) Sensor
2			
3		Not Used	
4		Outlet Sensor	
5			
T1		Spark Igniter	

CONDENSING BOILER LIMITED WARRANTY

Camus® Hydronics Limited (“Camus®”) extends the following LIMITED WARRANTY to the owner of this appliance, provided that the product has been installed and operated in accordance with the Installation Manual provided with the equipment. Camus® will furnish a replacement for, or at Camus® option repair, any part that within the period specified below, shall fail in normal use and service at its original installation location due to any defect in workmanship, material or design. The repaired or replacement part will be warranted for only the unexpired portion of the original warranty.

THIS LIMITED WARRANTY DOES NOT COVER

1. Failure to properly install, operate or maintain the equipment in accordance with Camus®’ manual
2. Abuse, alteration, accident, fire, flood, foundation problems and the like
3. Sediment or lime build-up, freezing, or other conditions causing inadequate water circulation
4. Pitting and erosion caused by high water velocity;
5. Failure of connected systems devices, such as pump or controller
6. Use of non-factory authorized accessories or other components in conjunction with the system;
7. Failing to eliminate air from, or replenish water in, the connected water system
8. Chemical contamination of combustion air or use of chemical additives to water
9. Production of noise, odours, discolouration or rusty water
10. Damage to surroundings or property caused by leakage or malfunction
11. All labour costs associated with the replacement and/or repair of the unit
12. Any failed component of the hydronic system not manufactured as part of the boiler.

HEAT EXCHANGER

If within six years of the appliance having declared FOB from Camus®, a heat exchanger shall prove upon examination by Camus® to be defective in material, thermal shock, leakage or workmanship, Camus® will exchange or repair such part or portion on the following pro rated limited warranty

Years In Service	TH Series
1	100%
2	100%
3	100%
4	100%
5	100%
6	100%

Heat Exchanger shall be warranted for (20) years of the appliance having declared FOB from Camus® against “Thermal Shock” (excluded, however, if caused by appliance operation at large changes exceeding 150°F between the water temperature at inlet and appliance temperature or operating at temperatures exceeding 210°F).

BURNER

If within FIVE years of the appliance having declared FOB from Camus®, a burner shall prove upon examination by Camus® to be defective in material or workmanship, Camus® will exchange or repair such part or portion.

STAINLESS STEEL STORAGE TANK

If within TEN years of the appliance having declared FOB from Camus®, a stainless steel storage tank shall prove upon examination by Camus® to be defective in material or workmanship, Camus® will exchange or repair such part or portion

ANY OTHER PART

If any other part fails within one (1) year after installation, or eighteen (18) of the appliance having declared FOB from Camus®, whichever comes first. Camus® will furnish a replacement or repair that part. Replacement parts will be shipped f.o.b. our factory.

DURATION OF LIMITED WARRANTY

Any limited warranty, including the warranty of merchantability imposed on the sale of the boiler under the laws of the state or province of sale are limited in duration to one year from date of original installation.

STATE LAW & LIMITED WARRANTY

Some states or provinces do not allow:

- a) Limitations on how long an implied warranty lasts
- b) Limitations on incidental or consequential damages.

The listed limitations may or may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state and province to province.

CONDITIONS

We will not:

- a) Repair or replace any boiler, or part, subject to conditions outlined in ‘This Limited Warranty Does Not Cover’
- b) Reimburse any costs associated with repair and/or replacement
- c) Replace and/or repair any boiler without complete model number/serial number
- d) Replace any boiler without prior receipt of actual rating plate from the appliance.

HOW TO MAKE A CLAIM


Any claim under this warranty shall be made directly to Camus® Hydronics Limited Canadian Head Office

SERVICE LABOR RESPONSIBILITY

Camus® shall not be responsible for any labour expenses to service, repair or replace the components supplied. Such costs are the responsibility of the owner.

DISCLAIMERS

Camus® shall not be responsible for any water damage. Provisions should be made that in the event of a water/appliance or fitting leak, the resulting flow of water will not cause damage to its surroundings.



Name of Owner			
Name of Dealer			
Address			
Model No.			
Serial #:			
Date of Installation:		Date of Initial Operation:	

[6226 Netherhart Road, Mississauga, Ontario, L5T 1B7, CANADA](#)

CAMUS® Hydronics is a manufacturer of replacement parts for most copper finned water heaters and heating boilers as well as a



The CAMUS® CERTIFIED! Seal assures you that Reliability, Efficiency & serviceability are built into every single unit! For more information

supplier of specialty HVAC products. Our service line is open 24 hours, 7 days a week!

on our innovative products from CAMUS® Hydronics Limited, call 905-696-7800 today.



CAMUS® HYDRONICS LTD.

6226 Netherhart Road, Mississauga, Ontario L5T 1B7

TEL: 905-696-7800 FAX: 905-696-8801